

ZeroErr

eRob Rotary Actuator User Manual

Version 3.42



Build Robot Fast

Copyright © 2026 ZeroErr All Rights Reserved.

www.zeroerr.com

What's New

0.1 eRob Rotary Actuator User Manual Version 3.42 Update

0.1.1 NEW Content

- (1) New [Section 5.7 ESD Standard Specifications](#) added;

0.2 Content Modification Markings

0.2.1 New Content

The new content in this document of the current version is marked with a blue strip and ★ symbol.

Example:

★ Thank you for choosing ZeroErr's eRob series rotary actuator module. We appreciate your trust and confidence in our product. To ensure your satisfaction and enhance your user experience, we have carefully designed this user manual to provide you with all the necessary information for operating and maintaining your eRob rotary actuator module.

0.2.2 Enhanced Content

The enhanced content in document of the current version is marked with a green strip and Δ symbol.

Example:

Δ If you have any questions or encounter any issues while using eRob rotary actuator module, please do not hesitate to reach out to our customer support team. We are here to assist you and provide timely assistance to ensure that you have a smooth and enjoyable experience.

Record of Revisions

Version	Iteration	Description	Date
3.34	1	Symbols and terminology improvements in compliance with ISO80000; Image improvement; Page layout improvements; Header and footer improvements; Hyper link functionality added; Content improvements; Equation improvements; Removed Chapter2. Packaging and Accessories.	2023/11/27
3.35	2	New content added, content discrepancy error fixed, removed outdated content.	2024/01/05
3.36	3	New content added.	2024/01/31
3.37	4	New content added, content discrepancy error fixed, removed outdated content.	2024/02/21
3.38	5	New content added, paragraph description enhancement, content discrepancy error fixed, removed outdated content, improved readability of the title page, page structure improved.	2024/06/11
3.39	6	New content added, paragraph description enhancement, plots enhancement.	2024/12/04
3.40	7	New content added, paragraph description enhancement, content discrepancy error fixed.	2025/11/05
3.41	8	New content added, content discrepancy error fixed.	2026/02/27
3.42	9	New content added.	2026/04/13







SAFETY GUIDE

Before installing, operating, maintaining, or inspecting this product, please be sure to read this SAFETY GUIDE and fully understand the information provided in this user manual and appendices before using the product. Mishandling the eRob rotary actuator module may cause harm to personnel or damage to property. Therefore, it is essential that the operator read and understand this manual thoroughly.




It is recommended to keep this manual in a readily accessible location for easy reference during operation and maintenance of the product.

It is crucial to follow the SAFETY GUIDE outlined in this manual.

0.3 NOTATION

Symbol	Definition
	DANGER: This indicates an imminently hazardous electrical usage situation which, if not avoided could result in death or serious injury.
	DANGER: This indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury.
	WARNING: This indicates a potentially hazardous electrical situation which, if not avoided, could result in personal injury or serious equipment damage.
	WARNING: This indicates a potentially hazardous situation which, if not avoided, could result in personal injury or serious equipment damage.
	WARNING: This indicates a hot surface that can create a hazard, which if touched, could result in personal injury.
	CAUTION: This refers to a situation which, if not avoided, could result in equipment damage.

0.4 Please Adhere to the Following Guidelines to Avoid Personal Injury:

	<p>DANGER:</p> <ol style="list-style-type: none"> 1. Set Appropriate Protection Limits: Avoid any incorrect target command when operating the rotary actuator in torque mode. Set appropriate protection limits on the host controller and the servo driver, including position limit, speed limit and current limit. 2. Perform Risk Assessment: Machine manufacturers must perform risk assessment on machine and take appropriate measures to ensure unexpected movements will not result in any personal injury or property damage. More demands may be placed on professionals after risk assessment. 3. Assembly Precautions: Make sure the rotary actuators are properly and securely in place without the danger of accidental falls. Our company is not responsible for any damage caused by abnormal operation.
	<p>WARNING:</p> <ol style="list-style-type: none"> 1. Conduct the Initial Test Without Load: Put rotary actuator trial run under a no-load condition. (Do not connect to drive shaft).
	<p>WARNING:</p> <ol style="list-style-type: none"> 1. Beware of Hot Surfaces: During operation of the motors, depending on their ingress protection level, the surfaces can be very hot. The surface temperature will exceed 85°C, beware of minor burns. Measure the temperature and wait until the motor cools below 40°C before touching it. 2. Keep Module Suspended: The eRob module have passed strict power consumption testing before leaving the factory. The module generates heat due to friction, oil agitation loss, and brake power consumption, even when there are no load. The compact design and smooth surface of the Rob module may not be sufficient to dissipate the heat generated when it is not mounted (e.g. placed on the desktop), resulting in an increase in surface temperature. This could trigger temperature protection and pose a risk of high-temperature burns. For detailed information on the power consumption during no load operation, please refer to Chapter 25.
<p>If this product is used in environments where human safety or material losses are at stake, it is crucial to install safety devices that can prevent accidents even if the output control is disabled due to damage.</p>	

0.5 Please Adhere to the Following Guidelines to Avoid eRob Damage:



WARNING:

1. Beware of the risk of metal debris entering connector gaps:

Before installation, thoroughly clean the outer surface of the housing to ensure the installation environment is free of metal debris. Common sources of metal debris include: Metal shavings generated when tightening or loosening screws during robot installation. Metal particles produced from grinding or fitting machined parts. Broken copper strands from cable manufacturing or handling. During installation, wiring, and related operations, ensure that no metal debris falls into: The electrical connectors on the rear cover of the joint (including CAN, EtherCAT, RS485, IO, multi-turn battery, and power interfaces, as well as the gaps between these connectors), The through-holes, or The joint's hollow shaft gaps (where the output encoder disk is mounted). Failure to prevent this may result in communication errors or electrical faults.

2. Do Not Plug or Unplug Power Cable While Power ON:

Please make sure to perform wiring and inspection tasks only after confirming that the Power LED indicator light has turned off by itself.

3. Do Not Plug or Unplug CAN Cable While Power ON:

Since the electrical level of the CAN_GND at both ends of the host controller and the actuator may be different when they are not wired, the voltage difference between the CAN_GND at both ends will cause damage to the CAN interface at the moment of connection.

4. Do Not Plug or Unplug RS485 Cable While Power ON;

Due to the possible difference in the ground potential between the master controller and the eRob module when not connected, upon connection, the voltage difference between the two ground points may lead to damage to the RS485 interface.

NOTE: It is important to note that the process of plugging and unplugging cables while the power is on should include the power from power supply, “eRob to PC Connector”, and controller. This means that all three components need to be powered OFF during the cable connection or disconnection process.

5. Connect Power Terminals Properly and Securely:

Refer to [Section 5.10](#)

6. Ground Module Housing:

If the eRob joint housing is not properly grounded, static charge may accumulate on the housing, potentially causing it to become electrically charged. Proper grounding of the housing is therefore required. For detailed grounding instructions, refer to [Chapter 6](#), specifically [Subsection 6.6.3](#).

7. Use ZeroErr's Proprietary Multi-Turn eRob Battery:

Continued on next page

Continued from previous page

A rotary actuator with multi-turn counting function will have an extra battery being packaged in the box, which has a stable voltage, a temperature range of $-55^{\circ}\text{C}\sim 85^{\circ}\text{C}$, and a normal working life of more than 10 years. The battery is also available on our website: <https://www.zeroerr.com/products/accessories/battery>. Do not use other batteries other than ZeroErr proprietary multi-turn counting battery. We do not offer technical support for other batteries. Typically, each multi-turn eRob module is designed to operate with a single battery, which ensured both convenience and reliability during wiring procedure. It is important to note that if an attempt is made to modify a single battery setup to supply power to multiple eRob modules simultaneously, ZeroErr cannot be held responsible for any potential consequences arising from this modification and the associated rewiring.

8. Adhere to Voltage and Current Limits:


Comply with technical data and specifications (nameplate and documentation). Exceeding the permissible voltage value or current value will damage the motor and appear abnormal phenomenon, such as overheating.



WARNING:

1. Pay Attention to the Rust-Prone Parts:

The material in the area indicated by the arrow in the image below is susceptible to rust. Therefore, when conducting installation operations, it is crucial to exercise caution and take necessary precautions. This includes wearing gloves to protect your hands and applying an anti-rust treatment to prevent corrosion and ensure the longevity of the material.



2. Do Not Exceed the Permissible Torque:

Please do not exceed the momentary permissible maximum torque when applying torque. Otherwise, it may result in loosening of fasteners, shaking, or damage, leading to product failure. When directly attaching to the output shaft, such as a robotic arm, colliding with the arm can cause damage and loss of control over the output shaft.

3. Do Not Disassemble Assembled Products:

This product is a high-precision device and must be installed and calibrated by professionals. It is strictly prohibited to disassemble or reassemble the assembled product. Reassembling the product may result in the loss of its original performance. Any product failures resulting from improper use will void the product warranty.

4. Do Not Modify the Module Assembly:

The product is a combination of various components, and its performance cannot be guaranteed when used in conjunction with other kits or components not intended for it. Any product malfunction resulting from improper use will result in the loss of warranty coverage. It is important to use the product as intended and avoid altering or mixing its components to ensure optimal performance and warranty protection.

5. Do Not Alter the Warranty Label:

Continued on next page

Continued from previous page

Removing the tamper-proof warranty label on this product will result in the loss of warranty coverage for the product.

6. Use the Module in the Specified Environment:

① The product has an IP54 protection rating.

② Extreme operating temperature: -40~70°C

(At extremely low temperatures, joint friction will increase significantly, resulting in higher operating currents. At high temperatures, over-temperature alarm protection and shut-off actions may be triggered.)

③ General Operating temperature: 0~60°C;

④ Storage temperature: -30~60°C;

Using low-temperature grease will decrease the operational resistance of the module in low temperatures. For detailed model specifications, please refer to [Section 2.1](#).

⑤ Operating and storage humidity: 20%~80%RH (non-condensing);

⑥ Avoid exposure to dust, metal particles, corrosive gases, flammable gases, oil mist, and similar substances.

7. Handle the Module with Care:

Avoid using hammers or forcefully striking any components or assemblies. Additionally, take precautions to prevent cracks or dents caused by accidental drops or impacts. Damaging the product in such a way can compromise its integrity, leading to performance issues and potential malfunctions. Handle the product with care to ensure its longevity and proper functionality.

8. Transportation:

Ensure that the personnel handling the transportation of the module do not bear excessive weight on their bodies, and maintain the original packaging during transportation. Use appropriate transportation equipment and adhere to all regional and national transportation guidelines. Our company is not responsible for any damages caused during transportation.

9. Operation Precaution:

The ZeroErr module is equipped with several outstanding features. However, incorrect operation or mishandling of its principles or structure can not only hinder its performance but also potentially result in malfunctions and damage. When using the module, it is vital to pay particular attention to the following:




① Avoid using the joint module in applications where there is a risk of dropping or

falling. Even if there are no visible external damages, internal stress accumulation

can weaken its fatigue strength. Therefore, it is advisable not to use the module if it

has been dropped.

0.6 Please Adhere to the Following Guidelines to Avoid Performance Issues:

	<p>WARNING:</p> <p>The following actions may cause performance issues:</p> <ol style="list-style-type: none"> 1. Failure to tighten the screws according to the specified torque standards or not using a diagonal method to tighten them. 2. Operating the product on a wooden table. 3. Running the joint module on a movable platform (such as an improperly secured base). 4. Installing the eRob module in a plastic or 3D-printed housing may effect heat dissipation, leading to overheating of the eRob module.
	<p>WARNING:</p> <ol style="list-style-type: none"> 1. Each eRob rotary actuator has undergone strict jitters and noise tests before delivery. If it fails to meet expected operation results, please reinstall it strictly in accordance with Chapter 18. 2. Mount the robot on a sufficiently solid surface without vibration (such as steel plates). 3. Even when opting for a rotary actuator model with EtherCAT communication, it is highly recommended to connect and preserve the joint CAN communication line within the entire system. It is also advisable to pre-configure the joint CAN ID (as outlined in Section 6.2) in order to facilitate subsequent debugging processes. This includes troubleshooting, parameter adjustments, firmware upgrades, and other tasks related to individual joints. Retaining the joint CAN communication line enables efficient and effective debugging procedures throughout the system's operation.
	<p>CAUTION:</p> <ol style="list-style-type: none"> 1. Suspended and No-Load Operation: eRob rotary actuator will also generate heat when running under no-load condition. The temperature of the rotary actuator which has not been installed actually will gradually increase due to nowhere for heat diffusion, until the temperature protection is triggered. Please test with caution. Overheating is not an actuator fault under a suspended high-speed continuous operation. Install the rotary actuator normally, and additional cooling components are not required. 2. Oil churning noise reminder: After the eRob rotary actuator rests horizontally in the axial direction for a period, there will be a slight oil churning noise due to the uneven distribution of grease sedimentation when running at a speed above 80% of the rated speed. The sound will disappear naturally when the distribution of grease gets even after the rotary actuator runs for about 5 minutes. The characteristics of the noise are:

Continued on next page

Continued from previous page

- | | |
|--|--|
| | <p>(1) It appears when running at a high speed after keeping in a static state to cool down;</p> <p>(2) The noise in the vertical state is lower than that of in the horizontal state;</p> <p>(3) The noise at high temperature is lower than that of when the temperature is low;</p> <p>(4) The noise at a low speed is lower than that of at a high speed;</p> <p>(5) It will disappear naturally after running for about 5 minutes. This noise is not an actuator fault, please rest assured to use.</p> |
|--|--|

0.7 Maintenance:**WARNING:****1. Enhanced Protection for Specialized Industries:**

Within the eRob module, lubricating grease is well-contained with effective seals at the input shaft and various joints. While these seals typically meet IP65 standards for general industrial use, it is advisable to consider additional external protective casings if deploying the product in specific sectors like food, medical, or pharmaceutical industries.

2. Grease Replacement in eRob Modules:

The lubricating grease within the eRob module does not require replacements, and the SWG does not allow for grease changes.

0.8 Disposal Information:**WARNING:****1. Module Disposal must comply with industrial waste standards:**

Please ensure that the product is disposed of as industrial waste and in compliance with relevant regulations and guidelines.

Table of Contents

What's New	i
0.1 eRob Rotary Actuator User Manual Version 3.42 Update	i
0.1.1 NEW Content	i
0.2 Content Modification Markings	i
0.2.1 New Content	i
0.2.2 Enhanced Content	i
Record of Revisions	ii
SAFETY GUIDE	iii
0.3 NOTATION	iii
0.4 Please Adhere to the Following Guidelines to Avoid Personal Injury:	iv
0.5 Please Adhere to the Following Guidelines to Avoid eRob Damage:	v
0.6 Please Adhere to the Following Guidelines to Avoid Performance Issues:	viii
0.7 Maintenance:	ix
0.8 Disposal Information:	ix
Symbols and Abbreviations	xiv
1 Overview	1
1.1 About This Manual	1
1.2 Introductions of the eRob Series Modules	1
2 eRob Specifications	2
2.1 Understanding the eRob Model Code Definitions	2
2.2 The Specifications of eRob Modules	4
3 Power Input of eRob	9
3.1 Power Supply Voltage and Rated Current Value	9
3.2 Permissible Maximum Input Voltage	9
3.3 Permissible Minimum Input Voltage	11
4 Rotary Actuator Positive Rotation Direction	13
5 Electrical Interface and Status Indicator LED	14
5.1 Indicator LED Function	14
5.2 CAN Communication Interface	16
5.3 EtherCAT Communication Interface	17
5.4 Multi-Turn Power Supply Battery Interface	18
5.5 48V Power Supply Interface	19
5.6 I/O Signal Terminal	20
5.7 ESD Standard Specifications	21
5.8 Cable Specification Explanation	22
5.9 Force Instruction of Connector	22
5.10 Force Instruction of Power Terminal	23

6	Cable Wiring Among Rotary Actuators	24
6.1	Power Supply Wiring Illustration	24
6.1.1	Examples of Collaborative Robot Power Wiring	26
	3 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-4):	26
	5 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-5):	27
	10 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-6):	28
	20 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-7):	29
6.2	CAN/CANopen Communication Wiring Diagram (as shown in Figure 6-8)	30
6.3	EtherCAT Communication Wiring Diagram (as shown in Figure 6-9)	31
6.4	Modbus-RTU Communication Wiring Diagram(as shown in Figure 6-10)	32
6.5	I/O Signal Terminal Wiring Diagram	33
6.6	Important Wiring Instructions	35
6.6.1	Precautions for Wiring Through Module Central Hole	35
6.6.2	Instructions for Cable and Battery Fixing Methods	36
6.6.3	Module Housing Grounding	37
7	Brake Instruction	38
7.1	Instruction and Caution	38
7.2	Brake Lifespan	39
7.2.1	Brake Opening and Closing Times	39
7.2.2	The Amount of Forcible Drags While Brake Engaged	39
7.3	Method for Forcibly Releasing the Brake (Non-Enabled State)	39
7.3.1	PC Software (eTuner) Operation	39
7.3.2	EtherCAT Operation	40
7.3.3	CANopen Operation	42
7.4	Abnormal Brake Judgment	42
8	Kinetic Energy Recovery	43
8.1	Analysis of the Cause of Kinetic Energy Recovery	43
8.2	Solution	43
8.2.1	Add Bleeder Resistor	43
8.2.2	Add Super Capacitor	44
8.2.3	Add Storage Battery	44
9	Encoder and Position Feedback	45
9.1	Encoder Resolution and Single-Turn Position Feedback	45
9.2	Position Feedback of Rotary Actuator	45
9.3	Position and Cautions of Rotary Actuator with Single-Turn Function	46
9.4	Position and Cautions of Rotary Actuator with Multi-Turn Function	46
9.5	Instruction of Zero Position Calibration Function	47
9.5.1	Zero Position Calibration Function of Single-Turn Rotary Actuator	47
9.5.2	Zero Position Calibration Function of Multi-Turn Rotary Actuator	48
9.6	Instruction of Position Protection Function	50
10	Multi-Turn Power Supply Battery Instruction	52
10.1	Function of Battery	52
10.2	Cautions on Battery Usage	52
10.3	Power Consumption of Multi-Turn Encoder	52
10.4	Battery Related Errors Handling	54

11 Multi-Turn Encoder Battery Under-Voltage Warning	55
11.1 The Status when 48V Power Supply Switch from OFF to ON (0 -> 1)	55
11.2 The Status When the 48V Power Supply Has Been Activated (1)	56
11.3 The Status When 48V Power Supply from Startup to Close to Startup (1 -> 0 -> 1)	56
12 Strain Wave Gear Analysis	57
12.1 Gear Ratio Analysis	57
12.1.1 Output Rotational Speed Calculation	57
12.1.2 About Speed Setting and Angular Velocity Conversion	57
13 PC Connection and Debugging	60
14 Trial Run for Rotary Actuator	61
15 PID Tuning with Load	63
15.1 Speed Loop Adjustment	63
15.2 Position Loop Adjustment	64
15.3 EtherCAT Dynamically Modify PID Function	67
16 Special Function Introduction	68
16.1 PDO Dynamic Configuration	68
16.2 PID Control Function of Variable Integral Upper Limit	68
17 Permissible Forces in All Directions	69
17.1 Maximum Moment Load Calculation	69
17.2 Cross Roller Bearing Lifespan Calculation	70
17.2.1 Avergae Load Calculation	71
17.2.2 Load Coefficient Calculation	72
17.3 Static Safety Coefficient Calculation	73
17.4 Ratcheting Torque	75
18 eRob Installation Requirements	78
18.1 Seam Allowance Requirement of Flange Connection	78
18.2 Screw Locking Method	79
18.3 Screw Torque Standard	79
18.4 Common Improper Installation	80
18.5 Pre-Installation Cleaning Advisory	83
19 Firmware Version Upgrade	84
20 Restoring Factory Parameter Function	85
21 Safe Torque Off (STO)	86
21.1 STO Function Configuration	86
21.1.1 One STO Branch Circuit Function Configuration	86
21.1.2 Two STO Branch Circuits Function Configuration	87
22 Virtual Torque Sensor(VTS)	88
23 Life of Rotary Actuator	91

24 Pulse Direction Control Mode Instruction	92
24.1 Parameter configuration of pulse direction control mode	92
24.2 Pulse direction motion control	93
25 Output Characteristic	96
25.1 eRob Motor Current, Output Torque, Rotational Speed Curve	96
25.2 eRob Rotary Actuator Motor Parameter	100
25.2.1 eRob Rotary Actuator Version Identification	100
25.2.2 Motor Parameter	100
25.3 eRob Motion Range	102
25.4 eRob Bus Current, Output Torque, Rotational Speed Curves	109
26 Troubleshooting Instruction	111
26.1 Abnormal CAN Communication	111
26.1.1 “Check whether the drive is powered on” window pops up when click “con- nect” for test in the host computer	111
26.1.2 The number of CANID identified by the host computer connection test is less than the actual CANID number of connection	113
26.1.3 The data displayed on “Status Monitor” interface jumps abnormally when the host computer is connected.	113
26.2 Abnormal EtherCAT Communication	114
26.3 Motor Stalling Error	114
26.4 The Velocity Error Exceeds the Limit Value (Error HEX:0x8400, DEC:33792)	115
26.5 Position Feedback Value Misalignment After Power Cycle	116
26.6 Abnormal RS485 (Modbus) Communication	117
27 About Rigidity	119
27.1 Rigidity	119
27.2 Torsional Quantity Calculation Example	121
27.3 Hysteresis Loss	121
27.4 Backlash	121
28 Back-Driving by External Force	122
A Safety Precautions for Multi-Turn Encoder Battery	123
B Error Codes and Suggestions	124
C Warranty	125
C.1 Warranty Period and Scope	125
C.2 Warranty Terms	125
Declaration	127
About Us	128

Symbols and Abbreviations

α	angular acceleration/deceleration
η_t	the efficiency of SWG transmission
ω	output angular velocity
ω_θ	output angular velocity measured in °/s
ω_{rad}	output angular velocity measured in rad/s
ω_t	target speed (angular velocity)
θ	position angle
θ_{in}	angle of wave generator input shaft
θ_{out}	angle of flexspline output shaft
AAB	Armature Actuated Brake
Acc.	Acceleration
AKA	Also Known As
C	basic dynamic load rating
C_0	basic static load rating
CCW	Counterclockwise
D	diameter
DC	Direct Current
$D_{Circular\ Spline}$	the circular spline diameter
Dec.	Deceleration
$D_{Output\ Shaft}$	the output shaft diameter
d_p	pitch circle diameter
ECAT	EtherCAT
E_{FED}	error caused by flexspline elastic deformation
e.g.	for example
E_{in}	the transmission error of input shaft
E_{ITG}	error caused by input teeth gap
E_k	kinetic energy
E_M	error caused by manufacture
E_{out}	error caused by circular spline elastic deformation
etc.	and so forth
E_{WGD}	error caused by wave generator deformation
F	force
F_a	axial load
$F_{a,avg}$	average axial load
$F_{a,max}$	maximum axial load
F_r	radial load
$F_{r,avg}$	average radial load
$F_{r,max}$	maximum radial load
f_s	static safety coefficient
FS	factor of safety
f_w	load coefficient
GR	Gear ratio
I	electrical current

Continued on next page

Continued from previous page

$I_{a, motor}$	the actual current input of motor
IP	Ingress Protection
ISO	International Organization for Standardization
K_e	voltage constant of torque motor AKA back EMF constant
K_m	Moment Stiffness
K_T	the torque constant
$K_{T, eRob}$	the eRob module torque constant
$K_{T, motor}$	the motor torque constant
L_a	axial load length
L_h	life measured in hours
L_n	life of L_{10} or L_{50}
$L_{Output Shaft}$	the thickness of output shaft flange
L_r	radial load length
M_c	permissible moment load
M_{max}	maximum moment load
m_G	SWG gear ratio
N	the amount of revolutions
n	rotational speed
n_a	the actual maximum rotational speed output by the rotary actuator
n_{avg}	average SWG input / motor output rotational speed
N_{avg}	average output speed
N/A	Not Applicable
$NASA$	National Aeronautics and Space Administration
n_c	output rotational speed measured in counts/s
n_m	motor / SWG input rotational speed
n_o	SWG output rotational speed
N_{out}	the amount of eRob output rotation
n_r	the rated maximum output rotational speed
n_{RPM}	output rotational speed measured in RPM
n_t	motor rated rotational speed used for module rated torque testing (2000RPM)
OD	Outer Diameter
P_o	static equivalent load
P_c	current encoder position
P_C	dynamic equivalent
$P_{encoder}$	encoder position
p_{input}	the amount of external input pulses
P_s	single-turn encoder position
R	offset length
RPM	Revolutions Per Minute
SI	International System of Units
SWG	Strain Wave Gear
t	time
T	torque
t_a	acceleration/deceleration time
T_a	the actual torque output by the rotary actuator module
T_{avg}	average load torque on the SWG output side
T_{out}	the eRob output torque

Continued on next page

Continued from previous page

T_r	the rated torque output by the eRob module
V_{DC}	DC voltage
V_{in}	the actual voltage supplied to the rotary actuator module
V_r	the rated input voltage of the eRob module
X	radial load coefficient
Y	axial load coefficient

Chapter 1 Overview


1.1 About This Manual

This manual contains comprehensive information regarding the operation parameters, safety range, application methods, safety precautions, and other relevant details of the eRob series rotary actuator (aka servo, servo motor, robot joint) developed, designed, and manufactured by ZeroErr. We strongly advise reading the manual carefully before engaging in any operation.

1.2 Introductions of the eRob Series Modules

Each model in the eRob series rotary actuator incorporates ZeroErr's proprietary servo driver and absolute value encoder technologies. These technologies have been meticulously refined through extensive customer service experience, ensuring unparalleled performance and reliability.

The primary objective of the eRob series is to streamline and accelerate the robot development process while prioritizing safety. By offering pre-integrated and pre-tested rotary actuator unit, ZeroErr significantly simplifies the integration process for robot developers. This approach reduces development time and associated costs typically incurred with custom design and integration.



(a) I-Type eRob Module

(b) T-Type eRob Module

Figure 1-1 Exploded View of eRob Rotary Actuator Modules

The eRob series rotary actuator offers a diverse range of meticulously crafted units, including the I-type eRob and T-type eRob. Each model is engineered to deliver precise performance and features a compact form factor, ensuring versatility across different applications.

Designed as a all-in-one solution, each eRob rotary actuator unit incorporates essential components within its small form factor. These components include a servo driver with an integrated temperature sensor, absolute encoder for the motor, multi-turn absolute encoder for output, frameless brushless torque motor, armature-actuated friction brake (AAB), high-precision strain wave gears (SWG, aka Harmonic Drive), as shown in [Figure 1-1](#)

The eRob series rotary actuators eliminate the need for time and effort investment in selecting, designing, purchasing, and assembling multiple mechanical and electronic devices from scratch. This simplifies the development process and accelerates time to market for robotic applications.

Chapter 2 eRob Specifications

The model code of the eRob series rotary actuator modules and instructions to read them are explained below (as shown in Figure 2-1).

eRob Series Model																		
Actuator Series	Outer Diameter	Gear Type		Gear Ratio		Form Factor	Brakes		Output Shaft Encoder		Hollow Bore Diameter	Communication Protocol	Torque Sensor		Customization			
eRob	70	F		100		I	B		M		18	E	N		□			
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓			
ZeroErr eRob Series Rotary Actuator Module	70 Φ70mm	F	Flat	50	50 GearRatio	I	I-Type	F	Free Motion (No Brake)	S	Single-Turn Encoder	18 Φ18mm	C	CANopen	N	No Torque Sensor	C	Low Temp. Grease
	80 Φ80mm																	
	90 Φ90mm	100	100 GearRatio	HS	High Precision Single-Turn Encoder													
	110 Φ110mm					120	120 GearRatio	HM	High Precision Multi-Turn Encoder									
	142 Φ142mm	160	160 GearRatio															
	170 Φ170mm																	

Model Code	eRob70F100I-BM-18EN
-------------------	----------------------------

Figure 2-1 The Model Code of eRob Series Rotary Actuator Modules

2.1 Understanding the eRob Model Code Definitions

Model Code Example:

eRob	70	F	100	I	-	B	M	-	18	E	N	□
(1)	(2)	(3)	(4)	(5)	-	(6)	(7)	-	(8)	(9)	(10)	(11)

(1) Actuator Series: ZeroErr eRob Series Rotary Actuator.

(2) Outer Diameter (OD): The outer diameter measured in millimeters (mm) of the I-Type eRob. The T-Type eRobs has a larger outer diameter; for more information regarding the size of the eRob, please refer to the [detail drawings](#) of the eRob.

(3) Gear Type: Indicate which type of strain wave gear (SWG) is equipped within eRob.

F	Indicates the eRob is equipped with the Ultra-Flat series SWG. The eRobs with this type of SWG is shorter in length and lighter in weight.
H	Indicates the eRob is equipped with the High-Torque series SWG. The eRobs with this type of SWG have more power, rotational speed, and load capacity.

(4) Gear Ratio (GR): The gear ratio of the eRob is determined by the number of teeth on the flexspline and circular spline of the SWG. For every complete revolution of the output, the input (torque motor) will rotate the gear ratio + 1 number of times.

(5) Form Factors: ZeroErr currently offers eRob series rotary actuators in 2 form factors: the I-type and T-type. These rotary actuators share identical parameters, such as torque, speed, and size, except for one key difference: the module housing. This distinction in module housing provides customers with flexibility in selecting the most suitable actuator type for their specific application, ensuring seamless integration while maintaining consistent performance across both variants.

I-type	The eRob aligns its housing with the its axis, resembling the shape of the letter “I”.
T-type	The eRob features a housing configuration perpendicular to the actuator’s axis, forming a “T” shape.

(6) Brakes: Some of the eRob rotary actuator module incorporates an armature actuated friction brake that offers a seamless and vibration-free stop and start. This mechanism enables the eRob module to initiate movement from a standstill, even under full load conditions. Furthermore, during operation, the mechanism operates silently without any grinding or audible noise during rotation. The robust design of the friction brake allows the eRob module to withstand heavy-load emergency stops while operating at full speed, ensuring reliable performance and safety in critical situations.

F	Indicates the eRob does not have a brake.
B	Indicates the eRob is equipped with a brake.

(7) Integrated Encoders: The output encoder configurations for the eRob joint are as follows:

S	Single-Turn Absolute Value Encoder: This encoder provides the absolute angle value at the output, but it does not record the number of complete rotations when power is lost and then restored. In other words, after a power loss and restart, it reverts to the single-turn value, regardless of the number of turns made during normal powered operation.
M	Multi-Turn Absolute Value Encoder: This encoder provides the absolute angle value at the output, and it record the number of complete rotations when power is lost and then restored. In other words, after a power loss and restart, it remembers the number of turns made during normal powered operation. The multi-turn function needs a multi-turn battery packaged in the accessories kit.
HS	High-Precision Single-Turn Absolute Value Encoder: Similar to the HM version, the HS configuration features a high-precision single-turn absolute value encoder. It also includes calibrated encoders after installation, compensating for assembly errors and elastic deformation errors. The HS version provides high absolute accuracy and is suitable for applications requiring precise positioning.
HM	High-Precision Multi-Turn Absolute Value Encoder: The output encoder in this configuration is a high-precision multi-turn absolute value encoder. It is equipped with calibrated encoders after installation, compensating for assembly errors and elastic deformation errors caused by different loads. This version offers high absolute accuracy and is suitable for applications that demand precise positioning.

Both the HM and HS models offer a resolution capability of 20 bits, with a repeatability/absolute accuracy of $\pm 7/\pm 15$ arcsec*.

The standard model, on the other hand, has a resolution of 19 bits, with a repeatability/absolute accuracy of $\pm 10/\pm 25$ arcsec*.

The standard version is typically sufficient for common industrial robots and automation industry requirements. However, if you have more demanding requirements for absolute positioning accuracy, it is recommended to opt for the HM/HS versions.

*Note: For more details regarding the accuracy, please refer to: zeroerr.com/accuracy

(8) Hollow Bore Diameter: Hollow bore diameter measured in millimeter (mm).

(9) Communication Protocol: There are two primary types of communication protocols available for the eRob: EtherCAT (abbreviated as E) and CANopen (abbreviated as C). These protocols enable seamless communication between the eRob and other devices in a networked system. Additionally, both type of the eRob supports the Modbus protocol when connected with to the RS485 interface.

C	Indicates the eRob module support CANopen communication protocol.
E	Indicates the eRob module support EtherCAT communication protocol.

(10) Torque Sensor: The torque sensor in the “T” models is achieves through the calculation of the angular value difference between the two absolute value encoders integrated in the module. For comprehensive information on the torque sensor feature and its implementation, please refer to [Chapter 22](#). This chapter will provide in-depth details and insights into the workings and benefits of the torque sensing feature in the eRob series rotary actuator modules.

N	Signifies an eRob module without torque sensing capability.
T	Signifies an eRob module with torque sensing capability.

(11) Customization: Customization options.

C	Optional Low-Temperature Grease*.
----------	-----------------------------------

*For more details, please refer to the “eRob High and Low Temperature Reliability Test Report” at zeroerr.com/temperature

2.2 The Specifications of eRob Modules

The Specifications of eRob Series Rotary Actuator Modules are shown in [Table 2-1](#).

Table 2-1 The Specifications of eRob Series Rotary Actuator Modules Part 1

Model	SWG Size & Gear Ratio	Peak Start Stop Torque	Permissible Maximum Torque with Average Load	Rated Torque	Permissible Maximum Momentary Torque	Maximum Output Rotational Speed	Torque Motor Rated Power	Input Voltage	SWG Output Side Inertia
eRob70F	14-50 Ultra-Flat	12	4.8	3.7	23	60	75	48V ± 10%	54030
	14-80 Ultra-Flat	16	7.7	5.4	35	37.5			
	14-100 Ultra-Flat	19	7.7	5.4	35	30			
eRob70H	14-50	23	9	7	46	60	100	48V ± 10%	69717
	14-80	30	14	10	61	37.5			
	14-100	36	14	10	70	30			
	14-120	36	14	10	70	25			
eRob80H	17-50	44	34	21	91	60	146	48V ± 10%	150085
	17-80	56	35	29	113	37.5			
	17-100	70	51	31	143	30			
	17-120	70	51	31	112	25			
eRob80F	17-50	23	18	11	48	60	126	48V ± 10%	107809
	17-100	37	27	16	71	30			
eRob90H	20-50	73	44	33	127	60	300	48V ± 10%	297466
	20-80	96	61	44	165	37.5			
	20-100	107	64	52	191	30			
	20-120	113	64	52	191	25			
eRob110H (Prior Ver.)	25-50	127	72	51	242	60	750	48V ± 10%	715482
	25-80	178	113	82	332	37.5			
	25-100	204	140	87	369	30			
	25-120	217	140	87	395	25			
	25-160	229	140	87	408	18.75			
eRob110H V6 (Latest Ver.)	25-50	127	72	51	242	60	723	48V ± 10%	717286
	25-80	178	113	82	332	37.5			
	25-100	204	140	87	369	30			
	25-120	217	140	87	395	25			
	25-160	229	140	87	408	18.75			
eRob142H	32-50	281	140	99	497	40	1000	48V ± 10%	2589596
	32-80	395	217	153	738	25			
	32-100	433	281	178	841	20			
	32-120	459	281	178	892	16.7			
	32-160	484	281	178	892	12.5			
eRob170H	40-50	402	196	137	686	40	1000	48V ± 10%	6679752
	40-80	519	284	206	980	25			
	40-100	568	372	265	1080	20			
	40-120	617	451	294	1180	16.7			
	40-160	647	451	294	1180	12.5			

Universal Specification

Hollow Bore Diameter: 18mm; IP-Rating: IP54; Brake Type: Armature Actuated

Optional Configuration

Communication Protocol: EtherCAT / CANopen / Modbus;
 Output-Side Encoder Resolution: 19 Bit, Repeatability/Accuracy: ±10/±25 arcsec*;
 Output-Side Encoder Resolution: 20 Bit, Repeatability/Accuracy: ±7/±15 arcsec;
 Optional Low Temperature Grease.

Please note that the specifications provided above are subject to slight variations in different product versions, for product drawings of each model and version; Furthermore, for detailed information regarding accuracy, please consult the following table.

* 1 arcsec = 1/3600 degree = 4.848 μrad

Table 2-2 The Specifications of eRob Series Rotary Actuator Modules Part 2

SWG Output Side Mass	Without Brake				With Brake			
	SWG Input Side Inertia	SWG Input Side Mass	OD × Length	Total Mass	SWG Input Side Inertia	SWG Input Side Mass	OD × Length	Total Mass
kg	$g \cdot mm^2$	kg	mm	kg	$g \cdot mm^2$	kg	mm	kg
0.13	43656	0.15	70 × 60.4	0.77	46885	0.16	70 × 67.7	0.83
0.17	47767	0.18	70 × 75.3	0.87	50996	0.19	70 × 75.3	0.93
0.25	67408	0.26	80 × 84.2	1.19	70637	0.27	80 × 84.2	1.25
0.172	29818	0.129	80 × 57.5	0.89	31399	0.142	80 × 57.5	0.95
0.36	139057	0.41	90 × 98.9	1.75	147025	0.43	90 × 98.9	1.87
0.58	277434	0.7	110 × 115.2	2.88	285402	0.72	110 × 115.2	3.06
0.56	308632	0.53	110 × 80.2	2.57	316600	0.55	110 × 80.2	2.68
1.21	1244894	1.33	142 × 133.9	6.49	1273287	1.37	142 × 133.9	6.7
2.02	1517148	1.66	170 × 144.9	9.29	1545541	1.7	170 × 144.9	9.5

Friction Brake.

For precise and specific specifications, it is recommended to refer to the detailed following link: zeroerr.com/about_us/certificates-patents/test-report.

2.2.1 Output-Side (Load) Specifications

(1) **Permissible Peak Start Stop Torque (as shown in Figure 2-2):**

During startup and stopping, due to the rotational inertia of the load, there may be a load acting on the actuator module that exceeds the normal torque. The values in the eRob specification table represent the permissible value of the peak torque in such situations.

(2) **Permissible Maximum Torque with Average Load:**

When there are variations in the load torque and input rotational speed, it is necessary to calculate the average value of the load torque. The values in the eRob specification table represent the permissible value at the average load torque. If the average load torque exceeds the values specified in the eRob specification table, it can lead to premature degradation of lubricants and abnormal gear wear due to heat generation. Please pay close attention to this.

(3) **Rated Torque:**

This information specifies the maximum continuous load torque that is allowed when the input motor rotational speed is 2000RPM.

(4) **Permissible Maximum Momentary Torque (as shown in Figure 2-2):**

Apart from the usual load torque and the load torque during startup and stopping, there may be unforeseen external impact torques. It is important to note that the maximum value of the impact torque must not exceed the Permissible Maximum Momentary Torque specified in the eRob specification table. This is crucial to ensure the proper functioning and longevity of the eRob module. Exceeding the permissible limits can result in mechanical stress, potential damage to the module, and compromised performance. Therefore, it is essential to carefully consider and account for these factors to maintain optimal operation and prevent any undesirable consequences.

(5) **Maximum Output Rotational Speed:**

The Maximum Output Rotational Speed is the maximum speed the SWG can output on the load bearing end, the motor rotational speed at this moment is at its rated rotational speed, as shown in Section 25.2.2. The relation between the output torque and the output rotational speed is shown in Section 25.4




Figure 2-2 Example of Load Pattern

2.2.2 Input-Side (Motor) Specifications

(1) **Torque Motor Rated Power:**

The rated power and power consumption of the torque motor in the eRob rotary actuator, for complete electrical specifications, refer to Table 25-1.

(2) **Input-Side SWG Inertia**

(3) **Input-Side SWG Mass**

The specification mentioned above are only applicable to the latest version, and there may be slight differences in different product versions. For more details, as well as 2D drawings and 3D models, for further information and downloads, please visit the official website: www.zeroerr.com

2.2.3 Difference Between Single-Turn and Multi-Turn Encoders

(1) **Multi-Turn Encoder**

For multi-turn encoders (with multi-turn memory function), they require the installation

of a battery and can retain multi-turn information even when power is disconnected.

(2) **Single-Turn Encoder**

On the other hand, single-turn encoders (without multi-turn memory function) do not have this capability.

To determine whether a module is single-turn or multi-turn, you can check if the "Multi-Turn" option in the "Encoder" interface is checked in the "eTuner" software. There are differences in both the hardware and software aspects between Single-Turn and Multi-Turn modules.

2.2.4 Communication Protocol Supported

(1) **CANopen** (Model eRobxxxxxxxx-xx-18Cx) Supports:

- CANopen
- CAN-custom
- Modbus (RTU/ASCII)

(2) **EtherCAT** (Model eRobxxxxxxxx-xx-18Ex) Supports:

- EtherCAT
- CAN-custom
- Modbus (RTU/ASCII)

CAN-custom and Modbus-ASCII are proprietary communication protocols developed by our company. The communication protocol used between our PC debugging software "eTuner" (connection method please refer to [YouTube Tutorial](#)) and the rotary actuator is CAN-custom. On the other hand, EtherCAT and CANopen follow the standard CiA402 control protocol, but they differ in terms of their communication physical layer interfaces.

Chapter 3 Power Input of eRob

3.1 Power Supply Voltage and Rated Current Value

When the power supply is powered with **48V DC** (the factory default settings), the permissible bus voltage range is as follows:

- **Minimum bus voltage:** 44V
- **Maximum bus voltage:** 55V

If the detected voltage exceeds **55V**, the drive will trigger an **over-voltage error**. Conversely, if the detected voltage drops below **44V**, an **under-voltage error** will be triggered. The rated current of an rotary actuator is shown in [Table 3-1](#).

Table 3-1 Rated Current of Each Rotary Actuator Model

Model	Voltage (V)	Current (A)
eRob70F	48±10%	1.91
eRob70H	48±10%	2.55
eRob80F	48±10%	3.5
eRob80H	48±10%	4.1
eRob90H	48±10%	6.7
eRob110H	48±10%	18.6
eRob142H	48±10%	26
eRob170H	48±10%	45

3.2 Permissible Maximum Input Voltage

The permissible maximum voltage of the eRob power interface is **60V DC**. If the input voltage exceeds **60V**, it may lead to drive failure. The input voltage waveform when the eRob is supplied power abnormally is shown in [Figure 3-2a](#).

Note: When powering on the eRob with a switching power supply or battery (by connecting the power output side to a circuit breaker and then to the eRob power interface), there may be an **over-voltage shock** (>60V) when turning on the switch. To prevent this, an capacitor (reference specification: **1000uF, 100V**) should be connected in parallel behind the circuit breaker before powering on the rotary actuator. This will help avoid the overshoot of input voltage at the moment of powering on. The wiring configuration is shown in [Figure 3-1](#). The input voltage waveform when the eRob is supplied power normally after connecting an capacitor is shown in [Figure 3-2b](#).





Figure 3-1 Wiring Diagram of Electrolytic Capacitor in Parallel with Power Supply



(a) Abnormal Power Input Voltage Waveform
($V_{max} = 130V > 60V$)

(b) Normal Power Input Voltage Waveform
($V_{max} = 48.8V < 60V$)

Figure 3-2 Power Input Related Diagrams


When powering on with a battery (e.g., lithium battery or other storage battery), the back electromotive force (back EMF) has no influence on the eRob system. This is because the back EMF generated during the regenerative braking process directly charges the battery. Therefore, no specific actions are required for back EMF. However, it is necessary to modify the permissible maximum and minimum voltage settings in the “Safe Power” section of eTuner.

When the battery voltage exceeds 48V (e.g., when using a 52V DC battery), the permissible bus voltage must be adjusted:

- (1) Set the permissible **maximum bus voltage** to 57.2V (calculated as $52V \times 110\%$). The percentage can be modified based on actual requirements;
 - **NOTE:** It is not recommended to set the maximum bus voltage above 60V.
- (2) Set the permissible **minimum bus voltage** to 46.8V (calculated as $52V \times 90\%$). Similarly, the percentage can be adjusted as needed.

After making these adjustments, apply and save the parameters. The configuration process is illustrated in Figure 3-3a.

Error Debugging: If the detected voltage exceeds the permissible maximum bus voltage of 57.2V, the eRob system will not be enabled. Instead, an error report will be generated, stating: “The bus voltage is overvoltage”, and the system will shut down. For example, in Figure 3-3b, the detected voltage is 58.558V, which triggers the error.



(a) Example of Using DC52V Power Supply (b) "The bus voltage is overvoltage" Error Message
 Figure 3-3 eTuner Over-Voltage Error Example

3.3 Permissible Minimum Input Voltage

The permissible minimum input voltage of eRob rotary actuator with brakes is shown in Table 3-2.

The permissible minimum input voltage of the eRob without brakes is 19.5V.

When the input voltage is lower than the permissible minimum input voltage, the eRob will fail to operate normally.

The correlation between the actual maximum rotational speed of the eRob and the input voltage is shown below:

$$n_a = n_r \times \frac{V_{in}}{48V} \tag{3.1}$$

Table 3-2 The Permissible Input Voltage of Rotary Actuators with Brakes

Model	Voltage (V)
eRob70F	24
eRob70H	24
eRob80F	24
eRob80H	24
eRob90H	48
eRob110H	48
eRob142H	48
eRob170H	48

Symbol	Definition	Unit
n_a	The actual maximum rotational speed output by the rotary actuator.	RPM
n_r	The rated maximum output rotational speed, as shown in Table 2-1.	RPM*
V_{in}	The actual voltage supplied to the rotary actuator module.	V

* To convert the rotational speed to angular velocity, please refer to Chapter 12.1.

When the input voltage is lower than the rated voltage, the actual maximum rotational speed will be reduced. However, the torque performance will remain unaffected.

$$V_{in} \leq V_r \Rightarrow \begin{cases} n_a \leq n_r \\ T_a = T_r \end{cases}$$

Symbol	Definition	Unit
V_{in}	The actual voltage supplied to the rotary actuator module.	V
V_r	The rated input voltage of the eRob module, as shown in Table 2-1 .	V
n_a	The actual maximum rotational speed output by the rotary actuator.	RPM
n_r	The rated maximum output rotational speed, as shown in Table 2-1 .	RPM
T_a	The actual torque output by the rotary actuator module.	Nm
T_r	The rated torque output by the rotary actuator module, as shown in Table 2-1 .	Nm


Since the factory default permissible minimum bus voltage is **44V**, using a voltage below **44V** requires manually modifying the permissible minimum bus voltage. This can be configured in the “*Safe Power*” interface of [eTuner](#).

Example: When powering the system with **24V DC**, the permissible bus voltage settings should be adjusted as follows:

- Modify the permissible **minimum bus voltage** to **21.6V** (calculated as $24V \times 90\%$; the percentage can be adjusted according to the actual situation).
- Modify the permissible **maximum bus voltage** to **26.4V** (calculated as $24V \times 110\%$; the percentage can be adjusted according to the actual situation).

After making these adjustments, apply and save the parameters. The configuration process is illustrated in [Figure 3-4a](#).

Error Handling: If the detected voltage falls below the permissible minimum bus voltage of **21.6V**, the eRob rotary actuator cannot be enabled. An error report will be generated stating: “*The bus voltage is undervoltage.*” The system will then shut down. For instance, in [Figure 3-4b](#), the detected voltage is **20.611V**, triggering this error.



(a) Example of Using DC24V Power Supply

(b) "The bus voltage is undervoltage" Error Example

Figure 3-4 eTuner undervoltage example

Chapter 4 Rotary Actuator Positive Rotation Direction

Facing the output shaft of the strain wave gear (SWG), the **positive rotation direction** of the eRob rotary actuator is as shown in [Figure 4-1](#). The positive rotation direction is the **counter-clockwise (CCW)** rotation direction.

Note: The rotation direction of the eRob rotary actuator **cannot be modified**. However, the eRob's rotation direction is determined by the direction of the target command, which can be adjusted by the controller.



Figure 4-1 Positive Rotation Direction of Rotary Actuator

Chapter 5 Electrical Interface and Status Indicator LED

5.1 Indicator LED Function

(1) **Run LED**

System Operation Indication.

LED Status	Green light flashes.
LED Status Figure	

(2) **Power LED**

Bus power connection indication.

LED Status	Green light is always on.
LED Status Figure	

(3) **ECAT In LED**

EtherCAT In is used to connect the ECAT Out port of previous eRob slave or master controller.

ECAT Communication Connection Status	LED Status	LED Status Figure
Communication cable is not connected and the EtherCAT (COE) controller does not start.	Light is off	
Communication cable is connected, but data communication is not performed.	Green light is always on.	
Data communication is in progress.	Green light flashes quickly.	







Figure 5-1 eRob Module LED Illustration






(4) ECAT Out LED

EtherCAT Out is used to connect the ECAT In port of slave of the next eRob.

ECAT Communication Connection Status	LED Status	LED Status Figure
Communication cable is not connected and the EtherCAT (COE) controller does not start.	Light is off	
Communication cable is connected, but data communication is not performed.	Green light is always on.	
Data communication is in progress.	Green light flashes quickly.	

(5) ECAT sta LED

Indicates the state of the EtherCAT status machine.

ECAT Communication Connection Status	LED Status	LED Status Figure
INIT status	Light is off	
PREOP status	Blue light flash	
SAFEOP status	Blue light flashes once, and $Time_{off} > Time_{on}$	
OP status	Blue light is always on	
OP status	Blue light flashes quickly.	



Note: Please refer to Section 4.3 in *eRob CANopen and EtherCAT User Manual* for the details about the EtherCAT status machine.

5.2 CAN Communication Interface

Pin	Terminal Label	Terminal Function
1	CAN_H	CAN Network Signal
2	CAN_L	
3	CAN_GND	CAN Network Ground

Pin Layout	Connector
<p>The diagram shows the top surface of the actuator with various terminals. A red box highlights the CAN(A), CAN(B), and Run terminals. A red arrow points to a detailed view of these terminals. The detailed view shows three pins: CAN_H (red), CAN_L (blue), and CAN_GND (yellow).</p>	<p>A white plastic JST connector housing with three pins labeled CAN_H, CAN_L, and CAN_GND.</p>
Header Information	Connector Information
<p>Model: BM03B-GHS-TBT</p>	<p>Manufacturer: JST Housing Model: GHR-03V-S Contact Model: SSSL-002T-P0.2</p>
<p>Specification: JST Top Entry Single Row 3Pin 1.25mm Pitch Disconnectable Crimp Style Connector</p>	

5.3 EtherCAT Communication Interface

Pin	ECAT In		ECAT Out	
	Terminal Label	Terminal Function	Terminal Label	Terminal Function
1	ECAT In_TX+	EtherCAT Input Signal Transmission+	ECAT Out_TX+	EtherCAT Output Signal Transmission+
2	ECAT In_TX-	EtherCAT Input Signal Transmission-	ECAT Out_TX-	EtherCAT Output Signal Transmission-
3	ECAT In_RX+	EtherCAT Input Signal Reception+	ECAT Out_RX+	EtherCAT Output Signal Reception+
4	ECAT In_RX-	EtherCAT Input Signal Reception-	ECAT Out_RX-	EtherCAT Output Signal Reception-
Pin Layout			Connector	
				
Header Information			Connector Information	
Model: BM04B-GHS-TBT Specification: JST Single Row 4Pin 1.25mm Pitch Disconnectable Crimp Style Connector			Manufacturer: JST Housing Model: GHR-04V-S Contact Model: SSSL-002T-P0.2	

Note: CANopen version rotary actuators (model: eRobxxxxxxxx-xx-18Cx) do not have this interface.



5.4 Multi-Turn Power Supply Battery Interface

Pin	Terminal Label	Terminal Function
1	VB+	Battery Positive
2	VB-	Battery Negative

Pin Layout	Connector
Header Information	Connector Information
<p>Model: BM02B-GHS-TBT</p> <p>Specification: JST Single Row 2Pin 1.25mm Pitch Disconnectable Crimp Style Connector</p>	<p>Manufacturer: JST</p> <p>Housing Model: GHR-02V-S</p> <p>Contact Model: SSSL-002T-P0.2</p>

Note: Single-turn rotary actuators (model: eRobxxxxxxxx-xS-18xx) do not have this interface. More details for multi-turn battery instruction, please refer to [Chapter 11](#).

5.5 48V Power Supply Interface

Pin	Terminal Label	Terminal Function
1	DC+	Power Supply Positive
2	DC-	Power Supply Negative
Pin Layout		Connector
		 <p>Left-Angled XT30ULW-F A</p> <p>Right-Angled XT30ULW-F B</p>
Header Information		Connector Information
Model: XT30UPB-M		Manufacturer: AMASS Model: XT30U-F
Specification: AMASS Top Entry 2Pin 5mm Pitch Straight Pin Connector With 2mm Pin Length		

5.6 I/O Signal Terminal

Pin	Terminal Label	Terminal Function
1	RS485-A	RS485 COM Interface DATA+
2	RS485-B	RS485 COM Interface DATA-
3	IN1- / Pulse- /STOA-	Digital Input DIn1 / Pulse Command Signal / STOA
4	IN1+ / Pulse+ /STOA+	
5	IN2- /Dir- /STOB-	Digital Input DIn2 / Pulse Command Direction / STOB
6	IN2+ /Dir+ /STOB+	
7	OUT_COM	Programmable output signal ground
8	OUT_1	Programmable digital output 1
9	OUT_2	Programmable digital output 2
10	GND	Signal ground
11	ANALOG1+	Analog signal input + (input range -10V ~+10V)
12	ANALOG1-	Analog signal input- (input range -10V ~+10V)
Pin Layout		Connector
Header Information		Connector Information
<p>Model: BM12B-GHS-TBT</p>		<p>Manufacturer: JST Housing Model: GHR-12V-S Contact Model: SSSL-002T-P0.2</p>
<p>Specification: JST Top Entry Single Row 12Pin 1.25mm Pitch Disconnectable Crimp Style Connector</p>		

5.7 ESD Standard Specifications

To assist users with system-level electrical design, interface protection design, and component selection evaluation, the ESD standards for eRob rotary actuators and their respective interfaces are detailed in Table 5-1.



The system-level ESD immunity assessment is conducted strictly in accordance with the IEC 61000-4-2 standard. This manual provides the electrostatic discharge (ESD) tolerance levels of the TVS chips and communication chips used in the communication interfaces. This data is intended to clarify critical component selection and design baselines; it is derived from the respective chip datasheets and does not directly equate to the ESD immunity performance of the final integrated system.

Performance Criterion A Requirements: During and after the application of interference, the equipment must maintain normal operation. The following conditions are strictly prohibited: system crashes or hangs, abnormal resets, control logic failure, communication link interruptions, any performance degradation that cannot be automatically recovered.

Table 5-2 eRob ESD Standard Specifications

Component	Parameter	Condition / Standard	ESD Standard
eRob rotary actuator	/	IEC 61000-4-2	Contact Discharge: ±4kV Criterion: A Air Discharge: ±8kV Criterion: A
DC Power Interface	TVS	IEC 61000-4-2	Contact Discharge: >15kV Air Discharge: >8kV
		MIL-STD-883	HBM: >4kV
	DC-DC Chip	ANSI/ESDA/JEDEC JS-001	HBM: ±2kV
CAN Interface	TVS	IEC 61000-4-2	Contact Discharge: ±30kV Air Discharge: ±30kV
	CAN Chip	ANSI/ESDA/JEDEC JS-001	HBM: ±16kV
RS485 Interface	TVS	IEC 61000-4-2	30kV
	RS485 Chip	TIA / EIA-485	HBM: ±15kV

5.8 Cable Specification Explanation

Table 5-3 eRob Rotary Actuator Module Wire Specification

Model	COM Port	Wire Count × Port Count	Wire Recommendation		Wire Connection Reserve Height (mm)
			Cross-Section Area (mm ²)	AWG#	
Universal Specification	CAN COM Port: CAN(A) & CAN(B)	3P×2	0.05~0.13	30~26	10
	EtherCAT COM Port: ECAT In & ECAT Out	4P×2	0.05~0.13	30~26	10
	I/O Port	12P×1	0.05~0.13	30~26	10
	Multi-Turn Func. Battery Port: BAT	2P×1	0.05~0.13	30~26	10
eRob70	48V Power Input Port: DC In	2P×2	0.5	20	15
eRob80		2P×2	0.75	19	15
eRob90		2P×2	1	18	15
eRob110		2P×2	1.25	17	15
eRob142		2P×2	1.5	16	15
eRob170		2P×2	1.5	16	15

5.9 Force Instruction of Connector

The permissible tensile force of connection between JST terminal and wire is shown in [Table 5-4](#), and the tensile test is shown in [Figure 5-2a](#).


Table 5-4 Permissible Tensile Force of Connection Between JST Terminal and Wire

AWG	Standard Value (N)	Actual Value (N)
AWG #26	≥ 20	33 ~ 39
AWG #28	≥ 10	21 ~ 26
AWG #30	≥ 5	14 ~ 18


The permissible tensile force of the male/female head buckles of JST connector are shown in [Table 5-5](#), and the tension testing is shown in [Figure 5-2b](#). Do not unplug the wiring terminal directly from the interface. Loose the buckle first, and then pull it out gently. Pulling out terminal directly may cause the buckle breakage and unstable connection.

Table 5-5 Permissible Tensile Force of Male/Female Connector Connecting to Buckle

Pin Number	2 ~ 3	4 ~ 6	7 ~ 9	10 ~ 15
Min. Value (N)	10	12	15	20




(a) Tension Testing of Connection Between JST Terminal and Wires



(b) Tension Testing of the Male/Female Head Buckles of Connector

Figure 5-2 Tension Testing Illustrations

The bases of four type of connectors are all GHS-TBT type, and the sizes of the four solder discs are the same. Therefore, the permissible thrust force of A-direction is no more than 3N, and the permissible thrust force of B-direction is no more than 4.2N. as shown in Figure 5-3a and Figure 5-3b




(a) A-Direction Force GHS-TBT Connector Housing (b) B-Direction Force GHS-TBT Connector Housing

Figure 5-3 Direction of Force Applied on GHS-TBT Connector Housing

5.10 Force Instruction of Power Terminal

- (1) When pulling in or pulling out the power plug, please plug and unplug the power terminal female head in vertical direction, as shown in Figure 5-4a. The tensile force limit of power terminal male head in vertical direction is about 170N, and in horizontal direction is about 0.4Nm. Do not shake the power terminals from side to side at any time. As shown in Figure 5-4b, shaking from side to side may cause the power terminals to fall off easily.
- (2) To avoid the power terminals fall off or the power terminal is in poor connection caused by vibration, pulling or other factors during operation, it is necessary to install plug retainers after connecting the power terminals. The installation steps are:
 - (1) Weld the power cable to the power terminal female head;
 - (2) Insert the power terminal female head, as shown in Figure 5-4c;
 - (3) Install the plug retainer and lock it firmly, as shown in Figure 5-4d.



(a) Plug and Unplug in Vertical Direction (b) Do Not Shake Power Terminal from Side-to-Side (c) Plug Female Power Terminal (d) Plug Retainer Installation

Figure 5-4 Direction of Force Applied on GHS-TBT Connector Base

NOTE: (1) Screw Size & Retainer

The locking screws of plug retainers are M1.6×4. The plug retainers can be purchased via our [official website](http://www.zeroerr.com).

(2) Warranty

The warranty of eRob does not apply if the eRob installed without plug retainers subjected to vibration, pulling or other factors causing the power terminals fall off or power terminals is in poor connection to ignition and further causing eRob occurs irreversible damage.

Chapter 6 Cable Wiring Among Rotary Actuators

Cable wiring among rotary actuators is as shown in [Figure 6-2](#). EtherCAT networking adopts direct wiring mode. Connect the RJ45 network port of the master controller to ECAT In port of the first eRob (Slave1), and connect the ECAT Out port of the first eRob (Slave1) to the ECAT In port of the next eRob and so on. The corresponding eRob network port pin sequence of the RJ45 network port is as shown in [Figure 6-1](#). Connect CAN networking cables according to port definitions, and the CAN port of the two adjacent eROBs can be connected in random order. Refer to [Section 6.1](#) for the wiring method of the power supply; refer to [Section 6.2](#) for the CAN/CANopen communication wiring, and refer to [Section 6.3](#) for the EtherCAT communication wiring.




Figure 6-1 EtherCAT Networking Connection Mode




Figure 6-2 Cable Wiring Among Rotary Actuators Illustration

6.1 Power Supply Wiring Illustration

There are three power wiring methods for the eRob modules: direct wiring for single eRob, tree topology wiring, and chain topology wiring (as shown in [Figure 6-3a](#), [Figure 6-3b](#) and [Figure 6-3c](#)). Under the condition of applying multiple eROBs which are powered by 48V, according to the actual test results of the pressure drop of each eRob, the recommended order of adopting the three wiring modes is:

- (1) **Direct Wiring Mode (as shown in [Figure 6-3a](#))**

the best mode, minimum wiring resistance, minimum pressure drop of wire consumption, suitable for high-power eRob;

(2) **Tree Topology Wiring Mode (as shown in Figure 6-3b)**
the better mode;


(3) **Chain Topology Wiring Mode (as shown in Figure 6-3c)**

the good mode, larger wiring resistance, larger pressure drop of wire consumption, suitable for low-power eRob .


CAUTION:

Please use direct wiring for single eRob method when using eRob90/110/142/170. Otherwise, it is easily to appear error reports of the too low bus voltage and too high bus voltage during running.


Do not connect other electrical devices in series. Other electrical devices may cause unpredictable voltage drop or voltage rise and cause a failure.



(a) Point-to-Point Topology



(b) Tree Topology



(c) Daisy Chain Topology

Figure 6-3 Wiring Topologies of eRobs

6.1.1 Examples of Collaborative Robot Power Wiring

3 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-4):

Note: Due to the adoption of a chain topology connection, it is recommended to use specific power cable specifications for each axis to ensure optimal performance and reliable power transmission.

(1) DC48V → J1 axis

For the connection between the DC48V power supply output and the J1 axis, it is highly recommended to use power cables with a minimum cross-sectional area of $\geq 1\text{mm}^2$ (18AWG). This ensures sufficient power delivery and minimizes power losses.

(2) J1 → J3 axis

Similarly, for the connection between J1 and J3 axes, it is advised to use power cables with a minimum cross-sectional area of $\geq 1\text{mm}^2$ (18AWG) to maintain efficient power transfer and prevent voltage drops.

(3) J3 → J5 axis

When connecting J3 to J5 axes, it is recommended to use power cables with a minimum cross-sectional area of $\geq 0.75\text{mm}^2$ (19AWG) to meet the power requirements and ensure stable power transmission.

(4) J5 → J6 axis

Lastly, for the connection between J5 and J6 axes, it is recommended to use power cables with a minimum cross-sectional area of $\geq 0.5\text{mm}^2$ (20AWG) to ensure reliable power transmission.

By following these cable specifications, you can ensure proper power distribution and minimize potential issues related to power supply, thereby optimizing the overall performance of the system.




Figure 6-4 3kg payload collaborative robot power wiring diagram example

5 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-5):

Note: Due to the adoption of a chain topology connection, it is recommended to use specific power cable specifications for each axis to ensure optimal performance and reliable power transmission.

(1) DC48V → J1 axis

For the connection between the DC48V power supply output and the J1 axis, it is highly recommended to use power cables with a minimum cross-sectional area of $\geq 1.5\text{mm}^2$ (16AWG). This ensures sufficient power delivery and minimizes power losses.

(2) J1 → J3 axis

Similarly, for the connection between J1 and J3 axes, it is advised to use power cables with a minimum cross-sectional area of $\geq 1.5\text{mm}^2$ (16AWG) to maintain efficient power transfer and prevent voltage drops.

(3) J3 → J5 axis

When connecting J3 to J5 axes, it is recommended to use power cables with a minimum cross-sectional area of $\geq 0.75\text{mm}^2$ (19AWG) to meet the power requirements and ensure stable power transmission.

(4) J5 → J6 axis

Lastly, for the connection between J5 and J6 axes, it is recommended to use power cables with a minimum cross-sectional area of $\geq 0.5\text{mm}^2$ (20AWG) to ensure reliable power transmission.

By following these cable specifications, you can ensure proper power distribution and minimize potential issues related to power supply, thereby optimizing the overall performance of the system.




Figure 6-5 5kg payload collaborative robot power wiring diagram example

10 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-6):

Note: Due to the adoption of both single-axis direct connection and chain topology connection, it is recommended to use specific power cable specifications for each axis to ensure optimal performance and reliable power transmission.

(1) DC48V → J1 & J2 & J3 axis

For the connection between the DC48V power supply output and the axes J1, J2, and J3, it is recommended to use power cables with a minimum cross-sectional area of $\geq 1.5\text{mm}^2$ (16AWG). This ensures sufficient power delivery and minimizes power losses.

(2) J3 → J5 axis

When connecting J3 to J5 axes, it is advised to use power cables with a minimum cross-sectional area of $\geq 1\text{mm}^2$ (18AWG) to maintain efficient power transfer and prevent voltage drops.

(3) J5 → J6 axis

Similarly, for the connection between J5 and J6 axes, it is recommended to use power cables with a minimum cross-sectional area of $\geq 0.75\text{mm}^2$ (19AWG) to ensure reliable power transmission.

If the DC48V power supply output is connected to the axes J1, J2, and J3 using branch terminals (such as a two-in, six-out configuration), then for the connection between the DC48V power supply output and the terminal input, it is recommended to use power cables with a minimum cross-sectional area of $\geq 3\text{mm}^2$ (12AWG).

By following these cable specifications, you can ensure proper power distribution and minimize potential issues related to power supply, thereby optimizing the overall performance of the system.




Figure 6-6 10kg payload collaborative robot power wiring diagram example

20 kg Payload Collaborative Robot Arm Example(as shown in Figure 6-7):

Note: Due to the adoption of both single-axis direct connection and chain topology connection, it is recommended to use specific power cable specifications for each axis to ensure optimal performance and reliable power transmission.

(1) DC48V → J1 & J2 & J3 axis

For the connection between the DC48V power supply output and the axes J1, J2, and J3, it is recommended to use power cables with a minimum cross-sectional area of $\geq 1.5\text{mm}^2$ (16AWG). This ensures sufficient power delivery and minimizes power losses.

(2) DC48V → J4 axis & J4 → J5 axis

When connecting J3 to J5 axes, it is advised to use power cables with a minimum cross-sectional area of $\geq 1.25\text{mm}^2$ (17 AWG) to maintain efficient power transfer and prevent voltage drops.

(3) J5 → J6 axis

Similarly, for the connection between J5 and J6 axes, it is recommended to use power cables with a minimum cross-sectional area of $\geq 1\text{mm}^2$ (18 AWG) to ensure reliable power transmission.

If the DC48V power supply output is connected to the axes J1, J2, J3 and J4 using branch terminals (such as a two-in, six-out configuration), then for the connection between the DC48V power supply output and the terminal input, it is recommended to use power cables with a minimum cross-sectional area of $\geq 6\text{mm}^2$ (9 AWG).

By following these cable specifications, you can ensure proper power distribution and minimize potential issues related to power supply, thereby optimizing the overall performance of the system.





Figure 6-7 20kg payload collaborative robot power wiring diagram example

6.2 CAN/CANopen Communication Wiring Diagram (as shown in Figure 6-8)




NOTES:

- (1) CAN communication lines use twisted pair cables with individual shielding. For eRob modules, a fixed baud rate of 1 Mbps is used. The maximum communication distance between the two farthest nodes on the CAN bus can reach 25m.
- (2) As shown in Figure 6-8, a 120Ω termination resistor should be connected in parallel to both the controller-end and end servo (eRob Drive n) CAN interfaces.
- (3) Before establishing CAN communication, ensure that each module is assigned a unique CAN ID (refer to Section 26.1.2).
- (4) The CAN interface circuit can tolerate a maximum voltage of DC 24V.
- (5) The module CAN bus and power supply share a common ground within the module and are non-isolated. If you require electrical isolation, please add isolation for the CAN network in your circuit.

Figure 6-8 CAN/CANopen communication wiring diagram

6.3 EtherCAT Communication Wiring Diagram (as shown in Figure 6-9)



NOTES:

- (1) EtherCAT communication lines use twisted pair cables with individual shielding.
- (2) Even if you choose a module with EtherCAT communication, it is still recommended to connect and retain the module CAN communication lines in the overall system. It is also advised to set the module CAN ID in advance (refer to [Section 6.2](#)). This enables convenient debugging of individual module in the entire system (without disassembling the casing) during subsequent debugging processes, including troubleshooting, parameter modification, firmware upgrades, etc.
- (3) If the ECAT_In and ECAT_Out connections are inadvertently reversed, the eRob modules will still establish a connection and remain controllable. However, it is crucial to note that the sequence in which the eRob modules appear in the master controller will not align with the intended configuration.

Figure 6-9 EtherCAT communication wiring diagram

6.4 Modbus-RTU Communication Wiring Diagram(as shown in Figure 6-10)

The Modbus-RTU communication interface is the RS485 communication interface of the I/O terminal of the eRob rotary actuator. The MODBUS master system and the MODBUS slave system can create a multi-point connection bus network. The wiring diagram is shown in Figure 6-10. For details on the use of the Modbus-RTU communication protocol, please refer to the [eRob Modbus-RTU User Manual](#).

Notes:

- (1) The Modbus-RTU communication lines use twisted pair cables with individual shielding.




Figure 6-10 Modbus-RTU communication wiring diagram

6.5 I/O Signal Terminal Wiring Diagram

(1) Universal digital input DI terminal (as shown in [Figure 6-11](#)):




Figure 6-11 Universal digital input DI terminal wiring diagram

(2) Safe Torque Off (STO) function terminal (as shown in [Figure 6-12](#)):




Figure 6-12 Safe torque off (STO) terminal wiring diagram

(3) Pulse direction control terminal

(1) 5V difference mode (as shown in Figure 6-13):




Figure 6-13 5V difference pulse command input terminal wiring diagram

(2) Open collector mode (as shown in Figure 6-14):




Figure 6-14 Open collector pulse command input terminal wiring diagram

(4) Digital output DO terminal (as shown in Figure 6-15):

The permissible maximum voltage and current capacity of the built-in opto-isolator:

- Voltage: DC30V (Max.)
- Current: DC50mA (Max.)




Figure 6-15 Digital output DO terminal wiring diagram

6.6 Important Wiring Instructions

6.6.1 Precautions for Wiring Through Module Central Hole

The rotary actuator is equipped with an extra-large hollow hole with a diameter of 18mm. When wiring the robot, power cables, communication cables, air pipes, and other components can easily pass through the central hole of the module to connect to the next module or devices such as the end gripper of the robotic arm. This enables a convenient and neat internal wiring method for the robot.

Even so, the following points still need attention: If too many cables are routed through the module central hole and the cables are tight (which will increase the resistance of module rotation), and there are protruding objects (such as cable ties) tied to the cables that enter the central hole, external squeezing force will be applied to the central hole. This will cause the end of the output shaft flange to deviate, leading to the deviation of the output encoder code disc installed at the end of the output shaft flange and thus the deviation of the position reading of the output encoder. In addition, if the user passes additional structural parts through the module central hole, it may also exert external squeezing force on the central hole, resulting in such abnormalities. Therefore, do not route too many cables through the module central hole; the cables should be reserved with sufficient length to avoid being tight. Do not pass additional structural parts through the module central hole, and do not apply excessive pressure to the inner wall of the module central hole. In addition, during installation, wiring, and other processes, ensure that no metal chips fall into the electrical interfaces of the module rear cover, through holes, or the gaps of the module central hole (where the output encoder code disc is installed). Otherwise, it

may lead to poor communication or even electrical failures. For more instructions, please refer to the "Beware of the risk of metal debris entering connector gaps:" in the "Safety Guide" section of this manual.

6.6.2 Instructions for Cable and Battery Fixing Methods


To prevent poor contact of terminals (which may cause unstable power supply, poor communication, and other faults) or even terminal loosening and damage due to vibration of the module during operation, pulling and shaking of cables during movement, it is necessary to fix the cables and multi-turn power supply battery. Regarding the cable routing method, the fixing methods for cables and batteries can be referred to as follows:

Step 1 Cable Routing

When passing cables through the module central hole, large-size cables should usually be threaded first, followed by small-size cables, to ensure all cables can pass through smoothly in sequence.

Step 2 Installing Cable Bracket

Four M3 screw holes are reserved on the module rear cover (as shown in the red circles in [Figure 6-16a](#)). Two of them can be used to install a cable bracket. To further enhance the physical protection of cables and the multi-turn power supply battery and avoid wear, it is recommended to sleeve the cable bracket with heat shrink tubing before installation, as shown in [Figure 6-16b](#).



(a) Installing Cable Bracket

(b) Cable Bracket with Heat Shrink Tubing

Figure 6-16 Cable Bracket


- NOTE:**
- (1) Do not disassemble the original screws on the rotary actuator without authorization, as this will affect the original performance of the module and its warranty.
 - (2) The thread depth of the reserved M3 screw holes on the module rear cover varies slightly among different model versions. For specific details, please visit the [ZeroErr official website](#) to download relevant 2D drawings and 3D models.
 - (3) Cable brackets can be purchased through the "Product Accessories" page on our official website. For relevant dimensions, please visit the ZeroErr official website ([ZeroErr](#)

[Download](#)) to download relevant 3D models.

- (4) When selecting the length of the locking screws for the cable bracket, comprehensively consider the thread depth of the reserved M3 screw holes on the module rear cover and the thickness of the cable bracket. For the recommended screw tightening torque, refer to [Section 18.3](#) in this manual.

Step 3 Cable and Battery Fixing

After connecting all cables to the corresponding electrical interfaces, use nylon cable ties to bundle and fix all cables on the cable bracket. Then fix the multi-turn power supply battery on the cable bracket in the same way, as shown in [Figure 6-17a](#).



(a) Cable and Battery Fixing

(b) Example of Module Housing Grounding

Figure 6-17 Wiring Topologies of eRobs

Note: When using cable ties to bundle and fix cables and the battery, do not over-tighten. It is sufficient to fasten them slightly without loosening. Excessive force may damage the cables (especially the battery connector cables) and the battery, while insufficient force may cause loosening and fail to achieve the fixing effect.

6.6.3 Module Housing Grounding

The module housing needs to be grounded (PE). The housing ground wire can be installed and connected through the reserved M3 screw holes on the module rear cover, as shown in the red circles in [Figure 6-17b](#).

Chapter 7 Brake Instruction

7.1 Instruction and Caution

- (1) The integrated brake does not require separate power. Simply connect power to the eRob's DC power interface, and the brake will be powered. Please refer to [Chapter 3](#) for the eRob power supply voltage details.
- (2) The integrated brake can be used as a static holding brake.
- (3) The integrated brake can withstand dynamic brake impact under low load conditions (<10% max torque) and low rotational speed (<10% max speed). However, frequent dynamic braking should be avoided.
- (4) If a fault, error, or emergency stop occurs under high speed and heavy load, the brake may engage and irreversibly damage the eRob. Therefore, avoid these conditions during development and tuning.
- (5) Exposure to strong magnetic environments may impair brake functionality. Avoid operating in these conditions, or implement magnetic shielding for the eRob when necessary.
- (6) In emergencies, if power is unavailable, manually rotate the eRob by applying external force exceeding its static friction torque. The static friction torque values for each model are detailed in [Table 7-1](#).
- (7) When powered, enabling the eRob releases the brake, while disabling it engages the brake. The brake activation time is approximately 150ms. The recommended minimum control interval between enabling and disabling is 300ms. After enabling, wait at least 500ms before issuing motion commands. Please refer to [Section 5.1](#) of the [eRob CANopen and EtherCAT User Manual](#) for more detail.

Warning: Rotating rotary actuators by external force can be only used in emergency and it may damage the rotary actuators. If the static friction torque at the module's output exceeds the strain wave gear's instantaneous maximum allowable torque, forced dragging may cause damage to the gear prior to the brake. For details regarding strain wave gear life, please refer to [Chapter 23](#).

Table 7-1 Static Friction Torque of the Integrated Brake at SWG Output (Nm)

Model Gear Ratio	eRob70F	eRob70	eRob80	eRob80F	eRob90	eRob110	eRob142	eRob170
50	30	30	62	44	90	127	281	402
80	40	40	75	-	118	195	395	519
100	50	50	89	61	132	206	433	620
120	-	50	89	-	132	246	497	775
160	-	-	-	-	-	246	497	840

Note: The static friction torque values of the module output ends, listed in Table 7-1, represent the standard qualified values based on factory tests of static brake torque (measured with the power off and module disabled). When the load torque applied to the module output shaft does not exceed the specified standard value, the module will maintain its locked position. However, if the applied load torque exceeds this value, the module may fail to lock properly, potentially causing the load to slip or fall, which could be hazardous. Therefore, do not apply a load torque greater than the specified standard value.

Table 7-2 Static Friction Torque of the Integrated Brake at SWG Input (Nm)

Parameter \ Model	eRob70F	eRob70	eRob80	eRob80F	eRob90	eRob110	eRob142	eRob170
Static Friction Torque	0.7		1.3		2.5		4.5	6

7.2 Brake Lifespan

7.2.1 Brake Opening and Closing Times

The brakes used in each module have undergone over 100,000 engagement tests, and all performance parameters remain normal after the lifespan testing.

7.2.2 The Amount of Forcible Drags While Brake Engaged

The brakes can withstand occasional forced dragging. Each brake undergoes over 1,000 cycles of forced dragging tests when engaged before leaving the factory, and all performance parameters remain normal.

7.3 Method for Forcibly Releasing the Brake (Non-Enabled State)

When the eRob power supply is functioning properly and the motor is not enabled, the eRob can be manually rotated by following the procedure in this section to release the brake, allowing rotation with minimal external force.


Note: Ensure the eRob is stopped and disabled before releasing the brake. Once released, no braking torque is applied, allowing free rotation. If gravity torque is present, the load will not maintain its position. Support or partially unload the load to prevent it from falling and causing further damage.

7.3.1 PC Software (eTuner) Operation

Step 1: As shown in [Figure 7-1a](#), install a computer with PC software [eTuner](#), connect eRob CAN communication interface through [eRob to PC Connector](#), and then supply the eRob with proper power, as shown in [Figure 7-1a](#).



(a) CAN wiring



(b) Connect PC and release brake

Figure 7-1 Wiring and Operation Illustration

Step 2: Open [eTuner](#) PC software and enter into the PC main interface. Click “Motor”, the “Motor Settings” interface will pop up, as shown in [Figure 7-1b](#).

- “Release Brake”: The brake (if equipped) will disengage.
- “Enable Brake”: The brake (if equipped) will engage.

Table 7-3 CAN Control Message of Brake

Function	COB-ID	Message
Release Brake	641	01 4F
	5C1	3E
Enable Brake	641	01 00 00 00 00 00
	5C1	3E

Note: The communication mode between PC and servo communication is CAN communication, so brake can also be operated by sending CAN messages. Please refer to [eRunner User Manual](#) for message protocol.

Take servo ID=1 as an example, sending messages are as shown in [Table 7-3](#).

7.3.2 EtherCAT Operation

Step 1: As shown in [Figure 7-2](#), install a computer with master software (TwinCAT3) or other master controllers with EtherCAT communication, connect to eRob ECAT communication interface via cables, and then supply proper power for the eRob.

Step 2: Take TwinCAT3 master station as an example, visit “Release Brake” parameter object “4602h (Release brake)” and enter value “1” through SDO, operation methods are shown in [Figure 7-3](#), click “Device 2 (EtherCAT)”, click “Drive1(ZeroErr Driver)”, click “CoE-Online”, pull down to find the object “4602”, double left-click the parameter object, the “Set Value Dialog” interface will pop up, enter value “1” in the “Dec”, and finally click “OK”, the brake is in release status (free brake), and if value “0” is entered, the brake is in close status(with brake).




Figure 7-2 EtherCAT wiring




Figure 7-3 TwinCAT release brake operation

7.3.3 CANopen Operation

Step 1: As shown in [Figure 7-4](#), connect the master controller with CANopen communication to the eRob CANopen communication interface the same hardware interface as CAN communication hardware interface, and then supply eRob with proper power.

Step 2: Master controller sends CANopen message to operate brake. Refer to *Chapter 3 of eRob CANopen and EtherCAT User Manual* for message protocol. Take servo ID=1 as an example, sending messages are as shown in [Table 7-4](#).



Figure 7-4 CAN wiring

Table 7-4 CANopen Control Message of Brake

Function	COB-ID	Message
Release Brake	601	23 02 46 00 01 00 00 00
	581	60 02 46 00 00 00 00 00
Enable Brake	601	23 02 46 00 00 00 00 00
	581	60 02 46 00 00 00 00 00

7.4 Abnormal Brake Judgment

The brake is abnormal when one of the below conditions occurs:

- (1) When the eRob rotary actuator with rated load is not powered on, it slips and cannot be maintained.
- (2) Powering on an eRob with DC48V separately and the eRob is in a no-load static status. After 6 seconds of power-on and no operation, the output current of the power supply exceeds the normal value (refer to [Table 7-5](#)), and then use the host computer to click to release the brake (Please refer to [Section 7.3.1](#) for details of the operation steps) After 3 seconds, the output current of the power supply exceeds the normal value (refer to [Table 7-5](#)).

Table 7-5 eRob Module Power Supply Current when Powered on Separately

Model	Power Current After 6 Seconds of Power-On and No Operation (mA)	Power Current After 3 Seconds of Releasing the Brake (mA)
eRob70	35~60	70~120
eRob80	35~60	90~120
eRob90	35~60	175~210
eRob110	35~60	175~210
eRob142	35~60	150~180
eRob170	35~60	150~180

Chapter 8 Kinetic Energy Recovery

8.1 Analysis of the Cause of Kinetic Energy Recovery

When the rotary actuator is powered by a 48V switching power supply, its simplified circuit loop is equivalent to that shown in Figure 8-1a and Figure 8-1b.

As shown in Figure 8-1a, when it works properly, the power supply supplies power to the load (motor) and outputs electric energy. As shown in Figure 8-1b, when the load is decelerating, the circuit loop is in the process of kinetic energy recovery. That is, the motor works as a generator, the kinetic energy is converted into electrical energy feedback, and the reverse current continuously charges the capacitor at the power supply end to increase the voltage. Since the recovered kinetic energy (power) is proportional to torque \times rotational speed ($E_k \propto (T \times n)$), the speed gets faster, the load gets greater, and the recovered kinetic energy (power) gets higher. When the power supply voltage rises to a value which is greater than the value of the permissible maximum bus voltage set by the drive, the servo will report errors and stop when the bus voltage is too high.

8.2 Solution


There are three processing methods for kinetic energy recovery:

- (1) Add leak resistor
- (2) Add super capacitor
- (3) Add storage battery


8.2.1 Add Bleeder Resistor

When the rotary actuator is powered on with a 48V switching power supply, the working circuit with adding leak resistor can be simplified and equivalent to Figure 8-2a and Figure 8-2b.

The function of adding leak resistor is that when the circuit loop is in kinetic energy recovery processing, the excess energy is dissipated through the resistor, thereby avoiding the power supply voltage spike in the process of the kinetic energy feedback. However, the leak resistor cannot be connected to the circuit for a long time, otherwise more heat will be generated continually, resulting in device damage, circuit failure or unnecessary current consumption. Therefore, it is recommended to design a reliable control logic of connecting leak resistor. For example, when setting the permissible maximum bus voltage setting value of the drive to 55V and the permissible minimum bus voltage setting value to 44V, the control logic of connecting the leak resistor




(a) During Normal Operation




(b) During Decelerating Operation

Figure 8-1 Circuit Illustrations for Different Operation



(a) Resistor is Disconnected when $V_{DC} < 51V$



(b) Resistor is Connected when $V_{DC} > 53V$

Figure 8-2 Bleeder Resistor Circuit Illustration

can be designed as that when the resistor is connected during $V_{DC} > 53V$ (as shown in Figure 8-2b, the excess power is dissipated through the resistor at this time), and when the resistor is disconnected during $V_{DC} < 51V$ (as shown in Figure 8-2a, the power supply only outputs power to the motor at this time).

8.2.2 Add Super Capacitor


The super capacitor with large capacitance and fast charging characteristics can be used to absorb and recover kinetic energy. The working circuit can be simplified and equivalent to Figure 8-3a and Figure 8-3b.

As shown in Figure 8-3a, switching power supply and the super capacitor supply power to the load (motor) and output electric energy at the same time when it works normally. As shown in Figure 8-3b, kinetic energy is converted into electric energy feedback and the super capacitor quickly charges to recover part of the kinetic energy when the load is decelerating, thereby avoiding quick supply voltage spike and realizing the effect of the supply voltage fluctuating within the range of safe voltage.


8.2.3 Add Storage Battery

Storage battery is used to charge and absorb kinetic energy recovery, whose circuit can be simplified and equivalent to Figure 8-4a and Figure 8-4b.

Similar to the principle of super capacitors, switching power supply and storage battery can supply power to the load (motor) and output electric energy at the same time (as shown in Figure 8-4a) when it works normally. As shown in Figure 8-4b, the kinetic energy is converted into electric energy feedback, and the kinetic energy is recovered by charging the storage battery when the load is decelerating.




(a) Super Capacitor is Discharging




(b) Super Capacitor is Charging

Figure 8-3 Super Capacitor Circuit Illustration



(a) Switching Power Supply add Storage Battery



(b) Storage Battery Charges

Figure 8-4 Storage Battery Circuit Illustration

Chapter 9 Encoder and Position Feedback

9.1 Encoder Resolution and Single-Turn Position Feedback

Rotary actuator is built-in dual absolute encoders to achieve dual loop position control, including a single-turn absolute encoder for motor with 17-bit resolution and a single-turn absolute encoder for output shaft with 19-bit resolution. (The multi-turn resolution of rotary actuator with multi-turn function is 16 bit)

Encoder resolution refers to the position number outputted by one rotation of the rotary actuator. For example, the encoder resolution of the output shaft is 19 bit, that is, the position number outputted by one rotation of the shaft is 2^{19} ; The single-turn position feedback of 19-bit resolution is 0~524287, which will jump from 0 to 524287 if the actuator moves in the opposite direction at the 0 position. On the contrary, the position feedback will jump from 524287 to 0 if the actuator moves in the positive direction at the 524287 position.

Calculation Example

Calculate the encoder position corresponding to the single-turn angle(19 bit), if the position angle is 20° :

$$P_{encoder} = \frac{\theta}{360} \times 524288 \quad (9.1)$$

$$P_{encoder} = \frac{20^\circ}{360} \times 524288$$

$$P_{encoder} = 29127$$




Figure 9-1 Position Feedback

9.2 Position Feedback of Rotary Actuator

When the encoder single-turn position jumps at the boundary position, the rotary actuator will count the multi-turn turns. As shown in Figure 9-1, the encoder boundary positions with 19-bit resolution are 0 and 524287; The position feedback will jump from 524287 to 0 if it rotates in the positive direction, and the multi-turn turns +1; On the contrary, the position feedback will jump from 0 to 524287 if it rotates in the opposite direction, the multi-turn turns -1.

The current position calculation formula:

$$P_c = N \times resolution + P_s \quad (9.2)$$

Symbol	Definition	Unit
P_c	Current encoder position	count
N	The amount of rotation	N/A
P_s	Single-turn encoder position	count

Rotary Actuator Position Feedback Acquisition:

- (1) Read object index 6064h (actual position, unit: pulse) via EtherCAT or CANopen bus. According to the above position calculation formula, it can be seen that:

$$6064h \text{ value} = N \times resolution + P_s \quad (9.3)$$

Symbol	Definition	Unit
N	The amount of rotation	N/A
P_s	Single-turn encoder position	count

- (2) In **eTuner**, read the position feedback of rotary actuator via the “Position” displayed in the “Monitor” interface; the singleturn position feedback corresponds to the “Motor Encoder” and “Load Encoder” displayed in the “Encoder” interface, as shown in [Figure 9-2a](#) and [Figure 9-2b](#).

Motor Encoder:	112,755	Position:	164,202	[count]
		Speed:	0	[count/s]
Load Encoder:	164,202	Pulse:	0	[count]

(a) Encoder

(b) Position

Figure 9-2 The **eTuner** Reads the Position Feedback

9.3 Position and Cautions of Rotary Actuator with Single-Turn Function

Adjust the output shaft position of reducer before installation of rotary actuator equipped with singleturn encoder to ensure no overshoot of output singleturn encoder boundary position (0 and 524287) within the operation range. Otherwise, the multi-turn count will be lost after powering off and restarting to operate, then the actuator position feedback will become the output encoder singleturn position.

9.4 Position and Cautions of Rotary Actuator with Multi-Turn Function

The rotary actuators with multi-turn encoder do not need to adjust the output shaft position of reducer to match the mechanical zero position before installation. Noted that the 3.6V multi-turn power supply battery needs to be installed before using the multi-turn rotary actuator, and then click “Reset Load Encoder” in “Encoder” interface to clear the multi-turn battery errors (The operation method is shown in [Figure 9-3](#)). If you intend to use the multi-turn eRob module as a single-turn model (i.e., not connected to the 3.6V multi-turn power supply battery), please be aware that the multi-turn module will generate an error upon each power-off and restart. To resolve this issue, users can clear the error by writing 0x80 to the control word (address 6040h) and then enable the eRob module. During operation, please ensure that the device operates within the single-turn range and does not surpass the boundaries of the output-side single-turn

encoder (0 and 524287). Failure to comply may result in the loss of multi-turn counting after a power-off restart, causing the position feedback to revert to the single-turn encoder's position at the output side.

NOTE:

- (1) The multi-turn eRob should be equipped with a battery during the first use, then click “Reset Load Encoder” to clear multi-turn error reports.
- (2) If encoder battery alarms occur during operation, click “Reset Load Encoder” to clear multi-turn error reports after troubleshooting.

9.5 Instruction of Zero Position Calibration Function

9.5.1 Zero Position Calibration Function of Single-Turn Rotary Actuator

Due to the installation method, when the singleturn rotary actuator operates with the zero position defined by the user and reaches the maximum motion range, the position feedback value may exceed the boundary value (0 or 524287). The user can set the zero position to 262144 by using zero position calibration function thereby ensuring the maximum motion range the singleturn eRob rotary actuator is $-175^{\circ}\sim 175^{\circ}$ and the position feedback value is within the singleturn position range as shown in Figure 9-4.

Connect [eTuner](#), make the eRob move to the zero position defined by the user. Refer to [Chapter 14](#) for detailed steps. The flow diagram for zero position calibration of singleturn eRob is as shown in Figure 9-5.

The steps for using zero position calibration function of singleturn eRob are as shown in Figure 9-6. When the save command is completed, power off and restart. Open the “Zero point” interface, when current “Position” value is 262144, the setting is successful.

NOTE: Mechanical zero calibration function of singleturn eRob in the latest [eTuner](#) should match firmware of X3071220X or above.




Figure 9-3 Load Encoder Reset Operation




Figure 9-4 Comparison Figures of Before/After Zero Position Calibration of Single-Turn eRob




Figure 9-5 Flow Diagram of Zero Position Calibration of Single-Turn eRob




Figure 9-6 Zero Position Calibration Function of Single-Turn eRob

9.5.2 Zero Position Calibration Function of Multi-Turn Rotary Actuator

The multi-turn eRob user can use zero position calibration function to set the zero position (0~524287) flexibly according to the actual situation. The default zero position value is 262144, as shown in Figure 9-7.

Connect eTuner and make the eRob move to the zero position set by the user. Refer to Chapter 14 for detailed steps. The flow diagram for zero position calibration of multi-turn eRob is as shown in Figure 9-8a.

The steps for using zero position calibration function of multi-turn eRob are as shown in Figure 9-8b. When the save command is completed, power off and restart. Open the “Zero point” interface, when the setting value is displayed in current “Position”, the setting is successful.

NOTE: Mechanical zero calibration function of multi-turn eRob in the latest eTuner should match firmware of X3071220X or above.






Figure 9-7 Comparison Figures of Before/After Zero Position Calibration of Multi-Turn eRob



(a) Flow Diagram for Zero Position Calibration of Multi-Turn eRob



(b) Zero Position Calibration Function of Multiturn eRob

Figure 9-8 Zero Position Calibration

9.6 Instruction of Position Protection Function

The rotary actuators are configured with the default parameters of position protection as shown in Figure 9-9. The user can use the “Pos Limit” function to limit the actual motion range of the eRob, preventing the eRob from operating beyond the actual permissible maximum motion range which may cause device collision or the wire connection damage between rotary actuators.

For example: the operation range is $\pm 15^\circ$, the encoder position corresponding to the mechanical zero position (0°) is 262144, that is ,

Lower limit set value: $262144 - 21846 = 240298$

Upper limit set value: $262144 + 21846 = 283990$

Setting method via eTuner is as shown in Figure 9-10. Open the “Safe Position” interface, set “Position Limit” from (lower limit set value) to (upper limit set value); then click “Apply” and “Save”.

Position protection parameters can also be set via EtherCAT or CANopen bus. The object index of position limit protection parameter is “607D_h”, enter lower limit set value “607D_h: 01_h”, enter upper limit set value “607D_h: 02_h”, and then enter save command “65766173_h”. (enter other value is invalid and the read-back value is “0”; when the read-back value is “1”, it means the save command is in execution; the read-back value is “2”, it means the save command is completed).




Figure 9-9 The Default Parameter of Position Protection




Figure 9-10 Set Position Protection

Table 9-1 The effects of position limitations in different operating modes

6060 _h Set Value	Operation Mode	Position Limit Effect
0x01	Profile Position Mode	If the target position (607A _h) sent by the master station controller exceeds the position limit, the driver will use the limit position as the internal target position for motion trajectory planning. It will decelerate to 0 at the profile deceleration rate (6084 _h) before reaching the limit and stop at the limit position, continuously outputting position-holding torque. At this time, the driver will only execute target position (607A _h) commands within the position limit range.
0x04	Profile Torque Mode	When the actual position (6064 _h) reaches or exceeds the position limit, the driver immediately shuts off the power to the motor, but the brake does not engage. At this point, both the motor actual current (6078 _h) and the torque actual value (6077 _h) become zero, and no position holding torque is outputted. It is important to note that the eRob module remains enabled during this time, and it may continue to move due to inertia and gravity acting on the load. In this situation, the driver will only execute target torque (6071 _h) commands that move the eRob module in the direction within the position limit range.
0x08	Cyclic Synchronous Position Mode	When the position actual value (6064 _h) reaches or exceeds the position limit, the driver will rapidly decelerate and come to a stop, return to the limit position and continuously outputting position holding torque. During this time, the driver will only execute target position (607A _h) commands within the range of the position limit.
0x0A	Cyclic Synchronous Torque Mode	When the actual position (6064 _h) reaches or exceeds the position limit, the driver will immediately cut off the power to the motor, but the brake will not engage. As a result, both the motor actual current (6078 _h) and the torque actual value (6077 _h) will be set to zero, and no position holding torque will be outputted. It is important to note that during this time, the joint remains in the enabled state, and it may continue to move due to inertia and gravity acting on the load. In such cases, the driver will only execute target torque (6071 _h) commands that move the joint in the direction towards the position limit range.

Chapter 10 Multi-Turn Power Supply Battery Instruction

10.1 Function of Battery

When the rotary actuator with multi-turn is powered off, it provides working power for the load multi-turn encoder to count the multi-turn position value and avoid rotary actuators and other devices losing zero position.

10.2 Cautions on Battery Usage

Cautions on multi-turn power supply battery usage:

- (1) Do not change the wiring sequence of the original battery, and do not vigorously pull the battery wires;
- (2) Do not use wires or other conductive media to directly connect to the positive and negative terminals of the battery;
- (3) The wiring terminal of the original battery is only suitable for the multi-turn power supply battery interface of rotary actuators in our company. Pay attention to the correct connecting direction. Fix the battery to prevent the terminals from being pulled and shaken after insertion;
- (4) Reset the load encoder after the first installation of the battery or replacement of a new battery (the reset operation method is shown in [Section 9.4](#)). When replacing the battery, do not pull out the connector terminal directly. Pull the terminal front end snaps to release the buckle, and then gently pull it out.

Note: More details for safety cautions, please refer to [Appendix A](#).

10.3 Power Consumption of Multi-Turn Encoder

According to the test (ambient temperature: 25°C), on the condition that a single multi-turn battery (initial voltage: 3.67V) supplies power to a rotary actuator (with multi-turn function), the current consumption is $4\mu\text{A}$ when the rotary actuator with 48V input power is not powered on; and the current consumption is $0\mu\text{A}$ when the rotary actuator with 48V input power is powered on. [Figure 10-1](#) shows the discharge characteristic curve of multi-turn battery at 25°C. According to the calculation of 1mA discharge curve, a battery can supply 250 rotary actuators, and the battery requires discharging continuously for at least 1000h when voltage drops to 3.2V. According to the calculation of $25\mu\text{A}$ discharge curve, a battery can




Figure 10-1 Discharge Characteristics of multi-turn battery at 25°C

supply power for 6 actuators; and the battery requires discharging continuously for at least 50,000h (about 5.7 years) when voltage drops to 3.2V. It can be estimated that a battery powers a rotary actuator ($4\mu A$ discharge) when voltage drops to 3.2V, it requires discharging continuously for at least 300,000h (about 34.2 years).

10.4 Battery Related Errors Handling

Refer to [Table 10-1](#) for the battery related errors handling.

Table 10-1 Query Table for Battery Related Errors Handling

Error Codes Reported by 0x603F	Messages	Direct Causes	Possible Causes	Troubleshooting
0x730D	Battery Warning Error* ¹	Load encoder multi-turn battery keeps holding voltage lower than warning voltage 3.15V.	<ol style="list-style-type: none"> 1. The battery is normally consumed to low voltage warning. 2. Use wrong battery. 3. Abnormal battery circuit leads to fast consumption. 	<ol style="list-style-type: none"> 1. Replace batteries with new ones and perform correct reset operation*². 2. Replace batteries with correct ones and perform correct reset operation. 3. Check cables, replace batteries with new ones and perform correct reset operation.
0x730F	Battery Voltage is Too Low	Load encoder multi-turn battery keeps holding voltage lower than working voltage 3.05V.	<ol style="list-style-type: none"> 1. After the battery is consumed to trigger the low voltage warning, continue consuming to trigger the voltage warning error. 2. Use a wrong battery. 3. The battery circuit is in poor contact. 4. The battery is not connected. 	<ol style="list-style-type: none"> 1. Replace batteries with correct ones and perform the correct reset operation. 2. Replace the correct batteries and perform the correct reset operation. 3. Check cables, replace batteries with new ones and perform correct reset operation. 4. Install the batteries and perform a correct reset operation.
0x7314	Power-Off Status Detected	When load encoder multi-turn battery keeps holding voltage higher than the working voltage 3.05V.	<ol style="list-style-type: none"> 1. Load encoder has been replaced the battery. 2. Load encoder battery wiring is too loose. 	<ol style="list-style-type: none"> 1. Perform correct reset operation. 2. Check load encoder wiring and perform correct reset operation.
0x7374	Multi-Turn Position Error	Under this condition, load encoder has been replaced the battery.		

*1 Multi-turn data will not be lost when the rotary actuator reports a battery warning error.

*2 The correct reset operation is shown in [Figure 9-4](#). Connect to [eTuner](#), open “Encoder” interface and click “Reset Load Encoder”.

Chapter 11 Multi-Turn Encoder Battery Under-Voltage Warning

Status instruction:

- (1) Battery status: “0” indicates the battery power supply voltage of the encoder is lower than 3.05V, “1” indicates the battery voltage of the encoder is normally powered, and “x” means arbitrary state.
- (2) 48V status: “0” indicates the rotary actuator is not supplied power with 48V, and “1” indicates the rotary actuator is supplied power with 48V.

11.1 The Status when 48V Power Supply Switch from OFF to ON (0 -> 1)

Case 1: Description: In the previous state, there were no reported errors, and the module started up without any issues. During the current startup, there are no error reports from CAN and EtherCAT, indicating a smooth and error-free initialization process.

	Previous Status	Startup
Battery	1	1
48V	1	0 → 1
Status	OK	OK

Case 2: Description: Under the condition that the previous status was in arbitrary status, when the actuator was started, the battery was dead. The CAN and EtherCAT are started this time with reporting multi-turn power failure alarm error, the multi-turn is lost, but the servo drive can be enabled.

	Previous Status	Startup
Battery	x	1
48V	1	0 → 1
Status	x	NG

Case 3: Description: Under the condition that there were no error reports in previous status, pull out the battery with 8 seconds (the capacitor discharge takes time, which can be quickly discharged by both terminals of short-circuiting) and then insert the battery back before the actuator starts. CAN and EtherCAT are started with reporting “multi-turn power-off alarm” this time, then the multi-turn is lost, but the servo drive can be enabled.

	Previous Status	Before Startup	Startup
Battery	1	1 → 0 → 1	1
48V	0	0	0 → 1
Status	OK	OK	NG

11.2 The Status When the 48V Power Supply Has Been Activated (1)

Case 1: Description: If the current status is normal, no error will be reported under arbitrary status when operating. CAN and EtherCAT will not report errors, the multi-turn value will not be lost.

	Current Status	Startup Status
Battery	1	×
48V	1	1
Status	OK	OK

11.3 The Status When 48V Power Supply from Startup to Close to Startup (1 -> 0 -> 1)

Case 1: Description: If the current status is normal at startup, and the battery voltage drops below 3.05V under startup condition, CAN and EtherCAT will not report any errors, and the multi-turn value will not be lost. When the rotary actuator restarts, CAN and EtherCAT will not report “multi-turn power-off alarm”, and the multi-turn will be lost, but the servo drive can be enabled.

	Current Status	Startup Status	Restart the Rotary Actuator
Battery	1	1 → 0	0
48V	1	1	1 → 0 → 1
Status	OK	OK	NG

Case 2: Description: If the current status is normal at startup, and the battery voltage drops below 3.05V under startup condition, CAN and EtherCAT will not report any errors, and the multi-turn value will not be lost. When the rotary actuator restarts, CAN and EtherCAT will not report the “multi-turn battery with low voltage” error, and the multi-turn is lost, but the servo drive can be enabled.

	Current Status	Startup Status	Restart the Rotary Actuator
Battery	1	1 → 0 → 1	1
48V	1	1	1 → 0 → 1
Status	OK	OK	NG

Chapter 12 Strain Wave Gear Analysis

12.1 Gear Ratio Analysis

12.1.1 Output Rotational Speed Calculation

The rotary actuator output side is outputted after the motor passed through the gear, and the conversion from motor speed(n_m) to the output speed(n_o) needs to be calculated by the gear ratio(m_G). The formula is:

$$n_o = \frac{n_m}{(m_G + 1)} \quad (12.1)$$

Symbol	Definition	Unit
n_o	SWG output rotational speed	RPM
n_m	motor / SWG input rotational speed	RPM
m_G	SWG gear ratio*	N/A

* The reason why dividing by ($m_G + 1$) is related to the gear installation method, that is, the input is wave generator; the output is circular spline; and the fixation of installation is flexspline.

12.1.2 About Speed Setting and Angular Velocity Conversion

There are two encoders in a rotary actuator, encoder for motor (17 bit) and encoder for output shaft (19 bit). The rotary actuator runs with dual loop position control, so the way to set the operating speed is setting the output rotational speed directly. The speed feedback is the rotational speed feedback of the output. As shown in Figure 12-1.

(1) The conversion formula between eRob rotational speed (n_c) (unit: count/s) and rotational speed (n_{RPM}) (unit: RPM): (524288 is the resolution of 19-bit encoder in the output shaft)

$$n_{RPM} = \frac{n_c}{524288} \times 60 \quad (12.2)$$

Symbol	Definition	Unit
n_{RPM}	output rotational speed	RPM
n_c	output rotational speed	counts/s

(2) The conversion formula between eRob rotational speed (n_c) (unit: count/s) and angular velocity (ω_θ) (unit: °/s):

$$\omega_\theta = \frac{n_c}{524288} \times 360 \quad (12.3)$$

Symbol	Definition	Unit
ω_θ	output angular velocity	°/s
n_c	output rotational speed	counts/s




Figure 12-1 Speed Setting Interface

(3) The conversion formula between eRob rotational speed (n_c) (unit: count/s) and angular velocity (ω_{rad}) (unit: rad/s):

$$\omega_{rad} = \frac{n_c}{524288} \times 2\pi \quad (12.4)$$

Symbol	Definition	Unit
ω_{rad}	output angular velocity	rad/s
n_c	output rotational speed	counts/s

(4) Set angular acceleration/deceleration (a): It is recommended to set the acceleration/deceleration time (t_a) ≥ 0.3 s. The acceleration time is the required time for the eRob to reach the target speed from 0. The deceleration time is the required time for the eRob to reach 0 from the target speed (ω_t). The relationship between ω_t and t_a :

$$a = \frac{\omega_t}{t_a} \quad (12.5)$$

Symbol	Definition	Unit
a	angular acceleration/deceleration	$^\circ/s^2, rad/s^2$
ω_t	target speed (angular velocity)	$^\circ/s, rad/s$
t_a	acceleration/deceleration time	second

(5) The max. rotational speed for each model of eRob is as shown in [Table 12-1](#).

Table 12-1 Max. Rotational Speed of Each Model of eRob

Model	Gear Ratio m_G	Max. Output Rotational Speed n_c (counts/s)	Max. Output Rotational Speed n_{RPM} (RPM)	Max. Output Angular Velocity ω_θ (°/s)	Recommended Acc. / Dec. Time t_a (seconds)
eRob70F	50	524288	60	360	≥ 0.3
	80	327680	37.5	225	≥ 0.3
	100	262144	30	180	≥ 0.3
eRob70H	50	524288	60	360	≥ 0.3
	80	327680	37.5	225	≥ 0.3
	100	262144	30	180	≥ 0.3
	120	218453	25	150	≥ 0.3
eRob80F	50	524288	60	360	≥ 0.3
	100	262144	30	180	≥ 0.3
eRob80H	50	524288	60	360	≥ 0.3
	80	327680	37.5	225	≥ 0.3
	100	262144	30	180	≥ 0.3
	120	218453	25	150	≥ 0.3
eRob90H	50	524288	60	360	≥ 0.3
	80	327680	37.5	225	≥ 0.3
	100	262144	30	180	≥ 0.3
	120	218453	25	150	≥ 0.3
eRob110H	50	524288	60	360	≥ 0.3
	80	327680	37.5	225	≥ 0.3
	100	262144	30	180	≥ 0.3
	120	218453	25	150	≥ 0.3
	160	163840	18.75	112.5	≥ 0.3
eRob142H	50	349525	40	240	≥ 0.3
	80	218453	25	150	≥ 0.3
	100	174763	20	120	≥ 0.3
	120	145927	16.7	100.2	≥ 0.3
	160	109227	12.5	75	≥ 0.3
eRob170H	50	349525	40	240	≥ 0.3
	80	218453	25	150	≥ 0.3
	100	174763	20	120	≥ 0.3
	120	145927	16.7	100.2	≥ 0.3
	160	109227	12.5	75	≥ 0.3

Chapter 13 PC Connection and Debugging

Step 1: Wiring the [eRob to PC Connector](#), do not connect PE, connect L to CAN_L, connect G to GND, connect H to CAN_H, switch 1 or 2 to ON in R DIP switch, and do not move the other one, then connect the “Connector” to the rotary actuator. As shown in [Figure 13-1](#).




Figure 13-1 eRob to PC Connector Interface

NOTES: For more details regarding the functionality and operation guide please refer to the “[eRob to PC Connector User Manual](#)”


Step 2: Install “USBCANWDM.INF”. Download the latest [eTuner](#) software in [ZeroErr official website](#), unzip the compressed package and open [eTuner_V13.51 \ Driver_installation](#).

Then double click the DriveSetup program to install the drive (as shown in [Figure 13-2a](#)).

Step 3: Open the software and follow the steps below to connect the actuator as shown in [Figure 13-2b](#).

- (1) Click “Connect” to open “Connect Settings” interface.
- (2) Click “Scanning” to test, wait for Scanning finish.
- (3) Click “Add List”.
- (4) Click the device has been added.
- (5) Click “Connect”.
- (6) Connect successfully and display CAN ID parameters etc.

Note: The equipment has been added, just need to repeat step 4, 5, and 6 in Step3.



(a) “Connector” Driver Installation

(b) “Connector” Driver Installation

Figure 13-2 PC Connection and Debugging

Chapter 14 Trial Run for Rotary Actuator




Figure 14-1 “MotorMovement” Interface

Interface Introduction:

- (1) Click “Enable”. The motor is enabled, and the brake is released automatically.
- (2) The current “Position” value is displayed and set the “Speed” which takes the encoder resolution as the unit. The “Jerk” is the time for the eRob achieves the set acceleration from 0 (The larger the setting value, the closer to the S-type speed curve; the smaller the setting value, the closer to the T-type speed). The default setting is 50us. The “Stop Time” is the dwell time when setting point-to-point reciprocating motion.
- (3) Set a target position and make the motor move to there. Tick “Repetitive” and make the motor move back and forth between the current position and target position.
- (4) Set the relative motion displacement value, make the motor move forward or backward by a set displacement value. Tick “Repetitive” and make the motor operate the reciprocating motion at the current position with the set displacement.
- (5) Do not tick “Continuous” and click “Forward” and “Backward” to make the motor move; click “Continuous”, click “Forward” and “Backward” to make the motor to move continuously.
- (6) Decelerate with the set “Dec.” to stop. Although the motion is stopped, the motor is not disabled and the brake keeps releasing.
- (7) Speed limit function: When “Limit Move (Acc., Dec.)” is ticked, the rotary actuator motion is limited by the “Acc.”, “Dec.”, “Speed limit” (set in “MotorMovement” interface) and “Max Motor Speed” (set in the “Speed” interface). When “Limit Move (Acc., Dec.)” is not ticked, the actuator motion is only limited by the “Max Motor Speed” set in the “Safe Speed” interface.

torMovement” interface) and “Max Motor Speed” (set in the “Speed” interface). When “Limit Move (Acc., Dec.)” is not ticked, the actuator motion is only limited by the “Max Motor Speed” set in the “Safe Speed” interface.

Steps for No-Load Trial Run of the Motor:

- (1) Check the “Speed” does not exceed the permissible maximum speed in “Speed” interface. It is recommended to set a lower speed operation at the beginning.
- (2) Click “Enable” before moving and confirm that the brake is released (there will be a “click” sound when the brake is released).
- (3) Click “Forward” in the “Repetitive”, the motor moves forward, and observe the operation status of the motor.
- (4) Click “Stop”, the motor will decelerate and stop.
(Note: Do not directly click “Motor Stop” on the main interface during



Motor Stop

Figure 14-2 “Motor Stop” Button on the Main Interface of the Software

operation).

- (5) Click “Motor Stop” (as shown in [Figure 14-2](#)) in the main interface of the software, the motor is disabled and the brake works. The trial run is finished.


Chapter 15 PID Tuning with Load

After loading, tune the PID of speed loop and position loop. First, open the “Oscilloscope” and “PID” on the main interface of the host computer, and click the icons as shown in [Figure 15-1a](#).


Note:

1. Before performing PID tuning, please ensure that the parameters shown in [Figure 15-1b](#) are set correctly. On the control mode interface, set “Operation Mode” to “Position Control” and “Control Source” to “0-Not Used”. The settings should be made while the joint is in the enabled state (click the “Motor Stop” button on the main interface to enable the joint). After setting the parameters, click the “Apply” button at the bottom of the interface to take effect immediately; otherwise, the joint will not operate.

2. Before performing PID tuning, it is recommended to adjust the load position to an appropriate location. For example, if the joint is horizontally installed (with the output shaft axis parallel to the ground), the load position should be adjusted to a vertical position as much as possible (i.e., the load force arm direction is perpendicular to the ground). After adjusting the load position, you can proceed with PID tuning.



(a) PID settings and Oscilloscope in Main Interface




(b) Control Mode Interface Parameter Setting
Figure 15-1 Settings Illustration

15.1 Speed Loop Adjustment


- (1) First, select the “Target Speed (limiting amplitude)” and “Actual Speed” as “Signals” in the oscilloscope interface; the “Interval” is “500 $\mu\text{sec}/\text{point}$ ”, the “Time” is “2 sec”. The “Target Speed (limiting amplitude)” is used as the “Signal”, the “Condition” is “ \neq ” and “Position” select “0%”, click “Start sampling” to make the oscilloscope in the status of “Waiting for triggering”, as shown in [Figure 15-2a](#).
- (2) Set “Excit Frequency” of speed loop in “PID Adjust” interface as shown in [Figure 15-2b](#), the recommended value is 1Hz. The “Excit Speed” is generally set to 524288/Gear Ratio; Tune PID from the original basic value. Click “Excit Speed”; at the moment, the motor will response following the excit speed and the oscilloscope will collect data.
- (3) Adjust “Speed Loop Gain” first, and it is acceptable that the waveform is without excessive oscillation. Then adjust “Speed Loop Integral”, the value does not need to be set too large, which can eliminate oscillation properly. The final waveform should be close to the one as shown in [Figure 15-2c](#).
- (4) Click “Motor Stop” after the completion of adjustment. Click “Apply” in the left bottom

of PID Adjust interface, then click “Save” in the main interface to save parameters (save command will be completed after about 3 seconds), thereby avoiding reverting into original parameters after the drive restarts.


- (5) The speed loop excitation type can be set to sine wave excitation, and the resulting waveform should resemble the waveform shown in Figure 15-2d.




(a) Oscilloscope Settings



(b) Excit Speed in PID Setting Interface



(c) Speed Loop Excitation Response Waveform



(d) Speed Loop Sine Wave Excitation Waveform


Figure 15-2 Speed Loop Adjustment

15.2 Position Loop Adjustment


- (1) Select “Target Position (limiting amplitude)” and “Position” as the “Signals” in oscilloscope interface, the “Interval” is “500 μ sec/point”, the “Time” is “2 sec”; use “Target Position (limiting amplitude)” as “Signal”, and “Condition” is “ \neq ” and “Position” select “0%”, then click “Start sampling” to make oscilloscope in the status of “Waiting for the trigger”, as shown in Figure 15-3a.
- (2) Set “Excit Frequency” in PID Adjust interface as shown in Figure 15-3b, the recommended value is 1Hz. The “Excit Position” is generally set to 52428/gear ratio; adjust PID from the original basic value. Click “Excit Position”; at the moment, the motor will response following the excit position and the oscilloscope will collect data.
- (3) Adjust “Pos Loop Gain”, the final waveform should be close to the one shown in Figure

15-3c.


- (4) Click “Motor Stop” after the completion of adjustment. Click “Apply” in the left bottom of “PID Adjust” interface, then click “Save” in the main interface to save parameters (save command will be completed after about 3 seconds), thereby avoiding reverting into original parameters after the drive restarts.
- (5) The position loop excitation type can be set to sine wave excitation, and the resulting waveform should resemble the waveform shown in [Figure 15-3d](#).




(a) Oscilloscope Settings



(b) Excit Position in PID Setting Interface



(c) Position Loop Excitation Response Waveform




(d) Position Loop Excitation Response Waveform

Figure 15-3 Position Loop Adjustment

15.3 EtherCAT Dynamically Modify PID Function

In addition to being modified by the PC, the PID parameters can also be modified dynamically through the EtherCAT. First, tick “Bus Adjust PID” in “PID Adjust” interface as shown in [Figure 15-3c](#), then click “Apply” and “Save”, otherwise the modification will be invalid. Then, visit 2381_h: 01_h (speed loop gain), 2381_h: 02_h (speed loop integral), and 2382_h: 01_h (position loop gain) through SDO to dynamically modify PID parameters (Current loop parameters are not available to modify. They are factory settings, do not need to be modified).

Attentions on Using Bus Adjust PID: Tick “Bus Adjust PID” first when EtherCAT modify PID parameter function is needed, otherwise the function cannot be used. If the operation of using PC to modify PID parameters is needed after using EtherCAT to modify PID parameters, please follow the operation steps below to avoid the PC modifying PID operation from not taking effect and becoming a value between the original value and the target value :



The screenshot shows a window titled "PID Adjust" with a close button in the top right corner. Below the title bar, it displays "PosErr: 0". There are six input fields arranged in two columns: "Pos Loop Gain" (80), "Speed Loop Gain" (1800), "Speed Loop Integral" (70), "Speed Feed" (0), "Acc Feed" (0), and "Bus Adjust PID" (checkbox). The "Bus Adjust PID" checkbox is checked and highlighted with a red rectangular box.

Figure 15-4 Tick “Bus Adjust PID”

- (1) Untick “Bus Adjust PID” ;
- (2) Tick “Apply” and “Save”
- (3) Reenter into “PID Adjust” interface and modify the PID parameters.

For more info regarding EtherCAT dynamically modifies PID function and the description of the related object dictionary, please refer to [Section 8.2](#) in [eRob CANopen and EtherCAT User Manual](#).

Chapter 16 Special Function Introduction

16.1 PDO Dynamic Configuration

In the predefined list of eDriver series PDO mapping, 0x1A00/0x1600 mapping TxPDO/RxPDO supports any mapping configuration (the total number of configurable PDO bytes is up to 80 bytes), including but not limited to:

(1) TxPDO:

- 6041_h
- 6064_h
- 606C_h
- 6061_h
- etc.

(2) RxPDO:

- 6040_h
- 607A_h
- 6065_h
- 6060_h
- etc.

Note: Due to the characteristics of the ESC chip, if you need to configure an 8-bit length object index (such as 6060_h/6061_h), you need to configure an empty 8-bit (bit8) at the same time to align with 2 bytes (16bit). More details about PDO mapping list description, please refer to *Chapter 3* in *eRob CANopen and EtherCAT User Manual*.

16.2 PID Control Function of Variable Integral Upper Limit

Access parameter ID: 97 (decimal) through CAN can proceed reading and writing operations on “Speed Loop Integral Upper Limit” parameters (parameter properties: INT32, not saved to flash, can be read and written, unit: mA) and also can modify parameters while the rotary actuator is running.

Function Instructions:

- (1) Setting integral upper limit to 0 can eliminate the accumulated speed loop integral value.
- (2) Restoring integral limit value to the original set value will cause shock. Therefore, it is recommended to increase the value gently (the increased appropriate value of each cycle depends on the actual smoothness of operation, and it is recommended to increase from small value to large value to see the actual effect).
- (3) PID control of variable integral upper limit can not only eliminate the integral being 0, but also can properly change integral upper limit, which makes the servo running more stable and allows a larger proportional gain and quicker response speed.

Chapter 17 Permissible Forces in All Directions

The eRob Rotary Actuator features a cross roller bearing designed to directly support external loads on the output flange. To fully optimize the performance of the eRob rotary actuator, please calculate:

- Maximum moment load (M_{max});
- Lifespan of the cross roller bearing (L_{10});
- Static safety coefficient (f_s).

17.1 Maximum Moment Load Calculation

The formula for calculating the *maximum moment load* (M_{max}) is provided below:

$$M_{max} = F_{r,max}(L_r + R) + F_{a,max} \times L_a \tag{17.1}$$

Symbol	Definition	Unit	Reference
M_{max}	Max. Moment Load	Nm	-
$F_{r,max}$	Max. Radial Load	N	Figure 17-1
$F_{a,max}$	Max. Axial Load	N	Figure 17-1
L_r	Radial Load Length	m	Figure 17-1
L_a	Axial Load Length	m	Figure 17-1
R	Offset Length	m	Figure 17-1 & Table 17-3

NOTE: Make sure $M_{max} \leq M_c$




Figure 17-1 External Load Influence Diagram

EXAMPLE Consider the eRob70H module under the following conditions:

$$L_a = 0.2 \text{ m}, \quad L_r = 0.5 \text{ m}, \quad F_{r,\max} = 50 \text{ N}, \quad F_{a,\max} = 30 \text{ N}$$

SOLUTION Refer to [Table 17-3](#) for the permissible moment load:

$$R = 0.0217 \text{ m}, \quad M_c = 74 \text{ Nm}$$

Substitute these values into [Formula 17.1](#):

$$M_{\max} = 50 \times (0.5 + 0.0217) + 30 \times 0.2$$

$$M_{\max} = 32.085 \text{ Nm}$$

The calculation demonstrates that $M_{\max}(32.085 \text{ Nm}) \leq M_c(74 \text{ Nm})$, confirming compliance with bending requirements.

17.2 Cross Roller Bearing Lifespan Calculation

The formula for calculating the *lifespan of the cross roller bearing* (L_{10}) is provided below:

$$L_{10} = \frac{10^6}{60 \times N_{avg}} \times \left(\frac{C}{f_w \times P_c} \right)^{\frac{10}{3}} \quad (17.2)$$

Symbol	Definition	Unit	Reference
L_{10}	Life (10% damage probability)	hr	-
N_{avg}	Average output speed	RPM	Section 17.2.1
C	Basic dynamic rated load	N	Table 17-3
f_w	Load coefficient	-	Table 17-1
P_c	Dynamic equivalent	N	Formula 17.3

The formula for calculating the *dynamic equivalent* (P_c) is provided below:

$$P_c = X \times \left(F_{r,avg} + \frac{2[F_{r,avg}(L_r + R) + F_{a,avg} \times L_a]}{d_p} \right) + Y \times F_{a,avg} \quad (17.3)$$

Symbol	Definition	Unit	Reference
P_c	Dynamic equivalent	N	Formula 17.3
X	Radial load coefficient	-	Formula 17.7
$F_{r,avg}$	Average radial load	N	Formula 17.4
L_r	Radial Load Length	m	Figure 17-1
R	Offset Length	m	Table 17-3
$F_{a,avg}$	Average axial load	N	Formula 17.5
L_a	Axial Load Length	m	Figure 17-1
d_p	Pitch circle diameter	m	Table 17-3
Y	Axial load coefficient	-	Formula 17.7

Table 17-1 Load Coefficient

Load status	f_w
Steady operation without impact and vibration	1 ~ 1.2
Normal operation	1.2 ~ 1.5
Operation with impact and vibration	1.5 ~ 3

17.2.1 Average Load Calculation

When the radial and axial load fluctuate, as shown in [Figure 17-2](#), an average load is required to confirm the lifespan of the cross roller bearing.

$$F_{r,avg} = \left(\frac{n_1 t_1 |F_{r1}|^{\frac{10}{3}} + n_2 t_2 |F_{r2}|^{\frac{10}{3}} + \dots + n_n t_n |F_{rn}|^{\frac{10}{3}}}{n_1 t_1 + n_2 t_2 + \dots + n_n t_n} \right)^{\frac{3}{10}} \quad (17.4)$$

Symbol	Definition	Unit	Reference
$F_{r,avg}$	Average radial load	N	-
n_x	Output Speed	RPM	Figure 17-2
t_x	Time	s	Figure 17-2
F_{rx}	Radial load	N	Figure 17-2

$$F_{a,avg} = \left(\frac{n_1 t_1 |F_{a1}|^{\frac{10}{3}} + n_2 t_2 |F_{a2}|^{\frac{10}{3}} + \dots + n_n t_n |F_{an}|^{\frac{10}{3}}}{n_1 t_1 + n_2 t_2 + \dots + n_n t_n} \right)^{\frac{3}{10}} \quad (17.5)$$

Symbol	Definition	Unit	Reference
$F_{a,avg}$	Average axial load	N	-
n_x	Output Speed	RPM	Figure 17-2
t_x	Time	s	Figure 17-2
F_{ax}	Axial load	N	Figure 17-2

$$N_{avg} = \frac{n_1 t_1 + n_2 t_2 + \dots + n_n t_n}{t_1 + t_2 + \dots + t_n} \quad (17.6)$$

Symbol	Definition	Unit	Reference
N_{avg}	Average output speed	RPM	-
n_x	Output Speed	RPM	Figure 17-2
t_x	Time	s	Figure 17-2




Figure 17-2 Load Pattern Diagram

17.2.2 Load Coefficient Calculation

The *radial load coefficient (X)* and *axial load coefficient (Y)* are critical factors used in the analysis of the lifespan of cross roller bearings. Their calculation methods are presented below.

$$F_{r,avg} + \frac{F_{a,avg}}{2 \times \frac{[F_{r,avg}(L_r+R) + F_{a,avg} \times L_a]}{d_p}} \quad (17.7)$$

Symbol	Definition	Unit	Reference
$F_{a,avg}$	Average axial load	N	Formula 17.5
$F_{r,avg}$	Average radial load	N	Formula 17.4
L_r	Radial Load Length	m	Figure 17-1
R	Offset	m	Table 17-3
L_a	Axial Load Length	m	Figure 17-1
d_p	Pitch circle diameter	m	Table 17-3

Table 17-2 Load Coefficient(X,Y) Calculation

Formula 17.7 Solution	X	Y
≤ 1.5	1	0.45
> 1.5	0.67	0.67

Table 17-3 Roller Bearing Specifications of Each eRob Model

Model	Pitch Circle Diameter (d_p)	Offset Length (R)	Basic Dynamic Load Rating (C)		Basic Static Load Rating (C_0)		Permissible Moment (M_c)	
	m	m	$\times 10^2 N$	kgf	$\times 10^2 N$	kgf	$N \cdot m$	kgf · m
eRob70F	0.0503	0.0111	29	296	43	438	37	3.8
eRob70	0.05	0.0217	58	590	86	880	74	7.6
eRob80F	0.061	0.0115	52	530	81	826	62	6.3
eRob80	0.06	0.0239	104	1060	163	1670	124	12.6
eRob90	0.07	0.0255	146	1490	220	2250	187	19.1
eRob110	0.085	0.0296	218	2230	358	3660	258	26.3
eRob142	0.111	0.0364	382	3900	654	6680	580	59.1
eRob170	0.133	0.044	433	4410	816	8330	849	86.6

(1) **Pitch Circle Diameter (d_p):**

The pitch circle diameter, which is the diameter of the circle passing through the center of the rolling elements (rollers) in the cross roller bearing.

(2) **Offset Length (R):**

The offset length refers to the distance between the centerline of the rollers and the pitch circle of the bearing (centerline of the rolling element’s contact points with the raceways).

(3) **Basic Dynamic Load Rating (C):**

AKA Catalog Load Rating or Basic Load Rating or Basic Dynamic Rated Load, is defined as the radial load that causes 10% of a group of bearings to fail at the rated life of 100 million revolutions.

(4) **Basic Static Load Rating (C_0):**

AKA Basic Static Rated Load, The static load applied at the central position of the contact area between the rotating element and the raceway, which is $4kN/mm^2$.

(5) **Permissible Moment Load (M_c):**

The maximum moment of force that can be applied to the output side bearing. Within this specified range, the bearing should be able to maintain its rated performance and operate reliably.

17.3 Static Safety Coefficient Calculation

Under standard operating conditions, the *basic static load rating* (C_0) is typically considered the permissible value for the static equivalent load. However, this permissible value may be adjusted based on specific application requirements and operating conditions. In such cases, the *static safety coefficient* (f_s) is determined using the following equation:

$$f_s = \frac{C_0}{P_0} \tag{17.8}$$

Symbol	Definition	Unit	Reference
f_s	Static Safety Coefficient	-	-
C_0	Basic Static Load Rating	N	Table 17-3
P_0	Static Equivalent Load	N	Formula 17.9

$$P_0 = F_{r,max} + \frac{2M_{max}}{d_p} + 0.44F_{a,max} \tag{17.9}$$

Symbol	Definition	Unit	Reference
P_0	Static Equivalent Load	N	-
$F_{r,max}$	Max. Radial Load	N	Formula 17.1
M_{max}	Max. Moment Load	Nm	Formula 17.1
d_p	Pitch circle diameter	m	Table 17-3
$F_{a,max}$	Max. Axial Load	N	Formula 17.1

Table 17-4 Static Safety Coefficient Chart

Operating condition of the roller bearing	f_s
When high rotational precision is required	≥ 3
When shock and vibration are expected	≥ 2
Under normal operating condition	≥ 1.5

EXAMPLE Consider the eRob70H module is subject to axial load only, and may experience shock and vibration, which means it is under the following conditions:

$$L_a = 0 \text{ m}, \quad L_r = 0 \text{ m}, \quad F_{r,max} = 0 \text{ N}, \quad F_{a,max} = 30 \text{ N}, \quad f_s = 2, \quad d_p = 0.0503 \text{ m}$$

SOLUTION Refer to [Table 17-3](#) for the permissible moment load:

$$R = 0.0217 \text{ m}, \quad M_c = 74 \text{ Nm}, \quad C_0 = 43 \times 10^2 \text{ N}$$

Substitute these values into [Formula 17.8](#):

$$2 = \frac{43 \times 10^2}{P_0}$$

$$P_0 = \frac{43 \times 10^2}{2}$$

$$P_0 = 2150 \text{ N}$$

Substitute these values into [Formula 17.9](#):

$$2150 = 0 + \frac{2M_{max}}{0.0503} + 0.44 \times 30$$

$$2136.8 = \frac{2M_{max}}{0.0503}$$

$$107.481 = 2M_{max}$$

$$M_{max} = 53.741 \text{ Nm}$$


The calculation demonstrates that $M_{\max}(53.741 \text{ Nm}) < M_c(74 \text{ Nm})$, confirming compliance with bending requirements.

17.4 Ratcheting Torque

When the rotary actuator is subjected to excess impact torque during operation, the engagement of the teeth between the circular spline and the flexspline may be put momentarily out of alignment instead of damaging the flexspline. This phenomenon is called “ratcheting”, and the torque is called “ratcheting torque” (see values in Table 17-5). Operating without fixing ratcheting will result in earlier abrasion of the teeth and shorter life of the wave generator bearing due to the effect of the grinding powder generated by ratcheting.

Table 17-5 Ratcheting Torque Values of Each Models (unit: Nm)

GR \ Model	eRob70F	eRob70	eRob80F	eRob80	eRob90	eRob110	eRob142	eRob170
50	88	88	150	150	220	450	980	1800
80	-	110	-	200	350	680	1400	2800
100	84	84	160	160	260	500	1000	2100
120	-	-	-	120	240	470	980	1900



(a) Correct Engagement of Teeth

(b) The Engagement of the Teeth is Out of Alignment

Figure 17-3 Strain Wave Gear Teeth Alignment Illustration

Figure 17-3a shows the correct engagement of teeth. When ratcheting happens, the teeth may not be correctly engaged and become out of alignment as shown in Figure 17-3b. Continue to operate in this condition will generate vibration and damage the flexspline.






Figure 17-4 Current Waveform When Ratcheting Happens

Taking eRob90H100I as an example, operating at a speed of 5242count/s when ratcheting (motor rotational speed is 1r/s at this moment) (when serious ratcheting is caused, operating the actuator with no-load may also result in alarm), using oscilloscope to collect the current waveform of the motor (as shown in [Figure 17-4](#), set motor current and motor corner as the “Signal” sources; sampling “Interval” is 1ms; sampling “Time” is 4s.), will result in a large current fluctuation. When serious ratcheting happens, operating the rotary actuator with load will generate alarm, such as excess current, motor struck protection, position error exceeded, speed error exceeded, and power temperature being too high etc. The rotary actuator can no longer be used after ratcheting.

Once a ratcheting happens one time, the teeth tips are worn as shown in [Figure 17-5a](#) and [Figure 17-5b](#) shows the normal teeth tips. Once ratcheting happens more than two times, the torque value will be lowered.



(a) The Tips of the Teeth are Worn



(b) The Normal Teeth Tips

Figure 17-5 Strain Wave Gear Teeth

Chapter 18 eRob Installation Requirements

18.1 Seam Allowance Requirement of Flange Connection

The seam allowance in load must be buckled on the designated position as shown in [Figure 18-1](#). The seam allowance length for specific actuator is shown in [Table18-1](#). The flange mating face is not allowed to have protrusions such as flash; pay attention to the orifice protrusions, flash etc., which can be caused by drilling easily. The design of flange must be equipped with a vacant space in $0.3 \text{ } \varnothing d$ depth. Rotary actuator output shaft cannot afford force within $\varnothing d$ range (as shown in [Figure 18-1](#)). The damage of rotary actuator caused by output shaft bearing forces within $\varnothing d$ range due to customers' improper flange design is not covered by the warranty.




Figure 18-1 Rotary Actuator Installation




Figure 18-2 Rotary Actuator Installation

Table 18-1 Seam Allowance Parameters

Model	D_{Output} (mm)	$D_{Circular\ spline}$ (mm)	$L_{Output\ shaft}$ (mm)	D (mm)	L (mm)	d (mm)	Seam Allowance Roundness	Seam Allowance Flatness
eRob70F	Ø48.6	Ø49 _{-0.016} ⁰	3	Ø49 ₀ ^{+0.016}	4.5	Ø38.3	0.01	0.01
eRob70H	Ø49.6	Ø50 _{-0.016} ⁰	4	Ø50 ₀ ^{+0.016}	6	Ø39	0.01	0.01
eRob80F	Ø58.5	Ø59 _{-0.019} ⁰	5	Ø59 ₀ ^{+0.019}	7	Ø46	0.01	0.01
eRob80H	Ø59.6	Ø60 _{-0.019} ⁰	5	Ø60 ₀ ^{+0.019}	7	Ø49	0.01	0.01
eRob90H	Ø69.6	Ø70 _{-0.019} ⁰	5	Ø70 ₀ ^{+0.019}	7	Ø56	0.01	0.01
eRob110H	Ø84.6	Ø85 _{-0.022} ⁰	5	Ø85 ₀ ^{+0.022}	7	Ø70	0.01	0.01
eRob142H	Ø109.6	Ø110 _{-0.022} ⁰	7	Ø110 ₀ ^{+0.022}	9	Ø91	0.01	0.01
eRob170H	Ø134.6	Ø135 _{-0.025} ⁰	7	Ø135 ₀ ^{+0.025}	10	Ø102	0.01	0.01

NOTE:

- (1) Fail to follow the installation requirement of the eRob output end connecting flange may cause the output shaft to deform, then the torque sensor cannot work properly even cause irreversible damage.
- (2) The output shaft length requirement is to ensure:
 - (1) the radial positioning accuracy of the output flange;
 - (2) the load moment is transmitted through the output flange seam allowance to the precision cross roller bearing that directly supports the external load.
- (3) The roundness and flatness of the customer’s load flange seam allowance should be as close as possible to the required values specified in Table18-1. Excessive roundness or flatness will lead to uneven force on the output end of the eRob, which will lead to abnormal noise or vibration of the eRob.
- (4) The seam allowance of the customer’s load flange must not be painted. Painting this surface may cause flatness deviation, resulting in uneven loading on the module output end. Consequently, the encoder disk mounted on the module output shaft may shift, leading to a positional offset in the output encoder readings after power-off and restart.

18.2 Screw Locking Method

Use diagonal method to tighten screws. The first step is to turn screws to the bottom without tightening it. The second step is to slightly tighten screws via the diagonal method. The third step is to use torque wrench to tighten screws via the diagonal method.

18.3 Screw Torque Standard

Refer to Table 18-2 for screw locking force.


Screw Strength Class: level 12.9

Table 18-2 Screw Locking Torque

Screw Model	M3	M4	M5	M6
Locking Torque	2 Nm	4 Nm	9 Nm	15 Nm
Note	The premise is that the material on the female thread side can withstand the screw locking torque.			

18.4 Common Improper Installation

- (1) Positioning deficiency, only have plane installation. As shown in [Figure 18-3a](#).
- (2) Insufficient positioning depth, fail of efficient positioning. As shown in [Figure 18-3b](#).



(a) Lack of Positioning Seam Allowance

(b) Insufficient Positioning Seam Allowance Depth

Figure 18-3 Common Improper Installation

- (3) Flange protrusion caused by drilling. As shown in [Figure 18-4](#).




Figure 18-4 Flange Protrusion

- (4) The flatness is out of tolerance due to poor processing. As shown in [Figure 18-5](#).




Figure 18-5 Insufficient Machining Flatness

- (5) The improper installation will affect the force of the module, as shown in [Figure 18-6](#): Since the module is equipped with precision cross roller bearing to directly support external loads, the improper installation method does not transmit the force of the output flange to the cross roller bearing, but to the bolts that fix the motor casing.




Figure 18-6 Improper Installation
(Fail to transmit the force of the output flange to the cross roller bearing)

If you need to lock the module from the fixed end of the motor casing, please refer to [Figure 18-7](#) and to ensure that the tightening torque of the bolts and nuts is sufficient (refer to [Table 18-2](#)), and both are locked simultaneously with the same torque but in different directions.




Figure 18-7 Insufficient Machining Flatness

Each eRob rotary actuator has undergone strict jitters and noise tests before delivery. Exceptions like jitters and noise will occur if the eRob cannot meet the installation requirements.

- (6) The installation of the eRob module does not require the addition of external bearings. As shown in [Figure 18-8](#), the eRob module is equipped with integrated cross-roller bearings that can withstand both radial and axial loads. The load-bearing capacity of the eRob module should be checked according to [Chapter 17](#). Adding external bearing support can lead to situations where the installation dimensions are exceeded, resulting in abnormal noises, vibrations, jitter, jamming, and bending of the eRob module.




Figure 18-8 No External Bearings Required for eRob Module Installation

Each eRob module undergoes rigorous jitter and noise testing before leaving the factory. If

it does not meet the installation requirements, it may exhibit abnormal jitters and noises.

18.5 Pre-Installation Cleaning Advisory

Ensure the mounting face is thoroughly cleaned before installation to prevent any interference caused by metal chips, thread glues, sealants, particles, or dust accumulation. Failure to achieve a clean mounting face may result in unreliable fits, leading to jitters and noise during operation.

Chapter 19 Firmware Version Upgrade

Definition rules of firmware version of rotary actuator are as shown in Figure 19-1.




Figure 19-1 Definition rules of firmware version of rotary actuators

For more information regarding the Firmware Versions, please visit our official website: en.zeroerr.cn/support/firmware-version

For more information regarding the Firmware Update Tool, i.e., the CAN_Update_Tool, please refer to our [CAN_Update_Tool User Manual](#)

Chapter 20 Restoring Factory Parameter Function

The operation steps of restoring factory parameters are as shown in [Figure 20-1](#).

- (1) Connect [eTuner](#) (refer to [YouTube Tutorial](#)) and then click “Parameter”, the “Upload and Download” window pops up.
- (2) Click “Reset parameters” and wait until the progress bar is completed. Click “Confirm” in the “Tips” window as shown in [Figure 20-1](#).
- (3) Power off and restart, reconnect in the “eTuner” software, confirm the parameters are restored. Then click “Save” to save the restored parameters.

Note:

- (1) The restoring factory parameter function can be used only when part of parameters or all the parameters are lost due to unexpected power failure during the process of saving parameters.
- (2) When applying restoring factory parameter function, please confirm that rotary actuators are equipped with the latest official version (firmware version number is X2040816X or the later firmware versions, and the eRob must be delivered after April 8, 2022). Actuators delivered before this date cannot support this function.
- (3) In the case of “[Note \(1\)](#)” but not meeting the conditions of “[Note \(2\)](#)”, please promptly contact our technical support engineers for confirmation.




Figure 20-1 Operation of Restoring Factory Parameters

Chapter 21 Safe Torque Off (STO)

Safe torque off (STO) function is used under the conditions of emergency stop and prevention of unexpected start-up. When STO signal is triggered, the motor power will be turned off and the brake will be enabled, but the drive power does not need to be disconnected.

Note:

- (1) More details for STO wiring figures, please refer to [Figure 6-12](#) STO terminal connection in [Section 6.5](#). The rotary actuator can support two STO branch circuits (STOA and STOB). When only one branch circuit is configured, connect STOA interface.



Figure 21-1 Wiring Figure

21.1 STO Function Configuration

As shown in [Figure 23-1](#), install a computer with [eTuner](#), connect CAN communication interface of rotary actuator via [eRob to PC Connector](#), connect 12P I/O wiring terminal and I/O signal interface, then supply proper power for rotary actuator.

21.1.1 One STO Branch Circuit Function Configuration

As shown in [Figure 21-2](#), connect [eTuner](#), enter control interface, select “0-None” in “Control Source”. Then enter “I/O Settings” interface to set STO function configuration (pay attention to check “Status Monitor” interface. Only when it displays “Disable”, can the function modification be allowed.)

Set DIn01 to “STOA”, set STO configuration to “2-One of STO”, click apply and save in sequence. Wait about 3 seconds, it will be prompted that the save demand is completed. Then STO one branch circuit configuration is completed.




Figure 21-2 One STO branch circuit function configuration steps

21.1.2 Two STO Branch Circuits Function Configuration

As shown in Figure 21-3, Connect eTuner, enter “Control Mode” and select “0-None” in “Control Source”. Then enter “I/O Settings” interface to set STO function configuration (pay attention to check status monitor interface. Only when it displays “Disable”, can the function modification be allowed.)

Set DIn01 to “STOA”, set DIn02 to “STOB”, set STO configuration to “3- Two of STO”, click apply and save in sequence. Wait about 3 seconds, it will be prompted that the save command is completed. Then STO two branch circuits configuration is completed.




Figure 21-3 Two STO branch circuits function configuration steps

Chapter 22 Virtual Torque Sensor(VTS)

(1) The transmission equation of SWG under ideal conditions:

$$\theta_{out} = \frac{\theta_{in}}{m_G} \quad (22.1)$$

Symbol	Definition	Unit
θ_{out}	Angle of flexspline output shaft. Measured by encoder for output shaft, and the resolution is 19 bit.	$^{\circ}$, rad
θ_{in}	Angle of wave generator input shaft. Measured by encoder for motor, and the resolution is 17 bit.	$^{\circ}$, rad
m_G	SWG gear ratio.	N/A

(2) The actual transmission equation of SWG:

$$\theta_{out} + E_{out} = \frac{\theta_{in}}{m_G} + E_{in} \quad (22.2)$$

Symbol	Definition
E_{in}	The transmission error of input shaft.
E_{out}	Error caused by circular spline elastic deformation.

The error value is so small that it can be ignored.

$$E_{in} = E_{FED} + E_{WGD} + E_{ITG} + E_M \quad (22.3)$$

Symbol	Definition
E_{FED}	Error caused by flexspline elastic deformation.
E_{WGD}	Error caused by wave generator deformation.
E_{ITG}	Error caused by input teeth gap.
E_M	Error caused by manufacture.

When compared with E_{FED} , E_{WGD} , and E_{ITG} , the E_M is very small and can be ignored.

Define variable $\Delta\theta$ (let $\Delta\theta = E_{in}$, represented by the object dictionary 0x2241) represents the total torsional angle of the SWG.

$$\Delta\theta = (\theta_{out} \times m_G) - \theta_{in} \quad (22.4)$$

Symbol	Definition	Unit
θ_{in}	Angle of wave generator input shaft. Measured by encoder for motor, and the resolution is 17 bit.	Resolution
θ_{out}	Angle of flexspline output shaft. Measured by encoder for output shaft, and the resolution is 19 bit.	Resolution
$\Delta\theta$	Calculated using Formula 22.4 , and the resolution is 17 bit.	Resolution

The sampling period of both encoders is 50 μ s, and both $\Delta\theta$ (0x2241) and calculated torque value (0x3B69) are calculated immediately after the encoder samples. Therefore, the bandwidth of $\Delta\theta$ and calculated torque value mainly depends on the communication cycle of EtherCAT or CANopen for 0x2241 and 0x3B69.

Table 22-1 Dual Encoder Difference

Index	0x2241	Object	Variation	Name	Dual Encoder Difference ($\Delta\theta$)
Sub-index	PDO Mapping	Read-write Operation	Data Format	Unit	Description
0x00	TxPDO	Read Only	INT32	Resolution	Mapped to the dual encoder difference on the motor side, the resolution is 17 bits. Taking eRob80H100 as an example, the relationship between $\Delta\theta$ dual encoder difference and load end torque at standstill is shown in Figure 22-1

Table 22-2 Calculated Torque Value

Index	0x3B69	Object	Variation	Name	Calculated Torque Value
Sub-index	PDO Mapping	Read-write Operation	Data Format	Unit	Description
0x00	TxPDO	Read Only	INT32	mNm	Calculated torque value based on the dual encoder scheme. Only for eRob with virtual torque sensor (model: eRobxxxxxxxx-xxx-18xT).

Note: Installation without obeying requirements of mounting flange in output flange (for details, refer to [Chapter 18](#)) may cause output shaft deformation and cause the torque sensor cannot properly work even cause an irreversible damage.

The correlation between the difference value 0x2241h and the torque value 0x3B69h of the dual encoder can be obtained by combining the characteristics of the rigidity and hysteresis curve of the SWG, as shown in [Figure 22-2](#).




Figure 22-1 Relationship Curve Between Dual Encoder Difference and Load End Torque at Standstill




Figure 22-2 Hysteresis and Rigidity Curve of The Strain Wave Gear

Reference: *HarmonicDrive General Catalog.pdf*

Table 22-3 Dual Encoder Difference and Load End Torque Relationship Test Data Sheet at Standstill

Load End Torque	Dual Encoder Difference (Avg.)	Load End Torque (Nm)	Dual Encoder Difference (Avg.)
0.000	-230	0.000	37
11.327	1583	-11.327	-1433
14.903	1935	-14.903	-1815
18.218	2305	-18.218	-2211
21.794	2629	-21.794	-2530
25.109	2935	-25.109	-2871
28.685	3240	-28.685	-3188
32.000	3490	-32.000	-3462
35.576	3756	-35.576	-3746
38.891	3977	-38.891	-4018
42.467	4220	-42.467	-4262
45.782	4439	-45.782	-4512
49.358	4680	-49.358	-4770
53.756	4888	-53.756	-5018
57.331	5109	-57.331	-5265
60.647	5299	-60.647	-5472
64.222	5512	-64.222	-5756
67.884	5716	-67.884	-5988
71.459	5931	-71.459	-6219
74.775	6137	-74.775	-6463
78.350	6353	-78.350	-6563
82.011	6556	-82.011	-6917
85.587	6766	-85.587	-7115
88.902	6955	-88.902	-7396
92.478	7165	-92.478	-7677
96.139	7357	-96.139	-7914
99.715	7565	-99.715	-8017
103.030	7773	-103.030	-8185
99.715	7620	-99.715	-8062
96.139	7620	-96.139	-7839
92.478	7244	-92.478	-7596
88.902	7086	-88.902	-7432
85.587	6926	-85.587	-7279
82.011	6766	-82.011	-7100
78.350	6481	-78.350	-6784
74.775	6314	-74.775	-6616
71.459	6115	-71.459	-6434
67.884	5945	-67.884	-6281
64.222	5602	-64.222	-5850
60.647	5439	-60.647	-5674
57.331	5254	-57.331	-5483
53.756	5092	-53.756	-5314
49.358	4747	-49.358	-4986
45.782	4566	-45.782	-4797
42.467	4337	-42.467	-4564
38.891	4141	-38.891	-4363
35.576	3801	-35.576	-4007
32.000	3595	-32.000	-3802
28.685	3324	-28.685	-3534
25.109	3097	-25.109	-3304
21.794	2671	-21.794	-2869
18.218	2392	-18.218	-2575
14.903	1985	-14.903	-2122
11.327	1678	-11.327	-1299

Chapter 23 Life of Rotary Actuator

The life of rotary actuator is determined by the lifetime of the SWG. Lifetime of the SWG depends on the life of wave generator bearing. It can be calculated by rotational speed and load torque just as with a general ball bearing lifetime calculation.

Table 23-1 Rotary Actuator Life

Series Name	Life	
	eRobxxF	eRobxxH
L_{10} (10% damage probability)	7,000 hr	10,000 hr
L_{50} (Average Lifetime)	35,000 hr	50,000 hr

Note: Life is based on rated rotational speed and rated torque from the ratings.

Calculation formula for life (L_h) by actual operation condition

$$L_h = L_n \times \left(\frac{T_r}{T_{avg}}\right)^3 \times \left(\frac{n_t}{n_{avg}}\right) \tag{23.1}$$

Symbol	Definition
L_h	Life measured in hours.
L_n	Life of L_{10} or L_{50} .
T_r	The Rated Torque Output by the eRob Module.
T_{avg}	Average Load Torque on the SWG Output Side.
n_t	Motor Rated Rotational Speed Used for Module Rated Torque Testing (2000RPM).
n_{avg}	Average SWG Input / Motor Output Rotational Speed.

Reference: *HarmonicDrive General Catalog.pdf*

Note: Use eRob series rotary actuator within the range of “Normal operation area”. Using it beyond “Normal operation area” may result in damaging eRob series rotary actuator earlier than usual. Lubricant life such as for abrasion on the tooth surface is not taken into consideration in the graph described above.






Figure 23-1 Relationship Between Strength and Lifetime of the Rotary Actuator



(a) Motion of the eRob is limited by motion configuration



(b) Motion parameter configuration

Figure 24-3 Motion Related Illustration

The user can reduce the external pulse sending frequency or configure a greater profile speed so that the target speed of eRob is less than the profile speed, thereby making the eRob operate at the target speed. The motion parameter configuration is as shown in [Figure 24-3b](#).

When using Pulse Direction control mode, the Output Shaft Actual Position can be determined via the CAN or RS485 communication interface:

(1) CAN Interface

The output shaft actual position can be determined by sending & receiving data messages via the CAN communication interface using CAN-custom communication protocol. For detailed instructions, please refer to the [eRunner User Manual Chapter 7](#). Take servo ID=1 as an example.

Table 24-2 CAN-Custom Messages for Reading Output Shaft Actual Position

COB-ID	Message	Description
641	00 02	Read output shaft actual position
5C1	00 15 8A 06 3E	Return output shaft actual position

(2) RS485 Interface

The output shaft actual position can be determined by sending & receiving data messages via the RS485 communication interface using Modbus communication protocol. For detailed instructions, please refer to the [eRob Modbus RTU User Manual](#)

Take servo ID=1 as an example.

Table 24-3 Modbus Messages for Reading Output Shaft Actual Position

Direction	Message	Comment
Send→	01 03 00 66 00 02 24 14	Read output shaft actual position
Receive←	01 03 04 00 15 8A 06 0C 95	Return output shaft actual position


Chapter 25 Output Characteristic

25.1 eRob Motor Current, Output Torque, Rotational Speed Curve

This plot highlights the eRob’s **motor current** draw in relation to the **output torque** and **rotational speed**. It demonstrates how the electrical demand varies as the actuator operates under different mechanical loads and speeds.

This plot provides valuable insights into the actuator’s electrical and mechanical performance under varying conditions.

NOTE: The motor current is the actual motor current. For details, please refer to [Table 25-3 Motor actual current \(0x6078\)](#).




(a) Plot

Motor Current / Output Torque / Rotational Speed	0 Nm	2.806 Nm	5.440 Nm	7.849 Nm	10.463 Nm
0.637 RPM	0.469 A (39 °C)	1.631 A (41 °C)	2.532 A (39 °C)	3.280 A (36 °C)	4.111 A (40 °C)
24 RPM	0.872 A (40 °C)	2.618 A (42 °C)	3.272 A (38 °C)	3.989 A (37 °C)	4.808 A (41 °C)
60 RPM	1.108 A (40 °C)	2.832 A (37 °C)	3.343 A (41 °C)	4.458 A (39 °C)	5.574 A (43 °C)

(b) Parameter

Figure 25-1 eRob70H50I Motor Current, Output Torque, Rotational Speed Curve




(a) Plot

Motor Current / Output Torque / Rotational Speed	0 Nm	2.826 Nm	5.440 Nm	7.849 Nm	12.922 Nm
0.637 RPM	1.049 A (37 °C)	1.402 A (36 °C)	1.745 A (36 °C)	2.069 A (36 °C)	2.797 A (36 °C)
15 RPM	1.370 A (40 °C)	1.821 A (39 °C)	2.146 A (38 °C)	2.515 A (39 °C)	3.096 A (41 °C)
30 RPM	1.562 A (39 °C)	1.947 A (36 °C)	2.500 A (35 °C)	2.854 A (35 °C)	3.475 A (38 °C)

(b) Parameter

Figure 25-2 eRob70H100I Motor Current, Output Torque, Rotational Speed Curve




(a) Plot

Motor Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	6.465 Nm	11.327 Nm	18.218 Nm	21.794 Nm
0.637 RPM	0.386 A (40 °C)	1.362 A (37 °C)	2.432 A (42 °C)	4.473 A (40 °C)	5.896 A (38 °C)
24 RPM	0.435 A (39 °C)	1.963 A (38 °C)	2.943 A (43 °C)	4.990 A (40 °C)	6.350 A (38 °C)
60 RPM	0.574 A (40 °C)	1.861 A (40 °C)	3.508 A (38 °C)	5.343 A (41 °C)	6.639 A (40 °C)

(b) Parameter

Figure 25-3 eRob80H50I Motor Current, Output Torque, Rotational Speed Curve




(a) Plot

Motor Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	5.604 Nm	21.475 Nm	29.409 Nm	39.398 Nm
1.5 RPM	0.424 A (38 °C)	1.362 A (41 °C)	3.454 A (38 °C)	4.473 A (40 °C)	5.896 A (41 °C)
12 RPM	0.944 A (40 °C)	2.075 A (38 °C)	3.824 A (42 °C)	4.887 A (42 °C)	6.215 A (40 °C)
30 RPM	0.868 A (41 °C)	1.861 A (39 °C)	4.062 A (44 °C)	5.343 A (42 °C)	6.639 A (40 °C)

(b) Parameter

Figure 25-4 eRob80H100I Motor Current, Output Torque, Rotational Speed Curve




(a) Plot

Motor Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	14.923 Nm	28.726 Nm	35.664 Nm	49.437 Nm
0.637 RPM	1.716 A (44 °C)	3.358 A (42 °C)	4.957 A (44 °C)	5.951 A (39 °C)	7.705 A (43 °C)
15 RPM	2.464 A (45 °C)	4.826 A (42 °C)	6.117 A (44 °C)	6.982 A (40 °C)	8.838 A (40 °C)
30 RPM	2.984 A (44 °C)	5.247 A (42 °C)	6.978 A (44 °C)	8.228 A (39 °C)	9.787 A (38 °C)

(b) Parameter

Figure 25-5 eRob90H100I Motor Current, Output Torque, Rotational Speed Curve




Motor Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	15.498 Nm	32.404 Nm	42.519 Nm	49.320 Nm
0.637 RPM	2.059 A (39 °C)	5.596 A (39 °C)	10.173 A (40 °C)	12.173 A (41 °C)	15.466 A (41 °C)
16.667 RPM	2.808 A (39 °C)	8.468 A (39 °C)	12.044 A (41 °C)	14.301 A (42 °C)	16.140 A (43 °C)
40 RPM	3.465 A (40 °C)	10.272 A (38 °C)	12.789 A (39 °C)	15.667 A (40 °C)	17.725 A (42 °C)

(a) Plot

(b) Parameter

Figure 25-6 eRob110H50I Motor Current, Output Torque, Rotational Speed Curve




Motor Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	25.609 Nm	42.519 Nm	66.222 Nm	83.142 Nm
0.637 RPM	1.716 A (35 °C)	4.862 A (35 °C)	7.001 A (37 °C)	10.501 A (40 °C)	13.033 A (39 °C)
10 RPM	3.243 A (38 °C)	6.279 A (36 °C)	8.385 A (38 °C)	11.548 A (39 °C)	13.890 A (41 °C)
20 RPM	3.347 A (41 °C)	6.688 A (36 °C)	8.790 A (38 °C)	11.791 A (40 °C)	14.653 A (41 °C)

(a) Plot

(b) Parameter

Figure 25-7 eRob110H100I Motor Current, Output Torque, Rotational Speed Curve




Motor Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	28.803 Nm	62.621 Nm	92.407 Nm	122.929 Nm
0.637 RPM	0.920 A (38 °C)	3.870 A (40 °C)	7.440 A (38 °C)	11.161 A (40 °C)	14.488 A (40 °C)
9.996 RPM	2.260 A (41 °C)	5.103 A (39 °C)	8.083 A (40 °C)	11.497 A (42 °C)	14.688 A (39 °C)
16.667 RPM	2.185 A (41 °C)	5.482 A (39 °C)	8.891 A (41 °C)	12.076 A (42 °C)	15.436 A (38 °C)

(a) Plot

(b) Parameter

Figure 25-8 eRob110H120I Motor Current, Output Torque, Rotational Speed Curve




(a) Plot

Motor Current / Output Torque	0 Nm	55.804 Nm	81.043 Nm	107.886 Nm	134.383 Nm
	Rotational Speed				
0.637 RPM	1.269 A (41 °C)	10.377 A (37 °C)	15.012 A (41 °C)	19.168 A (42 °C)	22.632 A (39 °C)
14.923 RPM	2.412 A (40 °C)	11.359 A (38 °C)	15.337 A (43 °C)	19.094 A (42 °C)	23.137 A (38 °C)
37.708 RPM	3.068 A (40 °C)	11.708 A (40 °C)	15.550 A (43 °C)	19.494 A (41 °C)	23.858 A (39 °C)

(b) Parameter

Figure 25-9 eRob142H50I Motor Current, Output Torque, Rotational Speed Curve



(a) Plot

Motor Current / Output Torque	0 Nm	63.059 Nm	187.186 Nm	256.616 Nm	315.476 Nm
	Rotational Speed				
0.637 RPM	1.908 A (36 °C)	7.531 A (41 °C)	17.455 A (42 °C)	24.139 A (40 °C)	30.545 A (42 °C)
9.996 RPM	3.399 A (38 °C)	9.018 A (40 °C)	18.606 A (40 °C)	24.374 A (43 °C)	28.779 A (40 °C)
16.667 RPM	3.734 A (38 °C)	9.755 A (40 °C)	19.410 A (39 °C)	24.971 A (41 °C)	29.825 A (40 °C)

(b) Parameter

Figure 25-10 eRob142H120I Motor Current, Output Torque, Rotational Speed Curve

The transfer function block diagram of motor current to output torque is as shown in [Figure 25-11](#).




Figure 25-11 Transfer function block diagram of motor current to output torque

Therefore, the motor needs efficient initial current to obtain the output torque.

Meanwhile, all friction torques have different dynamic friction and static friction.

The contact stress of sealing components is different at different temperature (The rigidity of rubber components changes).

Temperature also causes differences in the viscosity coefficient of the grease. Thermal expansion and contraction change in size, the higher the temperature, the lower the torque constant of the motor.

Inherent tolerances of the component sizes create different contact stresses at the seal. The viscosity coefficient is the same, the churning loss is nearly proportional to the square of the rotational speed.

Under the combined effect of the above factors, the transfer function of the SWG is not an ideal lossless model, and the relationship between the motor current and the output torque is also nonlinear.

On the whole, when the load is equal, the lower the temperature, the higher the speed, and the more current the motor needs.

25.2 eRob Rotary Actuator Motor Parameter

25.2.1 eRob Rotary Actuator Version Identification

As shown in [Figure 25-12](#).

25.2.2 Motor Parameter




Figure 25-12 eRob Rotary Actuator Version Identification

Table 25-1 eRob Rotary Actuator Motor Parameter Sheet

eRob Model	eRob70F	eRob70		eRob80F	eRob80		eRob90		eRob110		eRob142		eRob170		
eRob Ver.	V3_MC2	V3_MC1	V4_MC2	V4_MC2	V3_MC1	V4_MC2 V5_MC2	V3_MC1	V3_MC2	V3_MC1	V4_MC2	V6_MC2	V3_MC1	V4_MC2	V3_MC1	V3_MC2
No of poles	16	10	16	16	10	16	10	16	10	16	16	10	10	10	10
DC Link Voltage $U_{DC, motor}$ (DC Link)	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48
Rated Power $P_r, motor$ (W)	75	100	100	126	200	146	400	293	750	750	723	1000	1000	1000	1000
Rated Torque $T_r, motor$ (Nm)	0.24	0.32	0.32	0.4	0.64	0.45	1.27	0.85	2.4	2.39	2.3	4.78	4.78	4.78	4.78
Rated Speed $n_r, motor$ (RPM)	3000	3000	3000	3000	3000	3100	3000	3300	2000	3000	3000	2000	2000	2000	2000
Rated Current $I_r, motor$ (A)	1.91	3.3	2.55	3.6	6.9	3.4	11	6.7	20	18.6	18.9	26	22	26	22
Maximum Torque $T_m, motor$ (N·m)	0.72	0.96	0.96	1.2	1.92	1.25	3.81	2.55	7.2	7.17	6	15	14.3	15	14.3
Maximum Current $I_m, motor$ (A)	5.9	11	7.8	10.8	16.8	10.88	29	21.44	40	61	50	56	71	56	71
Resistance line-line $R_{L, motor}$ (Ω)($\pm 10\%$)	3.87	1.75	2	0.83	0.7	0.76	0.22	0.31	0.119	0.093	0.084	0.069	0.059	0.069	0.059
Inductance line-line $L_{L, motor}$ (mH)($\pm 20\%$)	2.54	2.5	2.46	1.362	1.362	1.32	0.6	0.86	0.2	0.2	0.16	0.37	0.38	0.37	0.38
Voltage Constant $K_e, motor$ (V/kRPM)($\pm 5\%$)	8	8.42	8.3	8.36	8.36	8.1	8.43	8.3	8.65	8	8.1	12.2	13.5	12.2	13.5
Torque Constant $K_t, motor$ (Nm/A _{rms})	0.134	0.075	0.132	0.126	0.101	0.134	0.088	0.14	0.112	0.132	0.134	0.153	0.22	0.153	0.22

NOTE: Please note that the motor parameters shown in [Table 25-1](#) are the factory parameters of the motor. The rated torque of the motor is not equal to the rated torque of the module. The rated torque value of the motor is suited for general robot model calculation use only. The rated torque of the eRob module is based on the rated torque of the SWG gearbox. These two values (eRob module rated torque & motor rated torque) are not equal, and for the rated torque of the eRob module, please refer to [Section 2.2](#).

Furthermore, it is important to understand that the rated current in the driver have no correlation with the rated torque of the module. The rated current in the driver is set based on the allowable heat capacity of the entire module.

The calculation formula of eRob torque constant (Nm/A) and output torque (Nm) :

- (1) eRob Torque Constant (usually 50%~70%. The efficiency curve is shown in [Figure 25-13](#))

$$K_{T, eRob} = K_{T, motor} \times m_G \times \eta_t \quad (25.1)$$

Symbol	Definition
$K_{T, eRob}$	The eRob module torque constant.
$K_{T, motor}$	The motor torque constant. (as shown in Table 25-1).
m_G	SWG Gear Ratio. (as shown in Table 2-1).
η_t	The efficiency of SWG transmission. (as shown in Figure 25-13).

- (2) eRob Output Torque (can be obtained by the object dictionary 0x6078. The description of the object dictionary 0x6078 is shown in [Table 25-2](#).)

$$T_{out} = K_{T, eRob} \times I_{a, motor} \quad (25.2)$$

Symbol	Definition
T_{out}	The eRob output torque.
$K_{T, eRob}$	The eRob module torque constant.
$I_{a, motor}$	The actual current input of motor.

Gear Ratio 50 / 80 / 100 / 120




Figure 25-13 Efficiency at Rated Torque

Table 25-2 Motor Actual Current (0x6078)

Index	0x6078	Object	Variation	Name	Motor Actual Current
Sub-index	PDO Mapping	Read-write Operation	Data Format	Unit	Description
0x00	TxPDO	Read Only	INT16	1‰	<p>The motor actual current is the value obtained by calculating the sum of momentary three-phase current value of the motor when sampling. It is displayed by the permillage of the rated current (obtained by object dictionary 0x6075).</p> $I_{motor\ actual} = 0x6078\ value \times \frac{(0x6075\ value)}{1000}$

Table 25-3 Rated Current (0x6075)

Index	0x6075	Object	Variation	Name	Rated Current
Sub-index	PDO Mapping	Read-write Operation	Data Format	Unit	Description
0x00	NO	Read/Write	UDINT32	mA	This object index corresponds to the “Continuous current” in “Safe Power” interface in eTuner .



25.3 eRob Motion Range

The following plots depict the operating range of the eRob rotary actuator, highlighting the relationship between **output torque** and **rotational speed**.

(1) Continuous Motion Range

The range allows continuous operation for the actuator. Marked in green.



- (2) **Motion Range During Acceleration & Deceleration (Acc. & Dec. Motion Range)**
 This range represents the torque and speed at which the actuator can operate momentarily. It is typically used for instantaneous operations such as acceleration and deceleration. Marked in orange.



(a) eRob70F50I Operating Range

(b) eRob70F80I Operating Range

Figure 25-14 Comparison of Operating Ranges for eRob70F50I and eRob70F80I.




(a) eRob70F100I Operating Range


(b) eRob70H50I(T) Operating Range

Figure 25-15 Comparison of Operating Ranges for eRob70F100I and eRob70H50I(T).

eRob70H80I(T) Operating Range




eRob70H100I(T) Operating Range




(a) eRob70H80I(T) Operating Range
 (b) eRob70H100I(T) Operating Range
 Figure 25-16 Comparison of Operating Ranges for eRob70H80I(T) and eRob70H100I(T).

eRob70H120I(T) Operating Range




eRob80H50I(T) Operating Range




(a) eRob70H120I(T) Operating Range
 (b) eRob80H50I(T) Operating Range
 Figure 25-17 Comparison of Operating Ranges for eRob70H120I(T) and eRob80H50I(T).

eRob80H80I(T) Operating Range




eRob80H100I(T) Operating Range




(a) eRob80H80I(T) Operating Range
 (b) eRob80H100I(T) Operating Range
 Figure 25-18 Comparison of Operating Ranges for eRob80H80I(T) and eRob80H100I(T).

eRob80H120I(T) Operating Range



(a) eRob80H120I(T) Operating Range


eRob90H50I(T) Operating Range



(b) eRob90H50I(T) Operating Range


Figure 25-19 Comparison of Operating Ranges for eRob80H120I(T) and eRob90H50I(T).

eRob90H80I(T) Operating Range



(a) eRob90H80I(T) Operating Range


eRob90H100I(T) Operating Range



(b) eRob90H100I(T) Operating Range


Figure 25-20 Comparison of Operating Ranges for eRob90H80I(T) and eRob90H100I(T).

eRob90H120I(T) Operating Range



(a) eRob90H120I(T) Operating Range


eRob110H50I(T) Operating Range



(b) eRob110H50I(T) Operating Range


Figure 25-21 Comparison of Operating Ranges for eRob90H120I(T) and eRob110H50I(T).

eRob110H80I(T) Operating Range



(a) eRob110H80I(T) Operating Range


eRob110H100I(T) Operating Range



(b) eRob110H100I(T) Operating Range


Figure 25-22 Comparison of Operating Ranges for eRob110H80I(T) and eRob110H100I(T).

eRob110H120I(T) Operating Range



(a) eRob110H120I(T) Operating Range


eRob110H160I(T) Operating Range



(b) eRob110H160I(T) Operating Range


Figure 25-23 Comparison of Operating Ranges for eRob110H120I(T) and eRob110H160I(T).

eRob142H50I(T) Operating Range



(a) eRob142H50I(T) Operating Range


eRob142H80I(T) Operating Range



(b) eRob142H80I(T) Operating Range


Figure 25-24 Comparison of Operating Ranges for eRob142H50I(T) and eRob142H80I(T).

eRob142H100I(T) Operating Range



(a) eRob142H100I(T) Operating Range


eRob142H120I(T) Operating Range



(b) eRob142H120I(T) Operating Range


Figure 25-25 Comparison of Operating Ranges for eRob142H100I(T) and eRob142H120I(T).

eRob142H160I(T) Operating Range



(a) eRob142H160I(T) Operating Range


eRob170H50I Operating Range



(b) eRob170H50I Operating Range


Figure 25-26 Comparison of Operating Ranges for eRob142H160I(T) and eRob170H50I.

eRob170H80I Operating Range





(a) eRob170H80I Operating Range

eRob170H100I Operating Range



(b) eRob170H100I Operating Range

Figure 25-27 Comparison of Operating Ranges for eRob170H80I and eRob170H100I.



(a) eRob170H120I Operating Range


(b) eRob170H160I Operating Range

Figure 25-28 Comparison of Operating Ranges for eRob170H120I and eRob170H160I.

25.4 eRob Bus Current, Output Torque, Rotational Speed Curves

These plots highlights the eRob' s **bus current** in relation to the **output torque** and **rotational speed**. It demonstrates how the electrical input varies as the actuator operates under different mechanical loads and speeds.

This plot provides valuable insights into the actuator' s efficiency and performance under varying electrical and mechanical conditions.




(a) Plot

Bus Current / Output Torque / Rotational Speed	Output Torque			
	0 Nm	2.415 Nm	4.466 Nm	6.617 Nm
0 RPM	0.11 A (39 °C)	0.23 A (41 °C)	0.32 A (39 °C)	0.42 A (38 °C)
24 RPM	0.50 A (40 °C)	1.10 A (42 °C)	1.54 A (38 °C)	2.00 A (37 °C)
60 RPM	1.40 A (40 °C)	1.90 A (37 °C)	2.62 A (41 °C)	3.52 A (39 °C)

(b) Parameter

Figure 25-29 eRob70H50I Bus Current, Output Torque, Rotational Speed Curve




(a) Plot

Bus Current / Output Torque / Rotational Speed	Output Torque				
	0 Nm	13.539 Nm	21.475 Nm	29.409 Nm	39.398 Nm
0 RPM	0.17 A (38 °C)	0.28 A (41 °C)	0.32 A (38 °C)	0.40 A (40 °C)	0.84 A (41 °C)
18 RPM	0.64 A (40 °C)	1.60 A (38 °C)	2.16 A (42 °C)	2.56 A (42 °C)	2.96 A (40 °C)
30 RPM	1.06 A (41 °C)	2.58 A (39 °C)	3.44 A (44 °C)	4.40 A (42 °C)	5.92 A (40 °C)

(b) Parameter

Figure 25-30 eRob80H100I Bus Current, Output Torque, Rotational Speed Curve




(a) Plot

Bus Current / Output Torque / Rotational Speed	Output Torque (Nm)				
	0	28.803	62.621	92.407	122.929
0 RPM	0.44 A (35 °C)	0.46 A (35 °C)	0.50 A (37 °C)	0.68 A (40 °C)	0.76 A (39 °C)
6.664 RPM	0.88 A (38 °C)	1.76 A (36 °C)	2.36 A (38 °C)	3.24 A (39 °C)	4.32 A (41 °C)
16.667 RPM	2.24 A (41 °C)	3.84 A (36 °C)	5.60 A (38 °C)	7.92 A (40 °C)	10.40 A (41 °C)

(b) Parameter

Figure 25-31 eRob110H120I Bus Current, Output Torque, Rotational Speed Curve




(a) Plot

Bus Current / Output Torque / Rotational Speed	Output Torque (Nm)				
	0	55.804	107.886	134.383	155.084
0 RPM	0.32 A (41 °C)	0.38 A (37 °C)	0.64 A (41 °C)	0.72 A (42 °C)	1.00 A (39 °C)
14.923 RPM	1.26 A (40 °C)	3.96 A (38 °C)	6.32 A (43 °C)	7.76 A (42 °C)	9.20 A (38 °C)
37.308 RPM	3.20 A (40 °C)	8.88 A (40 °C)	15.20 A (43 °C)	18.00 A (41 °C)	20.80 A (39 °C)

(b) Parameter

Figure 25-32 eRob142H50I Bus Current, Output Torque, Rotational Speed Curve



(a) Plot

Bus Current / Output Torque / Rotational Speed	Output Torque (Nm)				
	0	63.059	187.186	256.616	315.476
0 RPM	0.24 A (36 °C)	0.40 A (41 °C)	0.58 A (42 °C)	0.72 A (40 °C)	1.00 A (42 °C)
6.664 RPM	1.18 A (38 °C)	2.60 A (40 °C)	5.92 A (40 °C)	7.84 A (43 °C)	9.40 A (40 °C)
16.667 RPM	3.52 A (38 °C)	6.96 A (40 °C)	14.20 A (39 °C)	18.20 A (41 °C)	21.60 A (40 °C)

(b) Parameter

Figure 25-33 eRob142H120I Bus Current, Output Torque, Rotational Speed Curve

Chapter 26 Troubleshooting Instruction

Table 26-1 Troubleshooting and Solutions

Problem Classification	Alarm Prompt or Phenomenon	Possible Causes	Solutions
CAN Communication Abnormality	RUN LED indicator does not light up	<ol style="list-style-type: none"> (1) Incorrect power supply used. (2) Excessive voltage at the eRob's 48V power input, causing hardware failure. 	<ol style="list-style-type: none"> (1) Use a 48VDC power supply and pay attention to the polarity. (2) It is recommended to use our proprietary ePower power supply.
	RUN LED indicator is normal, but clicking the "Connection Test" button in the PC prompts: please check if the driver is powered on.	<ol style="list-style-type: none"> (1) The CAN interface of the eRob is not properly connected with the USBCAN "eRob to PC Connector". (2) Strong current is fed into the CAN interface, causing partial components of the CAN interface to burn out and communication to be interrupted. 	<ol style="list-style-type: none"> (1) Check the CAN wiring order to ensure a good connection. (2) Check the resistance of the CAN interface.
	The PC connection test recognizes fewer CAN IDs than the actual number of connections.	<ol style="list-style-type: none"> (1) There are slave devices on the CAN bus with the same CAN ID. 	<ol style="list-style-type: none"> (1) Connect each axis separately, reset the CAN IDs to ensure unique IDs.
	After connecting to the PC, the data displayed on the status monitoring interface fluctuates abnormally.	<ol style="list-style-type: none"> (1) There are slave devices on the CAN bus with the same CAN ID. (2) The wiring of the eRob's CAN port does not match the wiring of the USBCAN "eRob to PC Connector"'s port. 	<ol style="list-style-type: none"> (1) Connect each axis separately, reset the CAN IDs to ensure unique IDs. (2) Check the wiring of the eRob's CAN port with the USBCAN "eRob to PC Connector" to ensure a one-to-one correspondence.
EtherCAT Communication Abnormality	<ol style="list-style-type: none"> (1) Ethernet port indicator does not light up (2) Ethernet port indicator flashes for a while and then stops flashing. 	<ol style="list-style-type: none"> (1) Poor wiring of the EtherCAT bus; (2) Hardware failure of the eRob's PCB. 	<ol style="list-style-type: none"> (1) Check the wiring order and connectivity of the network cable to ensure a good connection.

26.1 Abnormal CAN Communication

26.1.1 "Check whether the drive is powered on" window pops up when click "connect" for test in the host computer

According to the following steps to check when the host computer cannot be connected as shown in [Table 26-1](#).

(1) Check "Run LED" indicator status of eRob rotary actuator.

When the eRob runs normally, the “Run LED” indicator is breathing and flashing. If the operation status is abnormal, the CAN communication cannot be connected.

- (2) **Check the voltage and the wiring of the power supply when “Run LED” indicator status is abnormal.**
 - (1) Check the positive and negative wiring sequence of the power supply, please refer to [Section 6.1](#).
 - (2) The voltage of power supply is DC24V~48V when the eRob works properly (For the permissible minimum input voltage, please refer to [Section 3.3](#). Use a multi-meter to measure the voltage, check whether the voltage is within the voltage range.
 - (3) Power off the power. Then connect the oscilloscope to measure waveform outputted by voltage at the moment of powering on. Check whether there is overvoltage phenomenon (>60V). Please refer to [Section 3.2](#).
- (3) **“Check whether the drive is powered on” window pops up when click “connect” for test in the host computer when “Run LED” indicator status is abnormal, check CAN wiring.**
 - (1) Power off the eRob. Check the wiring between CAN interface and “eRob to PC Connector” of the eRob, please refer to [Chapter 13](#). Make sure that the crimp terminals of the “eRob to PC Connector” and the CAN wire cores are connected effectively, the wiring sequence is correct, and the wires are conductive.
 - (2) Unplug and plug the USB wires. Make sure the effective connection between USB wires, USBCAN “eRob to PC Connector” and computer USB interface.
 - (3) Power off and restart the PC, click “Connect” for test. Check whether the PC identifies CANID normally.
- (4) **If the host computer still reminds that “Check the driver is powered on” , power off the rotary actuator and use a multimeter to measure the CAN interface resistance value of rotary actuator.**

The normal resistance measurement value:

- CAN_GND to CAN_L is 61kΩ~65kΩ;
- CAN_GND to CAN_H is 61kΩ~65kΩ;
- CAN_L to CAN_H is 2kΩ.

If the resistance value is abnormal, please confirm whether the CAN wire is plugged or unplugged when powering on during operation. Plugging or unplugging CAN wire when it is powered will easily damage to CAN interface.




Figure 26-1 CANID modification steps

26.1.2 The number of CANID identified by the host computer connection test is less than the actual CANID number of connection

- (1) Check the wiring between the eRob CAN interface and the [eRob to PC Connector](#), and the wiring of the CAN interface between the eRob rotary actuators (please refer to [Chapter 14](#)). Make sure the wire correspondence is in sequence and the wires are conductive.
- (2) Power off the eRob, and use the [eRob to PC Connector](#) to connect each eRob respectively. Then power on the eRob, connect to the host computer, and open the “Connection Settings” interface. Reset CANID (The steps are shown in [Figure 26-1](#)) to make sure the ID of each rotary actuator is unique.
- (3) Power off the eRob, and re-cascade the CAN bus networking (refer to [Section 6.2](#)). Then power the eRob and open the connection interface in the host computer to reconnect the test

26.1.3 The data displayed on “Status Monitor” interface jumps abnormally when the host computer is connected.

- (1) Check the wiring between the CAN interface of the eRob and the [eRob to PC Connector](#), and the wiring of the CAN interface between eRob rotary actuators (please refer to [Chapter 13](#) and [Section 6.2](#)). Make sure the wire correspondence is in sequence and the wires are conductive.
- (2) Power off the eRob, and use the [eRob to PC Connector](#) connect each eRob respectively. Then power the eRob, connect to the host computer and open the “Connection Settings” interface. Reset CANID (The steps are as shown in [Figure 26-1](#)) to make sure the ID of each rotary actuator is unique.
- (3) Power off the rotary actuator, and re-cascade the CAN bus networking (refer to [Section 6.2](#)). Then power the eRob and open the “Connection Setting” interface in the host computer to reconnect the test.

26.2 Abnormal EtherCAT Communication

- (1) Please provide the brand and model of the EtherCAT master controller you are using, so that our technical support engineer can confirm if it is within the compatible range.
- (2) Check the EtherCAT master controller and ensure it is functioning properly.
- (3) Check the status of the “Run LED” indicator on the eRob module.
When the eRob is operating normally, the “Run LED” indicator should be in a breathing flashing state. If the indicator is not in the expected state, it may indicate a problem with the EtherCAT communication connection. Please refer to [Section 5.1](#) for more details.
- (4) If the status of the “Run LED” indicator is abnormal, check the power supply voltage and wiring:
 - (1) Verify the correct polarity of the power supply connections. Refer to the [Section 6.1](#) for guidance.
 - (2) Make sure the eRob is powered within the range of DC24V~48V (refer to [Section 3.3](#)). Use a multimeter to measure the output voltage of the power supply and ensure it falls within this range.
 - (3) Disconnect the power supply and use a physical oscilloscope to measure the voltage output waveform when the power switch is turned on. Confirm if there is any over-voltage impact (above 60V) as described in [Section 3.2](#).
- (5) If the power supply is normal and the “Run LED” is flashing correctly after power-up, but the “ECAT In LED” or “ECAT Out LED” is not lit, further check the EtherCAT wiring:
 - (1) Verify the wiring order of the EtherCAT communication cable. Refer to the [Section 6.3](#) and use a multimeter to confirm the connectivity. Ensure the wiring order is correct, and the cables are securely fixed without any looseness.
 - (2) Refer to [Section 5.1](#) reconfirm the indicator LED status of the module. If the EtherCAT indicator LED is not lit, check for any loose connections on the module’s EtherCAT interface.
- (6) If all the above checks are normal, perform a complete power cycle by turning off the entire system, then power on the eRob module first and the controller second. Wait for the controller to finish initializing before confirming the communication connection.
Refer to [eRob CANopen and EtherCAT User Manual Section 5.1](#) for the operation sequence from power-on to servo enable.
- (7) Perform a cross-validation test by replacing the EtherCAT communication cable from a normal eRob module to the malfunction eRob module, then follow step 6 to confirm if the EtherCAT communication is restored to normal.

26.3 Motor Stalling Error

For the reasons and handling instructions related to motor stalling error, please refer to [Section 7.2.10](#) of the [eRob CANopen and EtherCAT User Manual](#). You can follow the steps below for troubleshooting:

- (1) Confirm whether the load torque of the connected output shaft of the eRob module that triggered the error exceeds the maximum permissible value specified in [Section 25.1](#). Please avoid exceeding this maximum value.
- (2) Check for any interference between the connected part of the eRob module’s output shaft and the external components, and eliminate any potential external interference.
- (3) Use the self-check function in the [eTuner](#) PC software to perform self-diagnostic tests and check if the module parameters and motion status are normal.

Note: Ensure that the module is in an unloaded state during the self-diagnostic test. If the mod-

ule is not unloaded, only retrieve the module information without conducting the full test. If the error is displayed on the status monitoring interface of the eTuner software, clear the error by clicking the enable button on the motion interface, then click the motor stop button on the main interface before performing the self-diagnostic test. Refer to our official YouTube video: "Self Test Function of eTuner" for detailed instructions on using the self-check function. After the test, check the test data (stored in folder path: eTuner_Vxx.xx\Self_check_report), which can assist in analysis.

- (4) Provide separate DC48V power supply to the eRob module. With the eRob in an unloaded and stationary state, enter the motor settings interface of the eTuner software and click the release brake button (refer to [Section 7.3](#) for detailed steps). Check whether the power output current exceeds the normal value after 3 seconds (refer to [Table 7.4](#)).
- (5) If all the above checks are normal and the motor stalling error still persists, please contact our technical support for remote confirmation.

26.4 The Velocity Error Exceeds the Limit Value (Error HEX:0x8400, DEC:33792)

The reasons and handling instructions for the "Velocity Error Exceeds the Limit Value" can be found in the [eRob CANopen and EtherCAT User Manual Section 7.2.19. 0x8400\(33792\): Velocity Error Exceeds the Limit Value](#). Please refer to this manual for detailed information. You can follow the steps below for troubleshooting:

- (1) Please verify whether the load torque of the eRob module's output shaft connection exceeds the "Permissible Maximum Torque with Average Load" specified in [Section 2.2](#). It is important not to exceed this maximum value during usage.
- (2) Check for any interference between the output shaft connection of the eRob module and the external components (load). Use a feeler gauge to ensure that the installation clearance of the module's output end is within the normal range and eliminate any potential external interference.
- (3) Confirm whether the speed and acceleration of the target instruction trajectory planned by the main station controller exceed the maximum speed and acceleration specified in [Table 12-1](#). It is crucial not to exceed this maximum value during usage.
- (4) Please verify if the "Max Motor Speed" set in the eTuner software "Safe Speed" interface is too low. If the "Max Motor Speed" setting is lower than the speed sent via the master controller, it can result in Velocity Error Exceeds the Limit Value.
- (5) Utilize the "Self-Test" function in the eTuner software to perform self-diagnostic tests and ensure that the module parameters and motion status are normal.

Note: Ensure that the module is in an unloaded state during the self-test. If the module is not unloaded, do not initiate full test, only retrieve the module information without conducting the full test. If an error is displayed in the "Monitor" interface of the eTuner software, clear the error by clicking the "Enable" button in the "Motion" interface, then click the "Motor Stop" button in the main interface before proceeding with the self-diagnostic test.

The instruction to utilize the self-test function of the eTuner, please refer to the [YouTube Tutorial Video](#).

The test result will be saved to file path: eTuner_Vxx.xx\Self_check_report, these data can assist the analysis process.

- (6) Open the "Fault diagnosis" menu in eTuner; replicate the fault and data collection will be triggered. The oscilloscope will automatically collect relevant data (including target position 0x607A, actual velocity 0x606C, motor current, etc.) and plot the curve. You can save the curve and send it to our technical support for further analysis.

- (7) If all the above checks are normal and the velocity error still exceeds the limit value, please contact our [technical support](#) for remote confirmation.

26.5 Position Feedback Value Misalignment After Power Cycle

1. For Single-turn eRobs (Model eRobxxxxxxxx-xxS-18xx), Follow These Steps:

- (1) Confirm the Position Feedback Value:
 - Verify if the position feedback value of the eRob's operational travel range exceeds the single-turn position range limit (0~524287).
 - Ensure that the eRob travel does not exceed one turn and that the position feedback value within the operational travel range does not cross the boundary positions (0 and 524287) of the single-turn encoder.
 - For related precautions using single-turn eRobs, refer to [Section 9.3](#).
- (2) Adjust the Installation Position:
 - If the eRob operational travel range does not exceed one turn but the position feedback value crosses the boundary position (0 or 524287), re-adjust the installation orientation of the eRob module. Alternatively, recalibrate the zero position using the method described in [Section 9.5.1](#).

2. For Multi-turn eRobs (Model eRobxxxxxxxx-xxM-18xx), Follow These Steps:

- (1) Power OFF the eRob, then connect the eRob to the “eRob to PC Connector (formally known as debugger)” (refer to [Chapter 13](#)).
- (2) Power ON the eRob again, connect to the eTuner software to check the status monitoring interface and historical error logs for any alarm information by clicking the “Monitor” button in the main menu.
- (3) Check for Alarm Information:
 - If there is no alarm information, first check if the alarm information has been cleared by the master controller (i.e., the master controller cleared the error by writing 0x80 to control word 0x6040).
- (4) For Error Code 0x7314:
 - If the error code is 0x7314, refer to [Section 9.4](#) to perform the reset operation of the load encoder and confirm the zero position.
- (5) For Error Code 0x730F:
 - If the error code is 0x730F, further confirm the following:
 - a. Check the Installation of the Multi-Revolution Count Battery:
Ensure the Multi-Revolution Count Battery provided with the eRob is installed (do not modify the original battery wiring). Then, refer to [Section 9.4](#) to perform the reset operation of the load encoder and confirm the zero position.
 - b. Further Battery Check:
If the Multi-Revolution Count Battery is installed and the reset operation has been performed, but after power cycling the error 0x730F still occurs, remove the battery, check for any damage, deformation, or loose/damaged connectors. Use a multimeter to measure if the battery voltage is too low (<3.05V).
 - i Replace the Battery if Voltage is Abnormal:
If the battery voltage is abnormal (<3.05V), replace it with a new one. Then, refer to [Section 9.4](#) to perform the reset operation of the load encoder and confirm the zero position.
 - ii Check the Resistance of the Multi-turn Battery Interface:

If the battery voltage is normal ($\geq 3.05\text{V}$), use a multimeter to measure the resistance between the two pins of the eRob multi-turn battery interface (note that this measurement should be taken when the eRob is POWERED OFF). The normal resistance value should be $>16\text{M}\Omega$. If the resistance is abnormal, contact our [technical support](#) for remote confirmation.

NOTE: The eRob mechanical zero-point calibration function is supported by firmware version X3071220X or above.

26.6 Abnormal RS485 (Modbus) Communication

1. Provide the Brand and Model of the Modbus Master Controller to Our Technical Support for Confirmation:
Please supply the brand and model of the Modbus master controller being used for our [technical support](#) to verify.
2. Check the RUN_LED Indicator Status:
When the eRob is operating normally, the RUN_LED indicator should be in a breathing flash state. If the status is abnormal, RS485 (Modbus) communication cannot connect.
3. If the RUN_LED Indicator Status is Abnormal, Check the Power Supply Voltage and Wiring:
 - (1) Check the Polarity of the Power Supply Wiring:
Ensure the correct polarity of the power supply wiring according to [Section 6.1](#).
 - (2) Verify the Power Supply Voltage:
The operating power supply voltage for the eRob drive should be DC 24V~48V (see [Section 3.3](#) for the permissible minimum input voltage value). Use a multimeter to measure if the output voltage of the power supply is within this range.
 - (3) Check for Overvoltage Surges:
Power off the supply, connect a physical oscilloscope, and measure the voltage output waveform at the moment the power switch is turned on to confirm if there are overvoltage surges ($>60\text{V}$). Refer to [Section 3.2](#).
4. If the Power Supply is Normal and the RUN_LED Indicator Flashes Normally After Powering On, Further Confirm the Following:
 - (1) Verify the RS485 Communication Cable Wiring Order:
Refer to [Section 6.4](#). Use a multimeter to ensure continuity, check for loose, damaged, deformed, or broken connectors, and ensure the wiring order is correct and secure.
 - (2) Check the RS485 Communication Interface on the eRob:
Ensure the RS485 communication interface on the eRob is not loose or damaged.
5. Check the Communication Parameter Configuration:
Verify the communication parameter configurations for both the eRob and the Modbus master serial port. Refer to [Chapter 3 in the "eRob Modbus-RTU Communication Application Manual"](#).
6. Verify the Communication Commands:
Ensure that the commands sent by the Modbus master comply with the protocol format specified in [Chapter 1 in the "eRob Modbus-RTU Communication Application Manual"](#). Control commands can be referenced from [Chapter 5 in the "eRob Modbus-RTU Communication Application Manual"](#).
7. If All the Above Checks are Normal, Proceed with the Following Steps:
Power off the entire system, then power on the eRob first, followed by the Modbus master controller. After the controller initialization is complete, check the communication connection status. Refer to [Section 5.1 in the "eRob CANopen and EtherCAT User Manual"](#) for

the power-on-to-servo-enable operation sequence.

8. If Modbus Communication Still Cannot Connect, Measure the RS485 Interface Resistance on the eRob:

Ensure the eRob is powered off and no cables are connected during the measurement. Use a multimeter to measure the resistance, the normal resistance value:

- RS485-A to RS485-B is $0.9K\Omega\sim 1.1K\Omega$;
- RS485-A to GND is $1.8K\Omega\sim 2K\Omega$;
- RS485-B to GND is $0.9K\Omega\sim 1.1K\Omega$.

If the resistance values are abnormal, confirm whether the RS485 communication cable was hot-plugged during use, as hot-plugging (cable manipulation while power on) can easily damage the RS485 interface.

Chapter 27 About Rigidity

27.1 Rigidity

Fixing the input side (wave generator) and applying torque to the output side (flexspline) generates torsion almost proportional to the torque on the output side.

Figure 27-1a shows the torsional angle quantity on the output side when the torque applied on the output side starts from 0, increases up to $+T_0$ and decreases down to $-T_0$. This is called the “Torque-torsional angle diagram”, which normally draws a loop of 0—A—B—A'—B'—A. The slope described in the “Torque-torsional angle diagram” is represented as the spring constant for the rigidity of eRob rotary actuators (unit:Nm/rad).

As shown in Figure 27-1b, this “Torque-torsional angle diagram” is divided into 3 partitions, and the spring constants in the area are represented as K_1 , K_2 and K_3 .

K_1 — The spring constant when the torque changes from 0 to T_1 .

K_2 — The spring constant when the torque changes from T_1 to T_2 .

K_3 — The spring constant when the torque changes from T_2 to T_3 .




Figure 27-1 Diagrams

References: *Harmonic Drive General catalog*.

Table 27-1 Partitioning of Spring Constant

Item		Model	eRob70F	eRob70	eRob80F	eRob80	eRob90	eRob110	eRob142	eRob170	
T_1		Nm	2	2	3.9	3.9	7	14	29	54	
		kgfm	0.2	0.2	0.4	0.4	0.7	1.4	3	5.5	
T_2		Nm	6.9	6.9	12	12	25	48	108	196	
		kgfm	0.7	0.7	1.2	1.2	2.5	4.9	11	20	
GR 50	K_1	$\times 10^4$ Nm/rad	0.29	0.34	0.67	0.81	1.3	2.5	5.4	10	
		kgfm/arcmin	0.085	0.1	0.2	0.24	0.38	0.74	1.6	3	
	K_2	$\times 10^4$ Nm/rad	0.37	0.47	0.88	1.1	1.8	3.4	7.8	14	
		kgfm/arcmin	0.11	0.14	0.26	0.32	0.52	1	2.3	4.2	
	K_3	$\times 10^4$ Nm/rad	0.47	0.57	1.2	1.3	2.3	4.4	9.8	18	
		kgfm/arcmin	0.14	0.17	0.34	0.4	0.67	1.3	2.9	5.3	
	θ_1	$\times 10^{-4}$ rad	6.9	5.8	5.8	4.9	5.2	5.5	5.5	5.2	
		arcmin	2.4	2	2	1.7	1.8	1.9	1.9	1.8	
	θ_2	$\times 10^{-4}$ rad	19	16	14	12	15.4	15.7	15.7	15.4	
		arcmin	6.4	5.6	4.6	4.2	5.3	5.4	5.4	5.3	
	GR >80	K_1	$\times 10^4$ Nm/rad	0.4	0.47	0.84	1	1.6	3.1	6.7	13
			kgfm/arcmin	0.12	0.14	0.25	0.3	0.47	0.92	2	3.8
K_2		$\times 10^4$ Nm/rad	0.44	0.61	0.94	1.4	2.5	5	11	20	
		kgfm/arcmin	0.13	0.18	0.28	0.4	0.75	1.5	3.2	6	
K_3		$\times 10^4$ Nm/rad	0.61	0.71	1.3	1.6	2.9	5.7	12	23	
		kgfm/arcmin	0.18	0.21	0.39	0.46	0.85	1.7	3.7	6.8	
θ_1		$\times 10^{-4}$ rad	5	4.1	4.6	3.9	4.4	4.4	4.4	4.1	
		arcmin	1.7	1.4	1.6	1.3	1.5	1.5	1.5	1.4	
θ_2		$\times 10^{-4}$ rad	16	12	13	9.7	11.3	11.1	11.6	11.1	
		arcmin	5.4	4.2	4.3	3.3	3.9	3.8	4	3.8	

27.2 Torsional Quantity Calculation Example

Take eRob110H100I-BM-18EN as an example to calculate the angular displacement (θ).

(1) When the load torque is extremely small ($T_{L1}=2.9$ Nm)

As the torque is T_1 or less, angular displacement θ_{L1} is represented as follows.

$$\theta_{L1} = \frac{T_{L1}}{K_1} \tag{27.1}$$

$$\theta_{L1} = \frac{2.9}{3.1 \times 10^4}$$

$$\theta_{L1} = 9.4 \times 10^{-5} rad (0.33 arc min)$$

(2) When the load torque is extremely small ($T_{L2}=39$ Nm)

As the torque between T_1 and T_2 , angular displacement θ_{L2} is represented as follows.

$$\theta_{L2} = \theta_1 + \frac{T_{L2} - T_1}{K_2} \tag{27.2}$$

$$\theta_{L2} = 4.4 \times 10^{-4} + \frac{39 - 14}{5.0 \times 10^4}$$

$$\theta_{L2} = 9.4 \times 10^{-4} rad (3.2 arc min)$$

The total angular displacement when the load is applied the other way round will be double the quantity obtained above plus the backlash quantity.

Note: Note that the angular displacement indicates the value of the each eRob rotary actuator only. The angular displacement of the output shaft is not included.

27.3 Hysteresis Loss

As shown in [Figure 27-1a](#), when the torque is applied up to the rated value and is brought back to “0”, the torsional angle does not become absolutely “0”, and a small amount remains (B—B’). This is called hysteresis.

Table 27-2 Hysteresis loss quantity for each eRob model

Gear Ratio	Model		eRob70F	eRob70	eRob80F	eRob80	eRob90	eRob110	eRob142	eRob170
	Unit									
50	$\times 10^4 rad$		7.3	5.8	5.8	5.8	5.8	5.8	5.8	5.8
	<i>arc min</i>		2.5	2.0	2.0	2.0	2.0	2.0	2.0	2.0
>50	$\times 10^4 rad$		5.8	2.9	2.9	2.9	2.9	2.9	2.9	2.9
	<i>arc min</i>		2.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

27.4 Backlash

As hysteresis loss is mainly generated by internal abrasion, it is hardly generated, and only a small allowance is represented in the diagram when the torque is extremely small. This quantity is expressed as the backlash quantity.

As the allowance of the tooth engagement is suppressed to “0” for the gear, the backlash quantity is caused by the clearance of the connection of mechanical structures.

Chapter 28 Back-Driving by External Force

- (1) The actuator can be rotated with a small external force under the condition of motor disabled and the brake released separately (please refer to [Section 7.3](#) for more details), because there is still friction and the magnetic induction force produced by motor dragging and the magnetic induction force is that the greater the rotation speed, the greater the resistance, so it is necessary to apply a torque with the help of a certain force arm to rotate the joint.
- (2) Use the torque mode (CST mode or PT mode), set the target torque (object dictionary 0x6071) to 0, and then enable the actuator. At this time, the external force required to rotate the actuator by external force is smaller than that of releasing the brake alone.
- (3) If you want to further reduce the drag force, the usual method is to first identify the friction force and load gravity of the actuator through the drag teaching function of the controller, and then send commands to the actuator through the torque feed-forward (object dictionary 0x60B2) to compensate the friction force and load gravity.
- (4) You can use the torque sensor of the actuator (please refer to [Chapter 22](#)) as a feedback of the external force, and after the calculation and processing of the force by the controller, send commands to the actuator through the torque feed-forward (object dictionary 0x60B2) for compensation.

Note: Note: For the instructions of CST mode and PT mode, refer to *Chapter 5* of [eRob CANopen and EtherCAT User Manual](#), and for the object dictionary description, refer to *Section 8.2* of [eRob CANopen and EtherCAT User Manual](#).

Appendix A Safety Precautions for Multi-Turn Encoder Battery

- (1) Do not place the battery at random to prevent short circuit.
- (2) Do not heat or place the battery in an environment of 100°C.
- (3) Do not charge the battery.
- (4) Do not disassemble and dissect the battery.
- (5) Do not use the positive and negative electrodes in reverse connection with the electrical equipment.
- (6) Do not use a soldering iron directly on the battery surface to solder or contact other high-temperature objects.
- (7) Do not perform various environmental and safety tests such as extrusion and impact without any protective conditions.
- (8) Do not put the battery into water or use or store it in a humid environment without protection.
- (9) Do not use the battery in the equipment without setting the cut-off voltage point. After reaching the cut-off voltage point, it must be removed from the equipment immediately to prevent the deep discharge of continuous current operation.
- (10) Do not use the battery if you find any heat, odor, discoloration, deformation or other abnormality in the battery during use or storage.
- (11) Dispose of the used battery in accordance with local environmental regulations, buried deep in the ground or thrown into salt water.
- (12) Rinse with plenty of water and seek medical treatment immediately if the liquid inside the battery splashes on the skin, eyes and clothes.
- (13) Do not use and store battery in the place with static electricity.
- (14) Store battery in an environment where the temperature does not exceed 30°C and the relative humidity is 45% ~ 75%.
- (15) Store battery away from heat sources, away from corrosive gas environments, and avoid direct sunlight, and ensure that the storage area is clean, cool, dry and ventilated.
- (16) Keep battery in their original packaging when not in use, and the batteries should not be piled up after removing the packaging.
- (17) Protect battery from sunlight, fire, rain, water and corrosive substances during transportation.
- (18) Limit the shock and vibration during transportation and handling to a minimum.
- (19) Place battery away from the engine when the battery is transported long-distance by ship; Do not leave in an unventilated environment for a long time in summer.

Appendix B Error Codes and Suggestions

Please refer to *Section 7.2 Device Error* in [eRob CANopen and EtherCAT User Manual](#) for more details.

Appendix C Warranty

C.1 Warranty Period and Scope

1. Within a period of seven (7) days from the day following the customer's reception of the product, in the event of non-human-induced performance failure, subject to confirmation by the ZeroErrAfter-Sales Service, the customer shall be entitled to initiate an exchange procedure. The customer is required to furnish a valid purchase receipt.
2. From eight (8) days to three hundred sixty-five (365) days after the customer's receipt of the product, upon verification by the ZeroErrAfter-Sales Service that the issue pertains to an inherent quality fault of the product, priority replacement service shall be granted. It is to be noted that this product undergoes a series of stringent factory tests, and ZeroErr reserves the right to decline the customer's requests for return or exchange in cases where the issue does not originate from an inherent quality fault of the product.
3. When the product is operated, used, and maintained in accordance with the specifications and instructions specified in the technical documentation, manuals, and catalog, the warranty period shall be eight (8) days to three hundred sixty-five (365) days after the customer's receipt of the product or two thousand (2000) hours of operation, whichever occurs first. Exceeding either of these durations will result in the loss of warranty eligibility.

C.2 Warranty Terms

This limited warranty does not apply to any product that has been subject to:

1. Disassembling, modification or repair by others than ZeroErr;
2. User's misapplication, improper installation, inadequate maintenance, or misuse;
 - ① Unauthorized disassembly of the eRob rotary actuator, resulting in damage to the tamper-evident seal;
 - ② Occurrence of product abnormalities subsequent to conducting destructive tests, including but not limited to extreme temperature variations, humidity exposure, overloading, submersion, electromagnetic compatibility (EMC) testing, vacuum testing, and similar assessments;
 - ③ Any abnormal product performance or damage resulting from the failure to operate the product in accordance with the user manual provided by ZeroErr;
 - ④ Issues related to power interfaces, including but not limited to detachment, looseness, melting, or poor contact, as well as issues related to communication interfaces, including but not limited to detachment or looseness;
 - ⑤ Damage to threaded mounting interfaces, including stripped threads or broken screws;
 - ⑥ Severe impact damage characterized by external damage exceeding 3mm in any direction, or the presence of protrusions or depressions exceeding 0.02mm.;
 - ⑦ Occurrence of collisions during either loaded or unloaded operation;
 - ⑧ Damage to circuit protection devices or electrostatic discharge (ESD) protection circuits, including but not limited to fuses, current-limiting resistors, current-limiting resistors for CAN or RS485 communication interfaces, and transient voltage suppression (TVS) diodes;
 - ⑨ Product performance issues discovered after seven (7) days, including but not limited to noise, jittering, vibration, and accuracy insufficiency, which are influenced by various factors such as installation compliance, design reasonableness, repeated assembly

and disassembly, transportation, wear and tear during normal use;

3. Imperfection caused by something other than the product;

4. Disaster or other occurrences that do not belong to the responsibility of ZeroErr

Our liability shall be limited to the product as found by ZeroErr to be defective. ZeroErr shall not be liable for consequential damages of other equipment caused by the defective product, and shall not be liable for the incidental and consequential expenses and labor costs associated with disassembly and installation to the driven equipment.

Declaration

Our product is not designed or intended for use outside the environmental limitations and operating parameters expressly stated on the product's datasheet. Products are not designed or intended for use in medical, military, aerospace, automotive or oil, gas applications or any safety-critical applications where a failure of the product could severe serious environmental or property damage, personal injury, or death. Any use in such applications must be specifically agreed to seller in writing and is subject to such additional terms as the seller may impose in its sole discretion. Use of products in such applications is at buyer's own risk, and buyer will indemnify and hold harmless seller and its affiliates against any liability, loss, damage, or expense arising from such use. Information contained in this datasheet was derived from product testing under controlled laboratory conditions and data reported thereon is subject to the stated, then to tolerances and variations, or if none are stated, then to tolerances and variations consistent with usual trade practices and testing methods. The product's performance outside of laboratory conditions, including when one or more operating parameters is at its maximum range, may not conform to the product's datasheet. Further, information in the product's datasheet does not reflect the performance of the product in any application, end-use or operating environment buyer or its customer may put the product to. Seller and its affiliates make no recommendation, warranty, or representation as to the suitability of the product for buyer's application, use, end-product, process, or combination with any other product or to any results buyer or its customer might obtain in their use of the product. Buyer should use its own knowledge, judgment, expertise, and testing in selecting the product for buyer's application, and-use and/or operating environment, and should not rely on any oral or written statement, representation, or samples made by seller or its affiliates for any purpose. Except for the warranties expressly set forth in the seller's terms and conditions of sale, seller makes no warranty express or implied with respect to the product, including any warranty of merchantability or fitness for any particular purpose, which are disclaimed and excluded. All sales are subject to seller's exclusive terms and conditions of sales which, where the seller is another person, are available on request, and in each case, are incorporated herein by reference, and are exclusive terms of sale. Buyer is not authorized to make any statements or representations that expand the environmental limitations and operating parameters of the products, or which imply permitted usage outside of that expressly stated on the datasheet or agreed to in writing by seller.

ZeroErr has made considerable effort to ensure the content of this document is correct at the date of publication but makes no warranties or representations regarding the content. ZeroErr excludes liability, howsoever arising, for inaccuracies in this document.

ZEROERR CONTROL CO., LTD.

About Us




ZeroErr was founded in December 2016 in ShenZhen, China. ZeroErr stands for Zero Error Motion Control.

We design, develop and manufacture rotary actuators and encoders which are widely used in automation industry, collaborative robots, surgical robots and bionic robots. More than thousands of customer groups in the global use simple combinations with our products makes wide range of applications.

ZeroErr is committed to providing reliable quality standard production, cost-effective products and quick response technical support, enabling our customers to accelerate innovation, improve productivity and achieve extraordinary application performance.

ZeroErr

Address:  Bldg 1, Unit 4, Dejin Industrial Park, 40 Fuyuan 1st Road, Fuhai St, Bao'a Shenzhen, Guangdong, P.R.China

Sales Support:  marketingdirector@zeroerr.cn  +86-13602607132
 overseas_dpt@zeroerr.cn  +86-19166212693

Technical Support:  otss@zeroerr.cn  +86-18922807806

Advice & Complaint:  network@zeroerr.cn

Global Support

Visit our website to contact your nearest sales representative.

www.zeroerr.com